

Terex Calibration and Troubleshooting Manual



TABLE OF CONTENTS

Introduction.....	3
1.1 Overview and Preparation.....	3
2.1 System Self-Test	4
2.2 Display Console Problems	5
2.3 Fault Reporting and Fault Codes	6
2.3.1 Group “A” Fault Codes	7
2.3.2 Group “B” Fault Codes	7
2.3.3 Group “C” Fault Codes	8
2.3.4 Group “D” Fault Codes	8
2.4 “No Fault Code” Problem	9
2.4.1 Anti-Two-Block Alarm (ATB).....	9
2.4.2 Displayed Load or Radius Errors.....	9
3.1 Computer Unit Overview	12
3.2 Intern Status Indicators	12
3.3 Function Kickout Fuse (FUS1)	13
3.4 Replacing the Computer Unit	13
4.1 Display Console Overview	14
4.2 Checking the Display Console.....	14
4.3 Unresponsive Buttons	15
4.4 Connectors.....	15
4.5 Horn	16
4.6 Moisture	16
4.7 Replacing the Display Console.....	16
5.1 Entering the Calibration Mode.....	17
5.2 Calibration Steps.....	18
5.3 Calibrating Menus	19
5.4 Calibrating the Extension Sensor Zero	20
5.5 Calibrating the Angle Sensor Zero	21
5.6 Calibrating Span of Extension and Angle	22
5.7 Calibrating the Swing Potentiometer	24
5.7.1 Calibrating Swing Direction.....	25
5.7.2 Cranes with Swing Switches.....	25
5.8 Calibrating the Outrigger Position Sensors.....	26
5.8.1 Enabling and Disabling the Outrigger Position Sensors.....	28
5.9 Calibrating the Frame-Level Sensor (If Equipped).....	29
5.10 After the Calibration Routine	31
6.1 Reeling Drum Overview	32
6.2 Checking the Reeling Drum Cable Layering.....	33
6.3 Sensor Baseplate Assembly	34
6.4 Anti-Two-Block Function Overview.....	36
6.5 Checking the Reeling Drum Cable	36
6.6 Checking the Anti-Two-Block Circuit	36
7.1 Swing Sensor Overview	38
7.2 Checking the Swing Sensor Drive Voltage	39
7.3 Checking the Swing Sensor Output Voltage.....	39
7.4 Checking the Swing Sensor Resistance.....	39
8.1 Frame-Level Sensor (If Equipped)	40

Introduction

The Greer Element system is designed as an aid to crane operation. The operator must be knowledgeable in safety guidelines, crane capacity information, and crane manufacturer's specifications.

This manual describes the setup and maintenance of the system. Please read the instructions in this manual.

1.1 Overview and Preparation

This manual provides general information and methods for isolating problems that may happen during operation. Service personnel should have previous training and experience in the procedure for setup and operation of this system. Some problems may require the replacement of parts or return of parts to the factory for servicing.


The procedures in this manual are based on crane operation and function, where possible. Required tools:

- Tool kit consisting of wrenches and screwdrivers (flat and Phillips)
- Digital level accurate to 0.1°
- 150-200 ft tape measure graduated in tenths of a foot
- Digital multimeter

NOTE: Low cost analog multimeters are not appropriate; their input impedance may give inaccurate readings.


2.1 System Self-Test

When the power is turned on, the system performs a self-test. This verifies the computer, display console, cable, and sensors are working properly. During the self-test, the display will show the expected crane model, load chart number, and units of measurement.



(NOTE: Display message is crane dependent.)

When the display shows the following screen, press the “PRESS TO CONTINUE” button.



If the above does not occur, refer to **Display Console Problems**.

2.2 Display Console Problems

Display console problems can be difficult to isolate due to the interaction between the display and the computer unit. Failure of either unit or the cabling connecting the units can cause a malfunction.

To solve problems using the display indicators, observe the display at power up and through the self-test. Use the following chart to help with the diagnosis:

Problem	Action
There are no display indications in any of the windows when the power is turned on.	Refer to Internal Status Indicators .
The load, angle, radius, length, and rated capacity windows do not show "188.8" and the bar graph is not fully illuminated during the self-test.	Refer to Replacing the Display Console .
The red and yellow indicators do not illuminate during the self-test.	Refer to Replacing the Display Console .
The display unit does not cycle through the self-test. The data in the display windows appears jumbled with missing segments.	Refer to Replacing the Display Console .
The display lights are illuminated. Load, angle, radius, length, and rated capacity show "188.8" or "888.800" for load and capacity, but the display shows: "Bad communications with main computer"	Display console is OK. Check the connectors on the back of the display console. Refer to The COMM Indicator .


2.3 Fault Reporting and Fault Codes

System fault codes provide ways to locate and assess problems within the Element system. Each time the system is turned on, it performs a self-test that lasts approximately 6 seconds. Many fault conditions are detected without a system self-test.

Faults detected during the self-test are indicated on the display console:

- The red overload indicator will illuminate.
- The ALARM will sound.
- “WARNING SYSTEM FAULT!” will display at the bottom of the text window.

To view the fault codes, press and hold the (i) button as shown.



There are four groups of FAULT CODES: A, B, C & D. The function of these groups and a complete listing of each code are provided on the following pages.

NOTE: Always investigate “B” and “C” faults before continuing with “A” and “D” faults.

2.3.1 Group “A” Fault Codes

Group “A” fault codes represent faults detected for analog sensors.

NOTE: Check and repair “B” and “C” group faults before proceeding with group “A” fault finding sensors.

The following chart details all the available codes in the left column and the actions to take in the right column.

FAULT CODE	SWING SENSOR	BOOM ANGLE SENSOR	EXTENSION SENSOR	TDX 1 ROD PRESSURE	TDX 0 PISTON PRESSURE	ACTION
000	No Fault Found					None
001					X	Refer to Replacing the Computer.
002				X		
003				X	X	
004			X			Refer to Calibrating the Extension Sensor Zero, Calibrating Span of Extension and Angle, and Reeling Drum Voltage Checks.
008		X				Refer to Calibrating the Angle Sensor Zero, Calibrating Span of Extension and Angle, and Reeling Drum Voltage Checks.
012		X	X			Refer to Calibrating the Angle Sensor Zero, Calibrating the Extension Sensor Zero, Calibrating Span of Extension and Angle, and Reeling Drum Voltage Checks.
016	X					Refer to Calibrating the Swing Potentiometer, and Reeling Drum Voltage Checks.

2.3.2 Group “B” Fault Codes

Group “B” fault codes represent faults detected for internal analog functions and power feeds to the function kickout and anti-two block switches.

The following chart details all of the available codes in the left column and the actions to take in the right column.

FAULT CODE	FKO POWER FEED	ATB POWER FEED	DISPLAY CONSOLE	ADC 2 INTERNAL FAULT	ADC 1 INTERNAL FAULT	ACTION
016	X					Check the Crane Circuit Breakers

2.3.3 Group “C” Fault Codes

NOTE: Group “C” fault codes represent faults detected for internal computer memories.

The following chart details all the available codes in the left column and the actions to take in the right column.

FAULT CODE	SERIAL EEPROM	CRANE DATA	RAM	DUTY DATA	PROGRAM	ACTION
000	No Fault Found					NONE
008		X				Erase crane data.
016	X					Refer to Replacing the Computer.

2.3.4 Group “D” Fault Codes

NOTE: Group “D” fault codes represent faults detected for capacity chart selection.

The following chart details all the available codes in the left column and the actions to take in the right column.

FAULT CODE	WRONG SWING AREA	WRONG BOOM LENGTH	CHART NOT FOUND	ACTION
000	No Fault Found			NONE
001			X	Check other sensor faults first, Re-select CRANE SETUP
002		X		Boom length is out of range for selected chart. Check crane setup, boom length and extension.
003		X	X	Check other sensor faults first, Re-select CRANE SETUP
004	X			Swing to correct working area to select chart. Check swing sensor zero position.
005	X		X	Swing to correct working area to select chart. Check swing sensor zero position.
006	X	X		Check other sensor faults first, Re-select CRANE SETUP
007	X	X	X	Check other sensor faults first, Re-select CRANE SETUP

2.4 “No Fault Code” Problems

This section addresses problems not reported by the computer fault code system.

2.4.1 Anti-Two-Block Alarm (ATB)

This section gives direction to fault diagnosis of ATB alarm problems. For detailed information, schematic, and voltages, refer to **ANTI-TWO-BLOCK FUNCTION OVERVIEW**.

PROBLEM:

- *The Anti-Two-Block alarm is continuously ON. Operating the switch at the boom head does not deactivate the alarm.*

This problem suggests an open circuit between the computer ATB input and the ATB switch, or an open circuit between the computer ATB feed and the ATB switch. Check the reeling drum cable for damage. Ensure the two-block switches are correctly connected. Check the slip-ring and wiring inside the extension reel. Check the signal cable from the extension reel to the computer. Check the connectors.

PROBLEM:

- *The Anti-Two-Block alarm is continuously OFF (safe). Operating the switch at the boom head, by lifting the ATB weight does not activate the alarm.*

This problem suggests a short circuit between the computer ATB input and the computer ATB feed somewhere between the computer and the ATB switch. Check the reeling drum cable for damage. Ensure the two-block switches are correctly connected. Check the slip-ring and wiring inside the extension reel. Check the signal cable from the reel to the computer. Check the connectors.

2.4.2 Displayed Load or Radius Errors

This section gives direction to fault diagnosis of load and radius errors. Load or radius errors can cause early or late tripping of overload alarms. Accuracy of load is governed by the radius accuracy, and the extension, angle, and pressure sensors. The accuracy of the radius (unloaded) value is governed by the extension and angle sensors.

Ensure there are no system faults before continuing.

2.4.2.1 Check Boom Extension

1. Ensure the boom is fully retracted.
2. Ensure the reeling drum cable is correctly layered as a single layer across the extension reel surface. Any stacking of the cable will cause extension errors when the boom is fully retracted. This will cause the System to exceed the 0.5 ft tolerance allowed by the computer for boom mode selection. If the reeling drum cable is stacking on the reel, refer to **CHECKING THE REELING DRUM CABLE LAYERING**.

3. Check the zero of the extension sensor with the boom fully retracted. Enter the Calibration Mode and use the "SPAN" command. Select sensor No. 2 to view the extension value in feet. The value of extension must be between -0.2 and +0.2, with the boom fully retracted. If the extension value is incorrect, refer to **ENTERING THE CALIBRATION MODE**. Fully telescope the boom and ensure the displayed boom length value matches the maximum length of the boom. If the length value is incorrect, follow the EXTENSION SPAN procedure in **CALIBRATING SPAN OF EXTENSION AND ANGLE**.

2.4.2.2 Check Main Boom Radius

NOTE: The required accuracy of taped radius measurements is within 0.1 feet. When taking radius measurements use a good quality tape that does not stretch. The tape should be graduated in feet and tenths of a foot. Always measure between the swing center of the crane and the hook line, using a single part of line with the crane centered over front (rough terrain) or centered over rear (truck crane).

1. Fully retract the boom and ensure the crane configuration is correctly set up.
2. Raise the boom to about 45° and measure the radius. The measured radius must match the displayed radius within +/- 0.1 ft. If it does not match, continue to the **CALIBRATING THE ANGLE SENSOR ZERO** procedure.
3. Raise the boom to a high angle (at least 70°) and measure the angle with the inclinometer. Ensure the displayed angle matches the inclinometer reading within 0.2°. If the displayed angle is incorrect, follow the angle span calibration procedure in **CALIBRATING SPAN OF EXTENSION AND ANGLE**.

2.4.2.3 Check Boom Angle

NOTE: The required accuracy of measured angles is within 0.2°. When taking boom angle measurements use a good quality inclinometer. Many inclinometers are only accurate near 0° (level). Ensure the digital inclinometer is securely mounted to the boom.

1. Fully retract the boom.
2. Using an inclinometer set the boom to 0° and ensure the displayed boom angle value is 0.0°. If the angle value is not 0.0°, refer to **CALIBRATING THE ANGLE SENSOR ZERO**.
3. Raise the boom to a high angle (at least 70°) and measure the angle with the inclinometer. Ensure the displayed angle matches the inclinometer reading within 0.2°. If the displayed angle is incorrect, refer to **CALIBRATING SPAN OF EXTENSION AND ANGLE**.


2.4.2.4 Check Pressure Sensors

There are two pressure sensors installed as part of the system. Both pressure sensors are mounted within the computer unit. One is connected to the piston side of the boom hoist cylinder via flexible hose; the other is connected to the rod side of the boom hoist cylinder via flexible hose. Both hoses are protected by velocity fuses within the boom hoist cylinder valve block on the end of the cylinder.

The pressure sensor located on the piston side, is subject to the hydraulic pressure needed to support the weight of the boom, any attachments, and the load. The pressure sensor on the rod side monitors the pressure necessary to control the down motion of the boom. The computer unit uses this information (along with other sensors such as extension, length, and angle), to compute the weight of the suspended load. The maximum continuous working pressure for the sensors is 250 bar (3625 PSI).

The pressure sensing system is calibrated at the factory. Pressure sensors may not be individually replaced. Any serious problem will necessitate changing the entire computer unit.

1. Lower the boom until the boom hoist cylinder is fully retracted and on its stop.
2. Loosen the hydraulic connections to the pressure sensors to ensure zero pressure is present on the sensors.
3. Enter the calibration mode and press “Menu Up” button to access “14 PRESSURE MONITOR” to view both sensor pressures and net pressure.
4. Check the pressure values of both sensors. The pressure values should be between -75 and +75 PSI. If not, replace the computer unit.
5. Check the nett pressure value. This should be between -35 and +35 psi. If not, replace the computer unit.



WARNING!


BOTH PRESSURE SENSORS ARE PRE-CALIBRATED FROM THE FACTORY AND SUPPLIED AS PART OF THE COMPUTER. THE PRESSURE SENSORS MAY NOT BE REPLACED. REMOVAL OR REPLACEMENT OF THE PRESSURE SENSORS FROM THE COMPUTER INVALIDATES THE WARRANTY AND WILL ADVERSELY AFFECT THE PRESSURE CALIBRATION.

3.1 Computer Unit Overview

The computer unit is the center of the system. It reads the sensors, controls computations and disconnect functions, and communicates with the display console/internal bar graph.

Two hydraulic pressure sensors are contained in the computer unit. These sensors measure the rod-side pressure and piston-side pressure in the boom hoist cylinder. They are factory calibrated at production and cannot be replaced in the field.

NOTE: Due to differences in computer unit configurations, the locations of board components may vary.



3.2 Internal Status Indicators

The computer unit contains a row of LED indicators for checking computer operation. During normal operation, all LEDs will be illuminated with the COMM indicator blinking. If not, please contact technical support for assistance. Use the following chart and preceding images for LED location.

LED Indicator	Function
D7	Communication Indicator TST0
D8	Battery Power_POS
D9	Communication Indicator TST1
D10	+VP
D11	+10V
D12	COMM (Communication Indicator)
D13	+8V2
D14	+5V
D17	+3V3

3.3 Function Kickout Fuse (FUS1)

NOTE: Prior to replacing the fuse, ensure any electrical shorts have been removed.

The computer unit contains a standard 10 amp replaceable fuse. The fuse protects the function kickout circuit and relay contacts, if a short circuit occurs across the crane kickout solenoids. Replace the fuse if the system error codes indicate that the function kickout power feed is missing. Ensure the crane circuit breaker is closed and power from the crane is present.

3.4 Replacing the Computer Unit

Computer Removal

1. Lower the boom until the boom hoist cylinder is completely retracted and on its stop or the boom is firmly in the boom rest.
2. Disconnect the hydraulic connections at the computer unit. Cap the end of the hydraulic hoses.
3. Disconnect both electrical connectors at the computer unit.
4. Remove the hardware securing the computer to the cab wall.

Computer Installation

1. Secure the computer unit to the cab wall with the mounting hardware.
2. Ensure the electrical connections face downward.
3. Connect the electrical connectors.
4. Remove the protective caps from the hydraulic ports.
5. Connect the base-side pressure (green band) hose to the piston pressure port.
6. Connect the rod-side pressure (red band) hose to the rod pressure port.

4.1 Display Console Overview

The display console allows the user to see the crane values and crane configuration selection. The display also provides calibration functions used for testing and fault diagnosis.



4.2 Checking the Display Console

When operated under extreme conditions the console can become damaged. The damage is not always apparent. To help identify subtle faults that are sometimes difficult to find, please review the following comments.

4.3 Unresponsive Buttons

All button options are not available for use at all times. It is important to verify the non-responsive button:

- Is programmed to respond during the operation of the system. In Calibration Mode, only the circled buttons will work with a few exceptions. The Configuration button will allow you to access the Configuration page, but the user will not be allowed to make any changes. The Brightness/Contrast button will allow the display to be adjusted.



- Being pressed in the center, pressing the printed symbol 'at one end' may not activate the switch underneath.
- Is not damaged or has a surface that is worn which may cause the switch underneath to operate improperly. In this case, refer to **REPLACING THE DISPLAY CONSOLE**.

4.4 Connectors

Connect the Deutsch connector in the upper left corner marked "A".



4.5 Horn

Ensure the horn is connected to the wiring harness via the two-pin Deutsch connector.

4.6 Moisture

The display console offers protection against dust and water, when correctly installed.

4.7 Replacing the Display Console

Removal

1. Disconnect the electrical cable from the rear of the operator's display console.
2. Remove the knob on each side of the console and retain for future use.
3. Remove the defective display console from the bracket in the cab.

Installation

1. Put the operator's display console on the bracket located in the cab by positioning it between the bracket legs.
2. Insert and tighten the knob on each side of the console.
3. Connect the electrical cable to the rear of the console.

5.1 Entering the Calibration Mode

The Greer Element system is an aid to crane operation. Do not use this system in place of an operator trained in safety guidelines, crane capacity information, and the crane manufacturer's specifications.

When the computer is new, it has no zero or span calibrations. It is necessary to enter zero and span points for accurate length and angle calculations.

Tools Needed:

- Digital level accurate to 0.1°
- 150-200ft. tape measure graduated in 1/10ths
- Digital multimeter


Pre-Requisites for Calibration

- The crane must be properly set on level ground per the manufacturer's specifications.
- Maximum boom height will be necessary for calibration. Ensure the area is free of overhead obstructions.
- All options such as jibs, fly's, auxiliary heads, etc. must be setup in the computer.

5.2 Calibration Steps

Follow the steps below to ensure proper calibration of the Element unit. The actual crane setup must be reflected on the display. Check the **Element Operator's Manual** for proper crane configuration after the calibration.

1. To enter calibration mode, the display must be in "Normal Operating" mode.
2. Press and hold the information and operator alarm buttons simultaneously until the display prompts the user for the security code.



3. Enter the security code within 5 seconds, or the system will revert to the "Normal Operating" mode. Press the buttons in the numerical order displayed.



5.3 Calibration Menus

Once the security code has been entered, the display will show the following menu.




The main menu items used to calibrate the system are:

- 02 Zero Sensors
- 03 Span Sensors
- 04 Swing Potentiometer

The only calibrations needed are for boom extension and boom angle. They must be properly set to zero. On machines with string potentiometer style outrigger position sensors, if a sensor is replaced, it will need to be calibrated. Refer to **CALIBRATING THE OUTRIGGER POSITION SENSOR**.

The system is also equipped with a swing potentiometer. This is designed to track the turret in relation to the chassis.


Boom extension and angle readings are dependent on the correct span values to be entered into the system. These span values are determined by using a digital level on the boom angle, and measuring the span of boom extension.




$$\text{Extended Length} - \text{Retracted Length} = \text{Span}$$

5.4 Calibrating the Extension Sensor Zero

1. Fully retract and lower the boom to 0.0°. Verify using a digital level.
2. Remove the cover from the reeling drum to expose the baseplate sensor assembly.
3. Rotate the extension sensor gear clockwise until the clutch drags/clicks, and rotate another ½ turn counterclockwise.
4. The voltage reading between the blue wire TB1-1 and the white wire TB1-3 on the terminal block should measure 0.15V to 0.35V. Rotate the gear to attain the proper voltage with the boom fully retracted.




5. Press the “Menu Up” button until “02 Zero Sensors” is reached.
6. Press the “02 Zero Sensors” button.
7. Press the “Zero No. 2 = ” button to be prompted with “Yes! Calibrate!”
8. Press the button a second time to calibrate the zero.
9. The display will then read “Zero No. 2 = 0 ” as shown. The retracted boom length will be displayed in the boom length window. Extension zero calibration is complete.




5.5 Calibrating the Angle Sensor Zero

The angle sensors are preset to zero on the potentiometer before leaving the factory. If the potentiometer is disturbed, the zero setting can be affected. If this happens, the angle sensor will be inaccurate.

If the factory setting has been disturbed, reestablish it by loosening the securing screws, and rotating the pot until the desired voltage reading is attained.



1. Place the boom to 0.0 degrees. Verify using a digital level.
2. Check the voltage between TB1-1 and TB1-2. It should measure between 0.4V and 0.6V in the correct position.
3. Enter the "02 Zero Sensors" menu. Press the "Menu Up" button to display "Zero No.3 = 0". The calibration and boom angle window should read 0.0.
4. Press the "Zero No. 3 =" to be prompted with "Yes! Calibrate!" Press the button a second time to calibrate the zero. The calibrating the angle sensor zero routine is complete.




5.6 Calibrating Span of Extension and Angle

WARNING!

THE AREA OVERHEAD ABOVE THE CRANE MUST BE CLEAR OF OBSTRUCTIONS PRIOR TO CALIBRATING SPAN OF EXTENSION AND ANGLE!


In order for the system to properly calculate the boom length and the boom angle, the “Span Number” must be entered into the system. Obtain the Span Number with the following steps:

1. Measure the boom from the base foot pin to the center of the head sheave pin. Record this measurement.




$$\text{Extended Length} - \text{Retracted Length} = \text{Span}$$


2. Raise the boom to between 60-65° and fully extend the boom. Record the measurement from the digital level for entry into the system later in this procedure.
3. From the calibration menu screen, press the “Menu Up” button until “03 Span Sensors” and press the button.
4. Press the “Span No. 2 = X.X ” button.
5. Press the button again to be prompted with “Yes! Calibrate!”
6. Press the “Yes! Calibrate!” button.
7. Use this screen to enter the span (Extended Length – Retracted Length = Span).



- The lower left and lower right buttons are used to select the number. The number inside the brackets is the current selection, in this image, the number 4 is between the brackets.



- Use the upper left button to enter the numbers, one at a time.
- When the number is entered, press the upper right button to enter the number into the system memory. Span of extension is now complete.
- Press the “Menu Down” button to display “Span No. 3 = xx.xx”.
- Press the “Span No. 3 = xx.xx” button.
- Press the “Yes! Calibrate!” button.



- You will be prompted with the same screen from step 6. Use this screen to enter the span of angle measurement from the digital level.
- This calibration routine is now complete. Press the “Exit” button to return to the calibration menu.

5.7 Calibrating the Swing Potentiometer

After completing the extension and angle span, return to the main calibration screen.

1. Press the “Menu Up” button until “04 Swing Potentiometer” is reached. This menu will allow a zero point to be set on the swing circle and a direction for the system to track the rotation angle.
2. The swing must be in the stowed position and the house lock engaged.

NOTE: Inaccuracy in the swing zero setting may result in the loss of load chart for pick and carry.

3. Press the “Zero” button to zero the swing.



4. The swing potentiometer zero is now set.

5.7.1 Calibrating Swing Direction

For consistency, the swing should count upwards (0, 1, 2, 3, etc.) when rotating clockwise. The direction of the swing can be changed while using the Greer Element display.

1. With the zero calibrated, if the swing direction is wrong, press the “Menu Up” button twice.
2. Press the “Direction = ‘-’ “ button to reverse the direction.



5.7.2 Cranes with Swing Switches

On units with swing switches, the swing potentiometer input can be disabled.

1. Enter the calibration mode and press the “Menu Up” button to “04 Swing Potentiometer”.
2. Press the “04 Swing Potentiometer” button menu and press the “Menu Up” button until the “Remove Swingpot?” option is displayed.



3. Press the “Remove Swingpot?” button.
4. The crane will now use the swing switches.


5.8 Calibrating the Outrigger Position Sensors

If an error code is displayed for a particular outrigger sensor, contact service for assistance.


For cranes with digital switch outrigger position sensors, contact service for assistance. No calibration is needed.

When directed by service to replace the string potentiometer outrigger position sensors, calibration is needed.


1. Enter the Outrigger Sensor calibration menu.
2. In the lower left portion of the screen, “Current Sensor: = CAN String Pots” will be displayed. If this is not correct, press the button once to toggle to “Current Sensor: = CAN String Pots”.




3. Press the “Configure Sensors” button.
4. Install the outrigger position sensors one at a time.
 - a. Install the front left string potentiometer. “New device found” will appear on the display.



- b. Press the “Configure Front Left” button to identify the new sensor location in the computer.
 - c. Repeat these steps and install the remaining sensors.
 - d. The message will change from “Configure” to “Reset” when calibration is finished.
5. With all sensors installed, ensure the outriggers are in the fully retracted position. Press the fully retracted position button to set the retracted position in the computer.



6. Move the outriggers to intermediate position and press the corresponding button to set the intermediate outrigger position.




7. Move the outriggers to fully extended position and press the corresponding button to set the fully extended outrigger position.



8. The outrigger position sensors are now calibrated.

5.8.1 Enabling and Disabling the Outrigger Position Sensors


Once in the Outrigger Position Sensing menu, the user can “Enable” or “Disable” the Outrigger Position Sensors. Press the circled button to toggle between the two options.




5.9 Calibrating the Frame-Level Sensor (If Equipped)

This is the procedure for calibrating the frame-level sensor on a new machine, or after replacing a faulty frame-level sensor. Ensure the sensor is mounted to a flat surface, this can affect the calibration.

1. Press the “Frame-Level” button, circled below.



2. This will access the frame-level screen.



3. Enter the security code to calibrate the frame-level sensor. Press the buttons in the order shown.



4. This allows access to the Initialize ("Init") and Zero ("Zero") functions.



5. Press the “Init” button to activate the sensor. *NOTE: To ensure proper operation, this must be done the first time the device is connected and powered on. This must also be performed with a replacement sensor, in the event of a failure.*
6. Using a method other than the frame-level sensor, ensure the machine is level on the X-axis and the Y-axis.
7. Press the “Zero” button. The display will now show 0.0° for the X and Y-axis.



8. The frame-level sensor is now calibrated.

5.10 After the Calibration Routine


When the calibration routine is complete, thoroughly test the machine to ensure the radius is accurate to + 0.5 of a foot.

In order to perform load testing, a known weight is necessary. Perform testing from 2-3 different boom angles, as well as extensions.

The load shown must be within 0 to +10% when testing. If the load is outside these limits, the calibration should be rechecked for accuracy. The displayed load should not be lower than the actual weight.

6.1 Reeling Drum Overview

The primary operation of the reeling drum is to measure the extension of the telescoping sections of the main boom. The reeling drum also includes an angle sensor to measure the main boom angle along with an electrical slip-ring which transfers the two-block signal from the reeling drum cable to the system computer. It is important the setup and maintenance of these devices is properly carried out per the procedures in this manual. Incorrect maintenance can result in system calculation errors.




6.2 Checking the Reeling Drum Cable Layering

The extension reel is designed to provide accurate measurement of boom extension. To provide accurate measurement, the reeling drum cable must form a single flat layer across the surface of the reeling drum as the boom is telescoped in and out. Any stacking of the cable will cause extension errors as the boom retracts.

1. Telescope the boom fully out and then fully in.
2. Ensure the reeling drum cable forms a flat single layer across the surface of the extension reel, with each successive turn of cable lying next to the last.

NOTE: If any stacking or build up of the cable occurs, ensure the first cable guide at the top of the boom root section is correctly aligned with the outside edge of the extension reel. Clean the reeling drum cable and lubricate it with a silicone spray.



6.3 Sensor Baseplate Assembly

The sensor baseplate assembly supports and connects the extension and angles sensors. It also supports the Two-Block switch signal and signal cable to the computer.


Electrical or mechanical failure of either the angle sensor or the extension sensor potentiometers cannot be repaired in the field. The angle sensor pendulum is factory set on the potentiometer shaft and the extension potentiometer gear contains a protection clutch which is difficult to replace in the field.

In the event of failure of either item, replace the entire sensor baseplate assembly.

The terminal block (TB1) mounted on the assembly provides wiring connection for all internal parts of the reeling drum and reel-to-computer cable. Most electrical diagnoses of the boom sensors can be made at this terminal block.

If problems occur with the two-block alarm operation, angle, or extension sensor, refer to the following chart. Follow the Boom Position/Action column before performing any voltage checks. Measure all voltages with a digital voltmeter set to DC volts range.

SIGNAL	BOOM POSITION/ ACTION	VOLTAGE		VOLTMETER CONNECTION	
		MIN	MAX	RED (+)	BLACK (-)
SENSOR DRIVE	-	+4.7V	+5.3V	TB1/4 - RED	TB1/1 - BLUE
ANGLE SENSOR OUTPUT	0 degrees	0.4V	0.6V	TB1/2 - GREEN	TB1/1 - BLUE
EXTENSION SENSOR OUTPUT	0 ft. FULL RETRACTED	0.15V	0.35V	TB1/3 - WHITE	TB1/1 - BLUE
TWO-BLOCK DRIVE	A2B WEIGHT DOWN	5.5V	7.5V	TB1/6 - BLACK	TB1/1 - BLUE
	A2B WEIGHT UP	9.5V	10.5V	TB1/6 - BLACK	TB1/1 - BLUE
TWO-BLOCK SIGNAL	A2B WEIGHT DOWN	5.5V	7.5V	TB1/5 - BROWN	TB1/1 BLUE
	A2B WEIGHT UP	0V	2V	TB1/5 - BROWN	TB1/1 - BLUE



6.4 Anti-Two-Block Function Overview

The computer supplies a protected positive feed to the Anti-Two-Block switches at the boom/jib head via the reel-to-computer cable, slip-ring, and reeling drum cable. With the Anti-Two-Block weight hanging freely on the switch, the switch contact is closed and the signal return to the computer is high. When the weight is lifted by the hook block, the switch contact is opened and the computer will sense a low signal input from the ATB signal return.

Since the computer checks the protected feed voltage internally, the system is capable of detecting a short circuit of the feed (or the ATB signal return when the switch is closed) to the crane chassis. Fault codes are defined in **FAULT REPORTING AND FAULT CODES**.

Most problems with the ATB circuit may be identified through inspection of cables, switches, and the reeling drum. Damage to these parts may result in continuous or intermittent ATB alarms.

6.5 Checking the Reeling Drum Cable


The outer braid of the cable carries the Anti-Two-Block feed to the switches. If the cable sheath is damaged, it may cause a short circuit to the boom/chassis and indicate the fault code above "B008." Refer to **GROUP "B" FAULT CODES**. The same fault code will be indicated if the ATB switch is closed and the inner core of the cable is shorted to the chassis at some point in the wiring.

1. Carefully inspect the reeling drum cable for wear.
2. Check for signs of damage to the outer sheath of the cable.
3. Check for any signs of severe "kinking" or crushing of the cable.

6.6 Checking the Anti-Two-Block Circuit

This procedure checks the ATB circuit when no power is applied to the circuit, use the diagram on the following page. Before continuing, ensure the connectors are correctly connected to the ATB switches at the boom head/jib.

1. Remove the reeling drum cover.
2. Disconnect the slip-ring arm from the plug by pulling it away from the center of the reel.
3. Close the ATB switch at the boom head by suspending the weight from it or pulling on the chain.
4. Measure the resistance on TB2, between A2 & B2 terminal connections on the sensor arm.
5. With the ATB switch closed, the resistance should be less than 300 ohms. If not, inspect the reeling drum cable, ATB switch, and the boom head connectors for an open circuit.
6. Open the ATB switch at the boom head by lifting the weight.
7. Measure the resistance on TB2, between A2 & B2 terminal connections on the sensor arm.
8. With the ATB switch open, the resistance should be greater than 10,000 ohms. If not, inspect the reeling drum cable, ATB switch, and the boom head connectors for a short circuit.




7.1 Swing Sensor Overview

The swing sensor measures the angle of the upper structure of the crane relative to its carrier. This angle is used to select capacity charts and operator swing alarms/working area alarms. If the swing sensor fails, the computer will be unable to select a valid capacity chart.

For fault diagnosis, access the swing sensor by removing the collector cover at the cranes swing center. Refer to the figure below.

For swing sensor replacement procedures, consult factory service.



7.2 Checking the Swing Sensor Drive Voltage

1. Remove the collector ring cover to expose the swing sensor.
2. With the system power turned on, measure the voltage between Terminal 1 of the swing sensor and crane ground. The voltage should be between 4.4 and 4.8 volts.
3. Measure the voltage between Terminal 3 of the swing sensor and crane ground. The voltage should be between 0.2 and 0.5 volts.

*NOTE: Voltages outside of those shown in steps 2 and 3 indicate a problem with the swing sensor or cabling connections. If voltages are incorrect, refer to **CHECKING THE SWING SENSOR RESISTANCE**.*

7.3 Checking the Swing Sensor Output Voltage

1. Remove the collector ring cover to expose the swing sensor.
2. With the system power turned on, measure the voltage between Terminal 2 of the swing sensor and crane ground. The voltage should be between 0.2 and 4.8 volts.
3. Measure the voltage between Terminal 4 of the swing sensor and crane ground. The voltage should be between 0.2 and 4.8 volts.

*NOTE: Voltages outside of those shown in Steps 2 and 3 indicate a problem with the swing sensor or cabling connections. If voltages are incorrect, refer to **CHECKING THE SWING SENSOR RESISTANCE**.*

7.4 Checking the Swing Sensor Resistance


1. Disconnect the connector (behind the collector ring).
2. Measure the resistance between pins C and D of the connector on the swing sensor side. The resistance should be between 2200 and 2800 ohms.
3. Measure the resistance between pins A and B of the connector on the swing sensor side. The resistance should be between 1800 and 2300 ohms.

NOTE: Resistances outside of those shown in steps 2 and 3 indicate a problem with the swing sensor or associated cable connections. If resistances are incorrect, replace the swing sensor and its cable.


8.1 Frame-Level Sensor (If Equipped)

The frame-level sensor measures the angle of the chassis relative to 0.0°. It is important to have the machine level before performing a lift.

If the frame-level sensor fails, the indicators on the screen will turn red and no measurement will be available.



Home Screen



Frame-Level Screen

If the displays go red, indicating a problem with the frame-level sensor:

1. Check the cabling and connections between the sensor and the harness.
2. Replace the sensor.

Consider Yourself Warned.™

11135 South James • Jenks, OK 74037

Phone: (918) 298-8300

Fax: (918) 298-8301

Greer Company is a part of TWG.



POWER to Move the World™

A **DOVER** COMPANY

www.team-twg.com

As a leader in product innovation, Greer Company is committed to the ongoing improvement of its equipment.
We reserve the right to make changes to our products without notice.

©2012 TWG. All rights reserved.