

WHT0103-101

SML-10

Maintenance Manual

HITACHI SUMITOMO



2006/7/10

Maintenance Table For LBCE Model

No.	Contents	No.	Contents	No.	Contents	No.	Contents
0	-----	26	Setting of rack sensor control data (Manual)	46	Setting of luffing protection device (Luffing set mode) data	# 60	A/D check
1	Setting of A/D channel	1.Engine idling speed	1.Working status	# 61	D/I check		
2	Setting of D/I polarity	2.Engine rated speed	2.Jib angle when the jib catch limit switch functions	# 62	Touch switch check		
3	Setting of load ratio	3.Ungleich end engine speed	3.Display of jib tension judgement value when raising the luffing boom	# 63	Counter check		
	1.Load ratio (forecast)	4.Ungleich start engine speed	4.Display of jib tension judgement value when lowering the luffing boom		1.Single phase counter		
	2.Load ratio (alarm)	5.Engine speed when reading full rack characteristic	5.Display of jib tension judgement value when raising the luffing jib		2.Two phase counter		
4	Setting of average cycles (Indication of load / angle)	(Maintenance No.16)		47	Setting of anti-two block limit data	# 64	LCD&LED check
5	Setting of delay coefficient (Indication of engine speed)	6.Engine speed 1 for calculating desired rack sensor output voltage	1.Deceleration start distance	65	D/I check		
6	Setting of coefficient (Actual load calculated by moment calculation)	7.Engine speed 2 for calculating desired rack sensor output voltage	2.Deceleration end distance	# 66	Voice alarm check		
7	Setting of voice alarm output	8.Rack sensor output voltage at full load and engine idling	48	Setting of pump control data	67	D/A check	
	1.Voice alarm output standard time	(Maintenance No.16)	1.Primary delay coefficient	68	Communication check (RS232C)		
	2.Voice alarm output interval time	9.Rack sensor output voltage at full load and engine full	2.Ultra low speed mode control type	69	Communication check (RS485)		
	3.Voice alarm release possible / impossible	(Maintenance No.16)	3.Control lever neutral check				
8	Setting of not use curve data	10.Desired rack sensor output voltage in engine low speed range	49	Setting of rigging mode data	70	Display of load history	
9	Setting of initial value	(Maintenance No.16)	1.Rigging mode judgement value	71	Display of error history		
	1.All initial	11.Desired rack sensor output voltage	2.Angle sensor signal wire breakage judgement value	# 72	Display of error code		
	2.Boom tension correction value initial (Maintenance No.11,21,31)	when engine speed detected is abnormal (Rack control[A])	3.Boom angle judgement value 1	73	Display of ROM data for load calculating		
	3.Boom angle correction value initial (Maintenance No.10,20,30)	(Maintenance No.16)		74	Display of data number		
	4.Jib tension correction value initial (Maintenance No.13,23,33)	12.Proportional gain constant	75	Display and rewrite of AJST data			
	5.Jib angle correction value initial (Maintenance No.12,22,32)	13.Integration constant	76	-----			
	6.Pump control data initial (Maintenance No.48,80,82,83)	14.Operating amount conversion coefficient	77	Setting of calendar			
	7.Winch motor control data initial (Maintenance No.84,85)	15.Loading upper judgement value	78	Setting of communication (RS232C)			
	9.Grip / Throttle volume control data initial (Maintenance No.14,24,34)	16.Rated point abnormal judgement value	79	Setting of communication (RS485)			
	10.Foot pedal throttle control data initial (Maintenance No.14,24,34)	17.Engine rated speed judgement speed					
	11.Throttle motor control data initial (Maintenance No.17,27,37,41)	18.Offset voltage for calculating the rack sensor target voltage	80	Setting of slowdown ratio voltage (Manual)			
	14.Rack sensor data initial (Maintenance No.16,26)	19.Offset voltage for calculating the rack sensor engine stall prevention judgement voltage	81	-----			
	15.Luffing protection device data initial (Maintenance No.46)	20.Offset pressure for calculating the max. power shift control pressure of rack sensor control	82	Setting of pump control adjustment value (Manual)			
	16.SRAM check data initial		83	Setting of pump control adjustment value (Actual machine)			
	17.Jib angle for rigging mode correction value initial (Maintenance No.29)	27	Throttle motor manual adjustment (Actual machine)	84	Setting of winch motor control adjustment value (Manual)		
	18.Rigging mode data initial (Maintenance No.49,58)	28	Setting of display selection of LMI override mode (load / load ratio)	85	Setting of winch motor control adjustment value (Actual machine)		
	20.Voice alarm release select data initial (Maintenance No.7)	29	Setting of jib angle for rigging mode correction value	86	-----		
	21.Voice alarm output interval data initial (Maintenance No.7)	1.Zero point correction value (Bench)	87	Display of drum speed			
	22.Self-weight correction value initial (Setting mode)	2.Zero point correction value (Manual)	88	Debug mode			
	23.Hour meter initial (Maintenance No.54)	3.Gain correction value (Manual)	89	Boom protection device non-function mode			
	24.LMI power ON time initial (Maintenance No.54)	4.Drift correction value (Manual)					
	25.ECU / ECM control data initial (Maintenance No.42)			90	-----		
	26.Radio load cell correction value initial (Maintenance No.35,36,43,44,45)			91	Display of tension		
10	Setting of boom angle zero point correction value (Bench)	30	Setting of boom angle correction value (Manual)	92	Display of angle		
11	Setting of boom tension zero point correction value (Bench)	31	Setting of boom tension correction value (Manual)	93	-----		
12	Setting of jib angle zero point correction value (Bench)	32	Setting of jib angle correction value (Manual)	94	-----		
13	Setting of jib tension zero point correction value (Bench)	33	Setting of jib tension correction value (Manual)	95	Setting of self-weight correction value (Manual)		
14	Adjustment of grip / throttle volume / foot pedal (Actual machine)	34	Setting of grip / throttle volume / foot pedal adjustment value (Manual)	96	Setting of tension drift correction value (Actual machine)		
15	-----	35	Setting of Luffing Test STEP	97	Setting of offset angle drift correction value (Manual)		
16	Adjustment of rack sensor (Actual machine)	36	Setting of radio load cell capacity & coefficient (Indication of actual load) for radio load cell	98	Setting of offset angle drift correction value (Actual machine)		
	1.Zero point correction value	37	Setting of throttle motor adjustment value (Manual)	# 99	Display of ROM informations		
	2.Full rack characteristic auto-reading	38	Setting of boom tension hysteresis correction value	1.Program Code / Version			
	1)Engine speed when reading full rack characteristic	39	Setting of jib tension hysteresis correction value	2.Data ROM Parts Number / Version			
	2)Rack sensor output voltage at full load and engine idling	40	Setting of pump / engine / winch motor control point	3.System Common Data (1) Number / Version			
	3)Rack sensor output voltage at full load and engine full	1.Pump control Min. / Max. point (At throttle variable)	4.System Common Data (2) Number / Version				
	4)Desired rack sensor output voltage in engine low speed range	2.Pump control Min. / Max. point (At throttle fixed)					
	5)Desired rack sensor output voltage when engine speed detected is abnormal (Rack control[A])	3.Engine control Min. / Max. point (At throttle variable)					
17	Throttle motor auto-adjustment (Actual machine)	4.Winch motor control Max. / Min. point (At throttle variable)					
18	Load history management data clear	5.Winch motor control Max. / Min. point (At throttle fixed)					
19	Error history management data clear	41	Setting of throttle motor control data				
		1.Throttle motor deadband engine speed					
		2.High idle cut engine speed					
20	Setting of boom angle gain correction value (Bench)	42	Setting of ECU / ECM control data				
21	Setting of boom tension gain correction value (Bench)	43	Setting of radio load cell - main[front] correction value (Manual)				
22	Setting of jib angle gain correction value (Bench)	44	Setting of radio load cell - aux[rear/3rd] correction value (Manual)				
23	Setting of jib tension gain correction value (Bench)	45	Setting of radio load cell hysteresis correction value (Manual)				
24	Setting of grip / throttle volume / foot pedal dead band ratio						
25	-----						

: There are same functions at "Setting mode - Adjustment - other".

Maintenance No.1 Setting of A/D channel

Function

In A/D input signals, the A/D channel enables to exchange of ch0 with ch1 and ch2 with ch3.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.= 1 with ##.

4) Press ENTER.

5) LCD1 01: ADch
Press &.

LCD2 Channel condition

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.

LCD2 Blinks

8) Press ## and select the channel condition.

The channel condition changes as follows.

→ 0123 ◀▶ . 0132 ◀▶ 1023 ◀▶ 1032 ◀▶

Channel condition	A/D channel			
	Boom tension	Jib tension	Boom angle	Jib angle
0123	ch0	ch1	ch2	ch3
0132	ch0	ch1	ch3	ch2
1023	ch1	ch0	ch2	ch3
1032	ch1	ch0	ch3	ch2

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

- 9) Press ENTER.
- 10) Return to the step 5).
- 11) Make sure that the indication on LCD2 shows the channel condition selected.
- 12) Press RETURN.
- 13) Return to the step 2).
- 14) Place the maintenance key switch in "OFF" position.

Initial value

0123

Setable value

0123 / 0132 / 1023 / 1032

Maintenance No.2 Setting of D/I polarity

Function

It can be corresponded at will for the difference of D/I input signals according to the difference contact polarity for the limit switches of boom upper limit, jib upper limit, and anti-two block limit.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.= 2 with ##.

4) Press ENTER.

5) LCD1 02: DI angle LS
& : next ## : other

LCD2 Polarity for the limit switches of boom upper limit, jib upper limit

LCD3 Polarity for the limit switch of anti-two block limit

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

02: DI angle LS Setting of the polarity for the limit switches of boom upper limit, jib upper limit



02: DI 2BLK LS Setting of the polarity for the limit switches of anti-two block limit

7) Press ENTER.



8) LCD1 Select content with ##, and press &. *

LCD2 Blinks (When "02: DI angle LS" selected)

LCD3 Blinks (When "02: DI 2BLK LS" selected)

9) Press ## and select the polarity for the limit switches.

0 : When the limit switch does not function 1 : When the limit switch does not function



<<Caution>>

The point above does not show the limit switch itself.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

The blinking on the corresponding LCD display goes out.

10) Press ENTER.

11) Return to the step 5).

12) Make sure that the indication on the corresponding LCD shows the polarity selected.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

0 : When the limit switch does not function → GND

Setable value

0 / 1

Maintenance No.3 Setting of load ratio

Function

This enables to change the load ratio (forecast / alarm / limit).

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.= 3 with ##.


4) Press ENTER.

5) LCD1 03: forecast
& : next ## : other

LCD2 Load ratio (forecast) [%]
LCD3 Load ratio (alarm) [%]
LCD4 Load ratio (limit) [%]
LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.



7) Press ENTER.

8) LCD1 Select content with ##, and press &. ****[%]

LCD2 Blinks (When "03: forecast" selected)
LCD3 Blinks (When "03: alarm" selected)
LCD4 Blinks (When "03: limit" selected)

9) Press ## and select the load ratio.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

The blinking on the corresponding LCD display goes out.

10) Press ENTER.

11) Return to the step 5).

12) Make sure that the indication on the corresponding LCD shows the load ratio selected.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

forecast : 90% alarm : 100% limit : 120%

Setable value

$70\% \leq \text{forecast} \leq 90\%$ $90\% \leq \text{alarm} \leq 110\%$ $120\% \leq \text{limit} \leq 1000\%$

Explanation

forecast : Yellow rotating lamp (D/O ch11) is output.

alarm : Overload limit (D/O ch00,15) and red rotating lamp (D/O ch10) are output.

limit : LCD1 (load ratio) → " - - - "

: LCD2 (rated load) and LCD3 (actual load) → Blank

Maintenance No.4 Setting of average cycles (Indication of load / angle)

Function

This enables to change the average cycles (Indication of load / angle).

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.= 4 with ##.

4) Press ENTER.

5) LCD1 04: average
 Press &.

LCD2 Average cycles (Indication of load / angle)

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.

LCD2 Blinks

8) Press ## and select the average cycles.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 shows the average cycles selected.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

3

Setable value

$1 \leq$ Average cycles ≤ 100

Maintenance No.5 Setting of delay coefficient (Indication of engine speed)

Function

This enables to change the delay coefficient (Indication of engine speed).

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.= 5 with ##.

4) Press ENTER.

5) LCD1 05: ENG delay
Press &.

LCD2 Delay coefficient (Indication of engine speed)

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2.)

6) Press ENTER.

7) LCD1 Select content with ##, and press &. ***

LCD2 Blinks

8) Press ## and select the delay coefficient.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5.)

The blinking on LCD2 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 shows the delay coefficient selected.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

1.000

Setable value

0.000 < delay coefficient ≤ 1.000

Explanation

Indication of engine speed = Engine speed calculated this time X Delay coefficient

+ Engine speed calculated last time X (1.000 - Delay coefficient)

The response of indication of engine speed is slow as delay coefficient is near to 0.000 and is fast as near to 1.000.

Maintenance No.6 Setting of coefficient (Actual load calculated by moment calculation)

Function

This enables to change the coefficient (Actual load calculated by moment calculation).

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.= 6 with ##.

4) Press ENTER.

5) LCD1 06: LOAD DISP
Press &.

LCD2 Coefficient (Actual load calculated by moment calculation)

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 ..*

LCD2 Blanks

8) Press ## and select the coefficient.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 shows the coefficient selected.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

1.050

Setable value

0.000 ≤ coefficient ≤ 9.999

Explanation

Actual load for line pull limit

= Lifting load (incloud hook weight) X Coefficient

Actual load for calculation of load ratio

= (Lifting load (incloud hook weight) + Inside hook weight) X Coefficient

Indication of actual load

= The average value [Maintenance No.4 Average cycles] of actual load for calculation of load ratio

Maintenance No.7 Setting of voice alarm output

Function

This enables to change the voice alarm output standard time, Tref (seconds).

This enables to change the voice alarm output interval time, Tintvl (seconds).

This enables to change the setting of the voice alarm release possible / impossible with LMI voice alarm switch.

Setting procedures ## : Δ▽ & : ↲

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.= 7 with ##.

4) Press ENTER.

5) LCD1 7: Tref
& : next ## : other

LCD2 The voice alarm output standard time

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

- | | |
|-----------------|--|
| ► 7: Tref | Setting of the voice alarm output standard time |
| ↑ | |
| 7: Tintvl | Setting of the voice alarm output interval time |
| ↓ | |
| ► 7: Release SW | Setting of the voice alarm release possible / impossible |

7) Press ENTER.

When selecting setting of the voice alarm output standard time → To 8-1)
When selecting setting of the voice alarm output interval time → To 8-2)
When selecting setting of the voice alarm release possible / impossible → To 8-3)

Setting of the voice alarm output standard time

8-1) LCD1 Select content with ##, and press &. **

LCD2 Blanks

9-1) Press ## and select standard time.

When stopping the setting, press RETURN before making the step 10-1). (Go to the step 5).)

The blinking on LCD2 display goes out.

10-1) Press ENTER.

11-1) Return to the step 5).

12-1) Make sure that the indication on LCD2 shows standard time selected.

13-1) Press RETURN.

14-1) Return to the step 2).

15-1) Place the maintenance key switch in "OFF" position.

Initial value

5 seconds

Setable value

0 second ≤ standard time ≤ 99 seconds

Maintenance No.7 Setting of voice alarm output

Setting of the voice alarm output interval time

8-2) LCD1
 1: Overload
 & : next ## : other

LCD2 The voice alarm output interval time

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 5.)

9-2) Press ## and select the setting item.

LCD1 display	Voice alarm	Initial value (seconds)
1: Overload	Overload Limit	0
2: forecast	Approaching Limit	0
3: Boom Upper	Boomhoist Limit	0
4: Jib Upper	Jibhoist Limit	0
5: Boom Lower	Boom Lower Limit	0
6: Jib Lower	Jib Lower Limit	0
7: 2BLK	Two-block Limit	0
8: Free mode	Free mode activated	0
9: Free fall	Freefall	0
10: Height limit	Height Limit Set	0
11: Radius limit	Radius Limit Set	0
12: LF protect	Luffing attachment protection activated	0
13: Boom protect	Boom protection activated	0
14: Pilot	Hydraulic control pressure reduced	0
15: Override	Override	0
16: Rigging mode	Rigging Mode	#

10-2) Press ENTER.

11-2) LCD1
 Select content with ##, and press &
 **

LCD2 Blinks

12-2) Press ## and select interval time.

When stopping the setting, press RETURN before making the step 13-2). (Go to the step 8-2).)

The blinking on LCD2 display goes out.

13-2) Press ENTER.

14-2) Return to the step 8-2).

15-2) Make sure that the indication on LCD2 shows interval time selected.

16-2) Press RETURN.

17-2) Return to the step 5).

18-2) Press RETURN.

19-2) Return to the step 2).

20-2) Place the maintenance key switch in "OFF" position.

Setable value

0 second ≤ interval time ≤ 99 seconds

Maintenance No.7 Setting of voice alarm output

Setting of the voice alarm release possible / impossible

8-3) LCD1
 1: Overload
 & : next ## : other

LCD2 The voice alarm release possible / impossible
 LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 5.)

9-3) Press ## and select the setting item.

LCD1 display	Voice alarm	Initial value	
1: Overload	Overload Limit	0 (Release possible)	※
2: forecast	Approaching Limit	0 (Release possible)	※
3: Boom Upper	Boomhoist Limit	0 (Release possible)	※
4: Jib Upper	Jibhoist Limit	0 (Release possible)	※
5: Boom Lower	Boom Lower Limit	0 (Release possible)	※
6: Jib Lower	Jib Lower Limit	0 (Release possible)	※
7: 2BLK	Two-block Limit	0 (Release possible)	※
8: Free mode	Free mode activated	1 (Release impossible)	
9: Free fall	Freefall	1 (Release impossible)	
10: Height limit	Height Limit Set	0 (Release possible)	
11: Radius limit	Radius Limit Set	0 (Release possible)	
12: LF protect	Luffing attachment protection activated	1 (Release impossible)	
13: Boom protect	Boom protection activated	0 (Release possible)	
14: Pilot	Hydraulic control pressure reduced	0 (Release possible)	
15: Override	Override	1 (Release impossible)	
16: Rigging mode	Rigging Mode	1 (Release impossible)	

10-3) Press ENTER.

11-3) LCD1
 Select content with ##, and press &.
 *

LCD2 Blinks

12-3) Press ## and select release possible / impossible.

When stopping the setting, press RETURN before making the step 13-3). (Go to the step 8-3).)

The blinking on LCD2 display goes out.

13-3) Press ENTER.

14-3) Return to the step 8-2).

15-3) Make sure that the indication on LCD2 shows release possible / impossible selected.

16-3) Press RETURN.

17-3) Return to the step 5).

18-3) Press RETURN.

19-3) Return to the step 2).

20-3) Place the maintenance key switch in "OFF" position.

<<Caution>>

- This setting is each setting value for crane / luffing etc according to the curve data selected when carrying out the maintenance.
 This enables the difference setting for crane / luffing etc.
 ex) crane : 0 (Release possible) / luffing : 1 (Release impossible)
- The voice alarm with the mark ※ can not be released, having no relation with this setting at "LMI override mode".

Setable value

0 (Release possible)

When placing override master key switch in "ENABLE" side and placing each override switch in "override", the voice alarm is sounded.

1 (Release impossible)

2 (Release possible)

Even if override master key switch placed in "ENABLE" side and each override switch in "override", the voice alarm is kept released. (Setting is possible only for 8 and 9.)

Maintenance No.8 Setting of not use curve data

Function

This is to set not to be selected the curve data which must not use according to the machine specification in the curve data memorized on ROM.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.= 8 with ##.

4) Press ENTER.

5) LCD1 08: Not use curve
Press &.

LCD2 Curve No.

LCD3 The memorized value

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)


6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 Curve No.**

LCD2 Blanks

8) Press ## and select Curve No..

Curve No. changes as follows.



When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

9) Press ENTER.

<<Caution>>

The curve No. with "E" displayed on LCD3 can not be selected as the curve data does not exist.

In this case, it does not need to set "0 (Not use)".

10) LCD1 Select content with ##, and press &.
 *

LCD2 Blinking goes out

LCD3 Blanks

11) Press ## and select "0 (Not use)" / "1 (Use)".

When stopping the setting, press RETURN before making the step 12). (Go to the step 7).)

The blinking on LCD3 display goes out.

12) Press ENTER.

13) Return to the step 7).

14) Make sure that the indication on LCD3 shows value selected.

15) Press RETURN when completing the setting.

16) Return to the step 5).

17) Press RETURN.

18) Return to the step 2).

19) Place the maintenance key switch in "OFF" position.

Initial value

1 (Use)

Setable value

0 (Not use) / 1 (Use)

Maintenance No.9 Setting of initial value

Function

This is to write the initial value for every adjusting data and controlling data in SRAM (Backup area).

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.= 9 with ##.

4) Press ENTER.

5) LCD1 1: All
 & : next ## : other

LCD2 to LCD3 ----

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select initializing item. (Refer to next page.)

7) Press ENTER.

8) LCD1 Set content with ##, and press &
 INIT(**) 0

LCD2 to LCD3 ----

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

9) Press ## and set 1919.

10) Press ENTER.

LCD2 to LCD3 ---- → HHHH → ----

11) Return to the step 5).

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Maintenance No.9 Setting of initial value

Initializing item

1 : All	INIT(01)	All initial It initializes all value (except hour meter and LMI power ON time).	
2 : Boom tension	INIT(02)	Boom tension correction value initial It initializes boom tension correction value (ZERO/GAIN/DRIFT).	(Maintenance No.11,21,31)
3 : Boom angle	INIT(03)	Boom angle correction value initial It initializes boom angle correction value (ZERO/GAIN/DRIFT).	(Maintenance No.10,20,30)
4 : Jib tension	INIT(04)	Jib tension correction value initial It initializes jib tension correction value (ZERO/GAIN/DRIFT).	(Maintenance No.13,23,33)
5 : Jib angle	INIT(05)	Jib angle correction value initial It initializes jib angle correction value (ZERO/GAIN/DRIFT).	(Maintenance No.12,22,32)
6 : Pump	INIT(06)	Pump control data initial It initializes pump control data.	(Maintenance No.48,80,82,83)
7 : Winch motor	INIT(07)	Winch motor control data initial It initializes winch motor control data.	(Maintenance No.84,85)
9 : Grip	INIT(08)	Grip / Throttle volume control data initial It initializes grip / throttle volumu control data.	(Maintenance No.14,24,34)
10 : Foot pedal	INIT(09)	Foot pedal throttle control data initial It initializes foot pedal throttle control data.	(Maintenance No.14,24,34)
11 : Throttle	INIT(10)	Throttle motor control data initial It initializes throttle motor control data.	(Maintenance No.17,27,37,41)
14 : Rack sensor	INIT(11)	Rack sensor data initial It initializes rack sensor data.	(Maintenance No.16,26)
15 : LF protect	INIT(12)	Luffing protection device data initial It initializes luffing protection device data.	(Maintenance No.46)
16 : SRAM check	INIT(13)	SRAM check data initial It initializes SRAM check data (judging SRAM abnormal [F-80]).	
17 : LF Jib	INIT(14)	Jib angle for rigging mode correction value initial It initializes jib angle for rigging mode correction value (ZERO/GAIN/DRIFT).	(Maintenance No.29)
18 : Rigging mode	INIT(15)	Rigging mode data initial It initializes rigging mode data.	(Maintenance No.49,58)
20 : Voice release	INIT(16)	Voice alarm release select data initial It initializes voice alarm release select data.	(Maintenance No.7)
21 : Voice spacing	INIT(17)	Voice alarm output interval data initial It initializes voice alarm output interval data.	(Maintenance No.7)
22 : Self weight	INIT(18)	Self-weight correction value initial It initializes all self-weight correction value.	(Setting mode)
23 : Hour meter	INIT(19)	Hour meter initial It initializes hour meter.	(Maintenance No.54)
24 : Power ON	INIT(20)	LMI power ON time initial It initializes LMI power ON time.	(Maintenance No.54)
25 : ECU	INIT(21)	ECU / ECM control data initial It initializes ECU / ECM control data.	(Maintenance No.42)
26 : Radio	INIT(22)	Radio load cell correction value initial It initializes radio load cell correction value.	(Maintenance No.35,36,43,44,45)

Maintenance No.10 Setting of boom angle zero point correction value (Bench)

Function

This is to memory A/D conversion value at 0V output of boom angle sensor as zero point correction value.

Preparation

It prepares so that 0V can be input to boom angle signal line.

Setting procedures ## : ΔV & : \leftarrow

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=10 with ##.

4) Press ENTER.

5) LCD1 10: B. Ang ZERO
Press &

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2).)

<<Caution>>

Drift correction value differs from the curve data to the curve data.

- "Crane" and "Auxiliary sheaves without jib" is same value.

- "Luffing" and "Auxiliary sheaves with jib" and "Midfall" is same value.

6) Press ENTER.

7) LCD1 Input 0[V] to signal line and press &

LCD2 Blanks

When stopping the setting, press RETURN before making the step 8). (Go to the step 5).)

The blinking on LCD2 display goes out.

8) Press ENTER.

9) Return to the step 5).

10) Make sure that the indication on LCD2 is same as LCD5.

11) Press RETURN.

12) Return to the step 2).

13) Place the maintenance key switch in "OFF" position.

Initial value

3167

Setable value

$2800 \leq$ Zero point correction value ≤ 3800

Maintenance No.11 Setting of boom tension zero point correction value (Bench)

Function

This is to memory A/D conversion value at 0V output of load cell for boom hoist rope tension detection as zero point correction value.

Preparation

- (1) It prepares so that 0V can be input to load cell signal line for boom hoist rope tension detection.
← When adjusting ZERO/GAIN with the calibrator.
- (2) It prepares so that the load cell for boom hoist rope tension detection is in no load with loosening the boom hoist wire rope.
← When adjusting with the load cell installed on the machine.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=11 with ##.

4) Press ENTER.

5) LCD1 11: B. Te ZERO
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Input 0[V] to signal line and press &.

LCD2 Blinks

When stopping the setting, press RETURN before making the step 8). (Go to the step 5).)

The blinking on LCD2 display goes out.

8) Press ENTER.

9) Return to the step 5).

10) Make sure that the indication on LCD2 is same as LCD5.

11) Press RETURN.

12) Return to the step 2).

13) Place the maintenance key switch in "OFF" position.

Initial value

500

Setable value

$0 \leq$ Zero point correction value ≤ 1000

Maintenance No.12 Setting of jib angle zero point correction value (Bench)

Function

This is to memory A/D conversion value at 0V output of jib angle sensor as zero point correction value.

Preparation

It prepares so that 0V can be input to jib angle signal line.

Setting procedures ## : ΔV & : \leftarrow

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=12 with ##.

4) Press ENTER.

5) LCD1 12: J. Ang ZERO
Press &

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2.).)

6) Press ENTER.

7) LCD1 Input 0[V] to signal line and press &

LCD2 Blinks

When stopping the setting, press RETURN before making the step 8). (Go to the step 5).)

The blinking on LCD2 display goes out.

8) Press ENTER.

9) Return to the step 5).

10) Make sure that the indication on LCD2 is same as LCD5.

11) Press RETURN.

12) Return to the step 2).

13) Place the maintenance key switch in "OFF" position.

Initial value

3167

Setable value

$2800 \leq$ Zero point correction value ≤ 3800

Maintenance No.13 Setting of jib tension zero point correction value (Bench)

Function

This is to memory A/D conversion value at 0V output of load cell for jib hoist rope tension detection as zero point correction value.

Preparation

- (1) It prepares so that 0V can be input to load cell signal line for jib hoist rope tension detection.
← When adjusting ZERO/GAIN with the calibrator.
- (2) It prepares so that the load cell for jib hoist rope tension detector is in no load with loosening the jib hoist wire rope.
← When adjusting with the load cell installed on the machine.

Setting procedures ## : Δ▽ & : ↴

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=13 with ##.

4) Press ENTER.

5) LCD1 13: J. Te ZERO
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Input 0[V] to signal line and press &.

LCD2 Blanks

When stopping the setting, press RETURN before making the step 8). (Go to the step 5).)

The blinking on LCD2 display goes out.

8) Press ENTER.

9) Return to the step 5).

10) Make sure that the indication on LCD2 is same as LCD5.

11) Press RETURN.

12) Return to the step 2).

13) Place the maintenance key switch in "OFF" position.

Initial value

500

Setable value

$0 \leq$ Zero point correction value ≤ 1000

Maintenance No.14 Adjustment of grip / throttle volume / foot pedal (Actual machine)

Function

- (1-1) This is to memory A/D conversion value of each output voltage in MIN and MAX position of the potentiometer built in the grip as adjusting value.
- (1-2) This is to memory A/D conversion value of each output voltage in MIN(at idle) and MAX(at full) position of the potentiometer for the throttle volume position detection as adjusting value.
- (2) This is to memory A/D conversion value of each output voltage in MIN(at idle) and MAX(at full) position of the potentiometer for the foot pedal position detection as adjusting value.

Confirmation items

- (1-1) Make sure that the potentiometer signal built in the grip is normally input to LMI.
- (1-2) Make sure that the potentiometer signal for the throttle volume position detection is normally input to LMI.
- (2) Make sure that the potentiometer signal for the foot pedal position detection is normally input to LMI.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=14 with ##.

4) Press ENTER.

5) LCD1 14: grip MIN
& : next ## : other

LCD2 MIN position adjustment value


LCD3 MAX position adjustment value

LCD4 Blank

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.



7) Press ENTER.

8) LCD1 14: @@@@ @@@@
& / RETURN

LCD2 Blinks (When "14: grip MIN" or "14: foot MIN" selected)

LCD3 Blinks (When "14: grip MAX" or "14: foot MAX" selected)

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on the corresponding LCD display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on the corresponding LCD is same as LCD5.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Maintenance No.14 Adjustment of grip / throttle volume / foot pedal (Actual machine)

				Initial value	Setable value
grip	Tier2	LS-308HII	Min	1440 [3.600V]	650 ≤ ≤ 2340 [1.625V] [5.850V]
		LS-308H5		2880 [7.200V]	1610 ≤ ≤ 4340 [4.025V] [10.850V]
	Tier3	LS-348H5	Max	2880 [7.200V]	1610 ≤ ≤ 4340 [4.025V] [10.850V]
		LS-348H5		3150 [7.875V]	1600 ≤ ≤ 4400 [4.000V] [11.000V]
throttle volume	Tier3	LS-238H5	Min	1650 [4.125V]	400 ≤ ≤ 3000 [1.000V] [7.500V]
		LS-248H5		3150 [7.875V]	1600 ≤ ≤ 4400 [4.000V] [11.000V]
		LS-108H5	Max	3752 [9.380V]	2400 ≤ ≤ 4400 [6.000V] [11.000V]
	Tier2	LS-348H5	Min	1600 [4.000V]	400 ≤ ≤ 2400 [1.000V] [6.000V]
				3200 [8.000V]	2000 ≤ ≤ 4400 [5.000V] [11.000V]
			Max	3200 [8.000V]	2000 ≤ ≤ 4400 [5.000V] [11.000V]
	Tier3	LS-238H5	Min	1600 [4.000V]	400 ≤ ≤ 2400 [1.000V] [6.000V]
		LS-248H5		3200 [8.000V]	2000 ≤ ≤ 4400 [5.000V] [11.000V]
		LS-108H5	Max	3200 [8.000V]	2000 ≤ ≤ 4400 [5.000V] [11.000V]

Maintenance No.16 Adjustment of rack sensor (Actual machine)

Function

1.Zero point correction value

This is to memory the rack sensor output voltage with the engine shutdown as rack sensor zero point correction value.

Usage

Zero point correction value is used to judge the status which the engine speed is 0 rpm though the engine runs.

Error condition of E-43 (Engine speed wire broken)

" Rack sensor output voltage < Zero point correction value - 0.05V " and " Engine speed = 0 rpm "

2.Full rack characteristic auto-reading

It reads the characteristic values of rack sensor automatically.

Confirmation items

1.Zero point correction value

- (1) Make sure that the rack sensor signal is normally input to LMI.
- (2) Make sure that the engine is shutdown (Engine speed = 0 rpm) and only the power is "ON".

2.Full rack characteristic auto-reading

- (1) Make sure that the rack sensor signal is normally input to LMI.
- (2) Make sure that the engine speed detection signal is normally input to LMI.
- (3) Make sure that the power shift control pressure varies normally by varying of the power shift control voltage.
- (4) Make sure that the engine speed normally changes according to outputting the engine throttle to the ECU.
- (5) Make sure that it is set so that the upper does not swing even if operating the swing control lever as the method to give a full load to the engine.
- (6) Make sure that it is set so that the machine does not travel even if operating the travel control lever as the method to give a full load to the engine.
- (7) Make sure that the travel control pressure switch signal is normally input to LMI.

Setting procedures # : △▽ & : ←→

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=16 with ##.

4) Press ENTER.

5) LCD1 16: Rack ZERO
& : next ## : other

LCD2 Zero point correction value [**,**V]

LCD3 to LCD4 Blank

LCD5 Rack sensor output voltage [**,**V]

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

→ 16: Rack ZERO Zero point correction value



→ 16: Rack AUTO Full rack characteristic auto-reading

7) Press ENTER.

When selecting zero point correction value → To 8-1)

When selecting full rack characteristic auto-reading → To 8-2)

Maintenance No.16 Adjustment of rack sensor (Actual machine)

[Zero point correction value]

- 8-1) LCD1 [Adjust zero point and press &.]

LCD2 Zero point correction value [**.**V] Blinks

LCD3 to LCD4 Blank

LCD5 Rack sensor output voltage [**.**V]

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on the corresponding LCD2 display goes out.

<<Caution>>

At abnormality, "HHHH" is displayed on LCD2 to LCD5.

- (1) Make sure that the rack sensor signal is normally input to LMI.
- (2) Make sure that the engine is shutdown (Engine speed = 0 rpm) and only the power is "ON".

[Reference]

"Rack sensor output voltage < 1.50V " or " Engine speed ≠ 0 rpm "

9-1) Press ENTER.

10-1) Return to the step 5).

11-1) Make sure that the indication on the LCD2 is same as LCD5.

When re-setting → To the step 6)

When finishing → To the step 12-1)

12-1) Press RETURN.

13-1) Return to the step 2).

14-1) Place the maintenance key switch in "OFF" position.

Initial value

LS-308HII, LS-308H5 : 3.85V [1925]

Setable value

1.50V [750] ≤ Zero point correction value ≤ 5.00V [2500]

Maintenance No.16 Adjustment of rack sensor (Actual machine)

Full rack characteristic auto-reading

- 8-2) Place the gate lock lever in "Operation" position.
 9-2) LCD1 Set lever in neutral and press & .

LCD2	Engine speed	[****rpm]
LCD3	Rack sensor output voltage	[**.**V]
LCD4	Blank	
LCD5	4-EE	

<<Caution>>

At abnormality, "HELP" is displayed on LCD2 or LCD3.

A. Confirm the followings when "HELP" is displayed on LCD2.

- (1) Make sure that the engine runs.
- (2) Make sure that the engine speed detection signal is normally input to LMI when "HELP" is displayed through the engine runs.

Reference

Displaying condition of "HELP" on LCD2.

" Engine speed \leq 20 rpm " or " Engine speed \geq 2500 rpm "

B. Confirm the followings when "HELP" is displayed on LCD3.

- (1) Make sure that the rack sensor signal is normally input to LMI.

Reference

Displaying condition of "HELP" on LCD3.

In the machine with rack sensor,

" Rack sensor output voltage \leq 0.25V " or " Rack sensor output voltage \geq 5.00V "

10-2) Place the travel control lever in "Neutral" position.

11-2) Press ENTER and start the auto-reading.

12-2) LCD1 Calculating now.

LCD2	Engine speed	[****rpm]
LCD3	Rack sensor output voltage	[**.**V]
LCD4	Power shift control pressure	[**.**kgf/cm ²]
LCD5	4	

When stopping the adjustment after pressing ENTER at step 11-2), operate the followings.

This operation is effective for the step before placing the travel control lever in "Forward" or "Backward" position at step 15-2).

- (1) Press RETURN.
- (2) Place the travel control lever in "Forward" or "Backward" position.

<<Caution>>

Confirm the followings if "4" is not indicated with being left "4-EE" on LCD5 indicating even if ENTER is pressed with placing the travel control lever in "Neutral" position.

- (1) Make sure that the ENTER is normally recognized.
- (2) Make sure that the travel control pressure switch signal is normally input to LMI.

13-2) Automatically, the engine speed rises to full and the P1&P2 pump displacement becomes maximum.

<<Caution>>

At abnormality, "5-EE" is displayed on LCD5.

- (1) Make sure that the engine speed normally changes according to outputting the engine throttle to the ECU.

Reference

Displaying condition of "5-EE" on LCD5.

" Engine speed \leq Engine rated speed + 50 rpm "

LS-308HII, LS-308H5	
Engine rated speed	1950 rpm

Maintenance No.16 Adjustment of rack sensor (Actual machine)

14-2) LCD1 Calculating now.

LCD2	Engine speed	[****rpm]
LCD3	Rack sensor output voltage	[**.*V]
LCD4	Power shift control pressure	[**.*kgf/cm ²] = 40.0kgf/cm ²
LCD5	5	

15-2) After "5" is displayed on LCD5, slowly operate the swing control lever and place the travel control lever "Forward" or "Backward" position.

<<Caution>>

- (1) As the load amount is short with only the travel control lever operation ("Forward" or "Backward"), "6-EE" may be displayed on LCD5.
- (2) If operating the lever suddenly, the load will increase suddenly and the engine speed decreases suddenly. Therefore, "5-EE" or "6-EE" may be displayed on LCD5.

16-2) LCD1 Calculating now.

LCD2	Engine speed	[****rpm]
LCD3	Rack sensor output voltage	[**.*V]
LCD4	Power shift control pressure	[**.*kgf/cm ²] = 40.0kgf/cm ² → Decrease
LCD5	6	

17-2) The followings are gained by status of " Engine speed (LCD2) ", " Rack sensor output voltage (LCD3) ", and " Power shift control pressure (LCD4) ".

1. Engine speed \geq Engine rated speed + Engine rated speed judgement speed < 1950 rpm >

- A. Power shift control pressure < Max. power shift control pressure < 0.0kgf/cm² >
 - a. Rack sensor output voltage > Loading upper judgement value → To the step 24-2) < 2.39V > [Abnormal end]
 - b. Rack sensor output voltage \leq Loading upper judgement value → To the step 18-2) < 2.39V > [Normal end No.1]
- B. Power shift control pressure \geq Max. power shift control pressure < 0.0kgf/cm² >
 → To the step 16-2) [Continuation of calculating]

2. Engine speed < Engine rated speed + Engine rated speed judgement speed < 1950 rpm >

- A. Rack sensor output voltage > Rated point abnormal judgement value < 1.88V >
 → To the step 24-2) [Abnormal end]
- B. Rack sensor output voltage \leq Rated point abnormal judgement value < 1.88V >
 → To the step 18-2) [Normal end No.2]

LS-308HII, LS-308H5	
Engine rated speed	1950 rpm
Engine rated speed judgement speed	0 rpm
Max. power shift control pressure	0.0kgf/cm ²
Loading upper judgement value	2.39V [1195]
Rated point abnormal judgement value	1.88V [940]

Maintenance No.16 Adjustment of rack sensor (Actual machine)

[Normal end]

18-2) LCD1 Adjustment finished. Set lever in neutral.

LCD2	Engine speed when reading full rack characteristic	[****rpm]
LCD3	Rack sensor output voltage at full load and engine full	[**.**V]
LCD4	Max. power shift control pressure	[**.**kgf/cm ²]
LCD5	7	

<<Caution>>

In the case of [Normal end No.1]

The characteristic values of rack sensor are not rewritten.
These are values before being adjusted.

In the case of [Normal end No.2]

The following characteristic values of rack sensor are rewritten.

(Refer to "Maintenance No.26 Setting of rack sensor control data (Manual)".

1. Engine speed when reading full rack characteristic ← LCD2
2. Rack sensor output voltage at full load and engine idling
3. Rack sensor output voltage at full load and engine full ← LCD3
4. Desired rack sensor output voltage in engine low speed range
5. Desired rack sensor output voltage when engine speed detected is abnormal (Rack control[A])

19-2) Place the travel control lever and the swing control lever in "Neutral" position.

20-2) Return to the step 5).

21-2) Press RETURN.

22-2) Return to the step 2).

23-2) Place the maintenance key switch in "OFF" position.

[Abnormal end]

24-2) LCD1 Adjustment failed. Press RETURN.

LCD2	Engine speed	[****rpm]
LCD3	Rack sensor output voltage	[**.**V]
LCD4	Power shift control pressure	[**.**kgf/cm ²]
LCD5	6-EE	

25-2) Place the travel control lever and the swing control lever in "Neutral" position.

26-2) Press RETURN.

27-2) Confirm the followings, and readjust.

<<Caution>>

Confirm the followings when "6-EE" is displayed on LCD5.

- (1) Make sure that the gate lock lever is placed in "Operation" position.
- (2) Make sure that the swing control lever is operated and the travel control lever is placed in "Forward" or "Backward" slowly. (Refer to the step 15-2).)
- (3) Make sure that "Maintenance No.52 Setting of Pz-DA curve - Adjustment of power shift control voltage (Actual machine)" is correctly set.
- (4) Make sure that the power shift control pressure varies normally by varying of the power shift control voltage.

Initial value

LS-308HII, LS-308H5

Engine speed when reading full rack characteristic	2000 rpm
Rack sensor output voltage at full load and engine idling	1.86V [930]
Rack sensor output voltage at full load and engine full	1.71V [855]
Desired rack sensor output voltage in engine low speed range	2.33V [1165]
Desired rack sensor output voltage when engine speed detected is abnormal (Rack control[A])	2.33V [1165]

Setable value

No limitation

Maintenance No.17 Throttle motor auto-adjustment (Actual machine)

Function

This is to memory A/D conversion value of each output voltage in the throttle motor position which the engine speed is in idle and full as adjusting value.

Confirmation items

- (1) Make sure that the throttle motor link mechanism is correctly adjusted.
- (2) Make sure that the throttle motor is normally controlled by the throttle motor control signal (UP/DOWN).
- (3) Make sure that the throttle motor position signal is normally input to LMI.
- (4) Make sure that the engine speed detection signal is normally input to LMI.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=17 with ##.

4) Press ENTER.

5) LCD1 17: Throttle AUTO
& : start

LCD2 Idle position adjustment value

LCD3 Full position adjustment value

LCD4 Engine speed [****rpm]

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2).)

The throttle motor is in stop status. (It is impossible to operate the throttle motor with operating the grip.)

6) Press ENTER and start the auto-adjustment.

When the auto adjustment does not start, refer to [Signal abnormal].

When stopping the adjustment, press RETURN.

7) LCD1 Calculating now.

LCD2 HHHH

LCD3 HHHH

LCD4 Engine speed [****rpm]

LCD5 A/D conversion value

8) The throttle motor goes "UP" automatically and the engine speed rises every 3 seconds.

Throttle UP condition

" Engine speed this time > Engine speed last time " or " Engine speed this time < 1800 rpm "

9) The throttle motor goes "DOWN" automatically and the engine speed lowers every 3 seconds.

Throttle DOWN condition

" Engine speed this time < Engine speed last time " or " Engine speed this time > 1000 rpm "

10) The indication on LCD5 returns to the step 5).

Make sure that " Idle position adjustment value (LCD2) " and " Full position adjustment value (LCD3) " varied.

[Normal end]

When the adjustment is not finished normally,
refer to [Abnormal end No.1], [Abnormal end No.2] and [Abnormal end No.3].

11) Press RETURN.

12) Return to the step 2).

13) Place the maintenance key switch in "OFF" position.


Maintenance No.17 Throttle motor auto-adjustment (Actual machine)

[Signal abnormal]

- Throttle motor position signal abnormal / Engine speed detection signal abnormal
- | | |
|--------------------|---|
| Display | LCD2 HELP |
| | LCD3 HELP |
| Condition | (1) "H-16 (Throttle motor position signal abnormal)" occurs.
(2) "H-42 (Engine speed abnormal)" occurs. |
| Confirmation items | (1) Make sure that the throttle motor position signal is normally input to LMI.
(2) Make sure that the engine speed detection signal is normally input to LMI. |

[Abnormal end No.1]

Full position setting range is over.




Condition

- (1) When "Full position memory value" is out of setting range.

- Confirmation items
- (1) Make sure that the throttle motor link mechanism is correctly adjusted.
 - (2) Make sure that the throttle motor is normally controlled by the throttle motor control signal (UP/DOWN).
 - (3) Make sure that the throttle motor position signal is normally input to LMI.
 - (4) Make sure that the engine speed detection signal is normally input to LMI.

[Abnormal end No.2]

Idle position setting range is over.




Condition

- (1) When "Idle position memory value" is out of setting range.

- Confirmation items
- (1) Make sure that the throttle motor link mechanism is correctly adjusted.
 - (2) Make sure that the throttle motor is normally controlled by the throttle motor control signal (UP/DOWN).
 - (3) Make sure that the throttle motor position signal is normally input to LMI.
 - (4) Make sure that the engine speed detection signal is normally input to LMI.

[Abnormal end No.3]

Idle and full position setting range is over.



Condition

- (1) When both "Full position memory value" and "Idle position memory value" are out of setting range.

- Confirmation items
- (1) Make sure that the throttle motor link mechanism is correctly adjusted.
 - (2) Make sure that the throttle motor is normally controlled by the throttle motor control signal (UP/DOWN).
 - (3) Make sure that the throttle motor position signal is normally input to LMI.
 - (4) Make sure that the engine speed detection signal is normally input to LMI.

Initial value

Idle position adjustment value : 599 [1.499V]

Full position adjustment value : 4110 [10.275V]

Setable value

$115 \text{ [0.288V]} \leq \text{Idle position adjustment value} \leq 1083 \text{ [2.708V]}$

$3626 \text{ [9.065V]} \leq \text{Full position adjustment value} \leq 4594 \text{ [11.485V]}$

Maintenance No.18 Load history management data clear

Function

This clears all load history management data.

Setting procedures ## : Δ▽ & : ←→

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=18 with ##.

4) Press ENTER.

5) LCD1 Set content with ##, and press &.
 18: Load 0

LCD2 to LCD3 ----

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and set 9191.

7) Press ENTER.

LCD2 to LCD3 ---- → HHHH → ----

8) Return to the step 5).

9) Press RETURN.

10) Return to the step 2).

11) Place the maintenance key switch in "OFF" position.

Maintenance No.19 Error history management data clear

Function

This clears all err history management data.

Setting procedures ## : Δ▽ & : ↲

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=19 with ##.

4) Press ENTER.

5) LCD1 Set content with ##, and press &. 19: Error 0

LCD2 to LCD3 -----

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and set 7777.

7) Press ENTER.

LCD2 to LCD3 ----- → HHHH → -----

8) Return to the step 5).

9) Press RETURN.

10) Return to the step 2).

11) Place the maintenance key switch in "OFF" position.

Maintenance No.20 Setting of boom angle gain correction value (Bench)

Function

This memorizes the boom angle gain correction value calculated by using the input voltage and the input angle.

Preparation

It prepares so that 1.8V or optional voltage can be input to boom angle signal line.

Setting procedures ## : ΔV & : \leftarrow

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1
Select content with ##, and press &.
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=20 with ##.

4) Press ENTER.

5) LCD1 20: B. Ang GAIN
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2).)

<<Caution>>

Drift correction value differs from the curve data to the curve data.

- "Crane" and "Auxiliary sheaves without jib" is same value.

- "Luffing" and "Auxiliary sheaves with jib" and "Midfall" is same value.

6) Press ENTER.

7) LCD1 Set content with ##, and press &.
90.0°

LCD3 Blinks

8) Press ## and set the angle that corresponds to the input voltage.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD3 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD3 is approx. 1.250.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

1.250

Setable value

$0.500 \leq$ Gain correction value ≤ 3.000

Maintenance No.21 Setting of boom tension gain correction value (Bench)

Function

This memorizes the boom tension gain correction value calculated by using the input voltage and the input tension.

Preparation

Connect the calibrator to the boom tension signal line, or enable to input 18mV.

Setting procedures ## : $\Delta\nabla$ & : \leftarrow

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=21 with ##.

4) Press ENTER.

5) Connect the calibrator to the boom tension signal line and set at 1.5mV/V, or input 18mV.

6) LCD1 21: B. Te GAIN
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2).)

7) Press ENTER.

8) LCD1 Set content with ##, and press &. **.*ton

LCD3 Blanks

9) Press ## and set the tension that corresponds to the input voltage.

Tension that corresponds to the input voltage = Load cell capacity X 1.5

Load cell capacity	Tension that corresponds to the input voltage
3 ton	4.50 ton
6 ton	9.00 ton
9 ton	13.50 ton
20 ton	30.00 ton

When stopping the setting, press RETURN before making the step 10). (Go to the step 6).

The blinking on LCD3 display goes out.

10) Press ENTER.

11) Return to the step 6).

12) Make sure that the indication on LCD3 is approx. 1.875.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

1.875

Setable value

$0.500 \leq$ Gain correction value ≤ 3.000

Maintenance No.22 Setting of jib angle gain correction value (Bench)

Function

This memorizes the jib angle gain correction value calculated by using the input voltage and the input angle.

Preparation

It prepares so that 1.8V or optional voltage can be input to jib angle signal line.

Setting procedures ## : ΔV & : \leftarrow

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=22 with ##.

4) Press ENTER.

5) LCD1 22: J. Ang GAIN
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Set content with ##, and press &. 90.0°

LCD3 Blanks

8) Press ## and set the angle that corresponds to the input voltage.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD3 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD3 is approx. 1.250.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

1.250

Setable value

$0.500 \leq$ Gain correction value ≤ 3.000

Maintenance No.23 Setting of jib tension gain correction value (Bench)

Function

This memorizes the jib tension gain correction value calculated by using the input voltage and the input tension.

Preparation

Connect the calibrator to the jib tension signal line, or enable to input 18mV.

Setting procedures ## : ΔV & : \leftarrow

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=23 with ##.

4) Press ENTER.

5) Connect the calibrator to the jib tension signal line and set at 1.5mV/V, or input 18mV.

6) LCD1 23: J. Te GAIN
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2).)

7) Press ENTER.

8) LCD1 Set content with ##, and press &. **.*ton

LCD3 Blanks

9) Press ## and set the tension that corresponds to the input voltage.

Tension that corresponds to the input voltage = Load cell capacity X 1.5

Load cell capacity	Tension that corresponds to the input voltage
3 ton	4.50 ton
6 ton	9.00 ton
9 ton	13.50 ton
20 ton	30.00 ton

When stopping the setting, press RETURN before making the step 10). (Go to the step 6).

The blinking on LCD3 display goes out.

10) Press ENTER.

11) Return to the step 6).

12) Make sure that the indication on LCD3 is approx. 1.875.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

1.875

Setable value

$0.500 \leq$ Gain correction value ≤ 3.000

Maintenance No.24 Setting of grip / throttle volume / foot pedal dead band ratio

Function

- (1-1) This is to set the dead band ratio at both ends of the grip movable range.
- (1-2) This is to set the dead band ratio at both ends of the throttle volume movable range.
- (2) This is to set the dead band ratio at both ends of the foot pedal movable range.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=24 with ##.

4) Press ENTER.

5) LCD1 24: grip deadband
& : next ## : other

LCD2 Grip / Throttle volume dead band ratio [%]

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

24: grip deadband Setting of grip / throttle volume dead band ratio



24: foot deadband Setting of foot pedal dead band ratio

7) Press ENTER.

8) LCD1 Select content with ##, and press &.
 **[%]

LCD2 Blanks

9) Press ## and select the dead band ratio.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

The blinking on LCD2 display goes out.

10) Press ENTER.

11) Return to the step 5).

12) Make sure that the indication on LCD2 shows the dead band ratio selected.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

grip / throttle volume / foot pedal : 5%

Setable value

grip / throttle volume / foot pedal : 0% ≤ dead band ratio ≤ 30%

Maintenance No.26 Setting of rack sensor control data (Manual)

Function

This is to set the rack sensor control data (power shift control).

Setting procedures ## : Δ▽ & : ↲

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=26 with ##.

4) Press ENTER.

5) LCD1 26: Rack data **
& : next ## : other

LCD2 to LCD5 Refer to next page.

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item. (Refer to next page.)

7) Press ENTER.

8) LCD1 Select content with ##, and press &.

The indication on the corresponding LCD blinks.

9) Press ## and select the value.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

The blinking on the corresponding LCD display goes out.

10) Press ENTER.

11) Return to the step 5).

12) Make sure that the indication on the corresponding LCD shows a value selected.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Maintenance No.26 Setting of rack sensor control data (Manual)**Setting item**

LCD1	LCD2	LCD3	LCD4	LCD5	Setting item	Initial value LS-308HII, LS-308H5
26:Rack data 1	**** rpm	**** rpm	Blank	Blank	1. Engine idling speed	750 rpm
26:Rack data 2					2. Engine rated speed	1950 rpm
26:Rack data 3	**** rpm	**** rpm	**** rpm	Blank	3. Ungleich end engine speed	1000 rpm
26:Rack data 4					4. Ungleich start engine speed	1200 rpm
26:Rack data 5					5. <u>Engine speed when reading full rack characteristic</u>	<u>2000 rpm</u>
26:Rack data 6	**** rpm	**** rpm	Blank	Blank	6. Engine speed 1 for calculating desired rack sensor output voltage	1400 rpm
26:Rack data 7					7. Engine speed 2 for calculating desired rack sensor output voltage	850 rpm
26:Rack data 8	**,** V	**,** V	Blank	Blank	8. <u>Rack sensor output voltage at full load and engine idling</u>	<u>1.86 V [930]</u>
26:Rack data 9					9. <u>Rack sensor output voltage at full load and engine full</u>	<u>1.71 V [855]</u>
26:Rack data 10	**,** V	**,** V	Blank	Blank	10. <u>Desired rack sensor output voltage in engine low speed range</u>	<u>2.33 V [1165]</u>
26:Rack data 11					11. <u>Desired rack sensor output voltage when engine speed detected is abnormal (Rack control[A])</u>	<u>2.33 V [1165]</u>
26:Rack data 12	**.**	**.**	Blank	Blank	12. Proportional gain constant	0.100
26:Rack data 13					13. Integration constant	0.100
26:Rack data 14	**** V	**,** V	**,** V	Blank	14. Operating amount conversion coefficient	92
26:Rack data 15					15. Loading upper judgement value	2.39 V [1195]
26:Rack data 16					16. Rated point abnormal judgement value	1.88 V [940]
26:Rack data 17	**** rpm	**,** V	**,** V	Blank	17. Engine rated speed judgement speed	0 rpm
26:Rack data 18					18. Offset voltage for calculating the rack sensor target voltage	0.08 V [40]
26:Rack data 19					19. Offset voltage for calculating the rack sensor engine stall prevention judgement voltage	1.00 V [500]
26:Rack data 20	**** kgf/cm ²	Blank	Blank	Blank	20. Offset pressure for calculating the max. power shift control pressure of rack sensor control	3.0 kgf/cm ² [303]

Data with under line : These data are adjusted with "Maintenance No.16 - Adjustment of rack sensor (Actual machine)
- Full rack characteristic auto-reading".

Setable value No limitation

Maintenance No.27 Throttle motor manual adjustment (Actual machine)

Function

This is to memory A/D conversion value of each output voltage in the throttle motor position which the engine speed is in idle and full as adjusting value.

Confirmation items

- (1) Make sure that the throttle motor link mechanism is correctly adjusted.
- (2) Make sure that the throttle motor is normally controlled by the throttle motor control signal (UP/DOWN).
- (3) Make sure that the throttle motor position signal is normally input to LMI.
- (4) Make sure that the engine speed detection signal is normally input to LMI.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=27 with ##.

4) Press ENTER.

5) LCD1 27: Throttle MIN
& : next ## : other

LCD2 Idle position adjustment value

LCD3 Full position adjustment value

LCD4 Engine speed [****rpm]

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2.)

The throttle motor is in stop status. (It is impossible to operate the throttle motor with operating the grip.)

6) Press ## and select the setting item.

27: Throttle MIN Adjustment of throttle motor Idle position



27: Throttle MAX Adjustment of throttle motor full position

7) Press ENTER.

8) LCD1 Select throttle position with ##, and press &.

LCD2 Blinks (When "27: Throttle MIN" selected)

LCD3 Blinks (When "27: Throttle MAX" selected)

9) Press ## and set the throttle motor position. (Δ: Throttle Up / ▽: Throttle Down)

When stopping the setting, press RETURN before making the step 10). (Go to the step 5.)

The blinking on the corresponding LCD display goes out.

10) Press ENTER.

11) Return to the step 5).

12) Make sure that the indication on the corresponding LCD is same as LCD5.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

Idle position adjustment value : 599 [1.499V]

Full position adjustment value : 4110 [10.275V]

Setable value

115 [0.288V] ≤ Idle position adjustment value ≤ 1083 [2.708V]

3626 [9.065V] ≤ Full position adjustment value ≤ 4594 [11.485V]

Maintenance No.28 Setting of display selection of LMI override mode (load / load ratio)

Function

This enables to set of display selection of LMI override mode (load / load ratio).

Setting procedures ## : Δ▽ & : ←→

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=28 with ##.

4) Press ENTER.

5) LCD1 28: Override
Press &.

LCD2 The memorized value

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &. *

LCD2 Blanks

8) Press ## and select "0 (No display)" / "1 (Display)".

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 shows value selected.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

1 (Display)

Setable value

0 (No display) / 1 (Display)

Explanation

LMI Override Mode

Load Ratio ≥ Load Ratio (limit) [Maintenance No.3 Setting of load ratio]

		0 (No display)	1 (Display)
LCD1	Load ratio	---	*** [%]
LCD2	Rated load	Blank	***.* [kips]
LCD3	Actual load	Blank	***.* [kips]

Maintenance No.29 Setting of jib angle for rigging mode correction value

Function

This is to memory the input signal of jib angle for rigging mode with holding jib horizontal as jib angle for rigging mode zero point correction value.

This enables to change jib angle for rigging mode zero point correction value.

This enables to change jib angle for rigging mode gain point correction value.

This enables to change jib angle for rigging mode drift point correction value.

Preparation

Hold the jib horizontal.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=29 with ##.

4) Press ENTER.

5) LCD1 29: ZERO bench
& : next ## : other

LCD2 Zero point correction value

LCD3 Jib angle for rigging mode [***.* °]

LCD4 Jib angle [***.* °]

LCD5 A/D conversion value

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

→ 29: ZERO bench Zero point correction value (Bench)



29: ZERO manual Zero point correction value (Manual)



29: GAIN manual Gain correction value (Manual)



→ 29: DRIFT manual Drift correction value (Manual)

7) Press ENTER.

When selecting "Zero point correction value (Bench)". → To 8-1)


When selecting others. → To 8-2)

Maintenance No.29 Setting of jib angle for rigging mode correction value

Zero point correction value (Bench)

8-1) LCD1 Hold jib horizontal.
Press &.

LCD2	Zero point correction value	[***.*]
LCD3	Jib angle for rigging mode	[***.* °]
LCD4	Jib angle	[***.* °]
LCD5	A/D conversion value	



When stopping the setting, press RETURN before making the step 9-1). (Go to the step 2).)

<<Caution>>

When selecting the curve data except "Luffing" and "Auxiliary sheaves with jib" and "Midfall", the indicated content on LCD1 changes to the following.

Select luffing
curve.

After executing the step 13-1) to 15-1), select the curve data of "Luffing" or "Auxiliary sheaves with jib" or "Midfall" with setting mode and set the attachment make-up.

9-1) Hold the jib horizontal.

When stopping the setting, press RETURN before making the step 10-1). (Go to the step 5).)

10-1) Press ENTER.

11-1) Make sure that the indication on LCD2 is same as LCD5, and the indication on LCD3 is "0.0".

12-1) Return to the step 5).

13-1) Press RETURN.

14-1) Return to the step 2).

15-1) Place the maintenance key switch in "OFF" position.

Zero point / Gain / Drift correction value (Manual)

8-2) LCD1 Set content with ##, and press &.

LCD2	Zero point correction value	Blinks (When "29: ZERO manual" selected)
LCD3	Gain correction value	Blinks (When "29: GAIN manual" selected)
LCD4	Drift correction value	Blinks (When "29: DRIFT manual" selected)
LCD5	Blank	

When stopping the setting, press RETURN before making the step 9-2). (Go to the step 5).)

9-2) Press ## and set value.

When stopping the setting, press RETURN before making the step 10-2). (Go to the step 5).)

10-2) Press ENTER.

11-2) Make sure that the indication on the corresponding LCD shows value set.

12-2) Return to the step 5).

13-2) Press RETURN.

14-2) Return to the step 2).

15-2) Place the maintenance key switch in "OFF" position.

Initial value

Zero point correction value : 680 [1.700V]

Gain correction value : 8.333

Drift correction value : 0.00

Setable value

$0 \leq$ Zero point correction value ≤ 1000

$0.100 \leq$ Gain correction value ≤ 9.999

$-10.00 <$ Drift correction value ≤ 10.00

Maintenance No.30 Setting of boom angle correction value (Manual)

Function

This enables to change the boom angle correction value (ZERO / GAIN / DRIFT).

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=30 with ##.

4) Press ENTER.

5) LCD1 30: B. Ang manual
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 Blank

(When RETURN is pressed, go to the step 2).)

<<Caution>>

Drift point correction value differs from the curve data to the curve data.

- "Crane" and "Auxiliary sheaves without jib" is same value.

- "Luffing" and "Auxiliary sheaves with jib" and "Midfall" is same value.

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 ZERO GAIN DRIFT

8) Press ## and select the setting item.

9) Press ENTER.

When selecting setting of zero point correction value "ZERO"

→ To 10-1)

When selecting setting of gain correction value "GAIN"

→ To 10-2)

When selecting setting of drift correction value "DRIFT"

→ To 10-3)

Setting of zero point correction value

10-1) LCD1 Set content with ##, and press &.

LCD2 Blanks

11-1) Press ## and set the zero point correction value.

When stopping the setting, press RETURN before making the step 11-1). (Go to the step 5).)

The blinking on LCD2 display goes out.

12-1) Press ENTER.

13-1) Return to the step 5).

14-1) Make sure that the indication on LCD2 shows the zero point correction value set.

15-1) Press RETURN.

16-1) Return to the step 2).

17-1) Place the maintenance key switch in "OFF" position.

Maintenance No.30 Setting of boom angle correction value (Manual)

Setting of gain correction value

10-2) LCD1 Set content with ##, and press &
*.***

LCD3 Blinks

11-2) Press ## and set the gain correction value.

When stopping the setting, press RETURN before making the step 11-2). (Go to the step 5).)

The blinking on LCD3 display goes out.

12-2) Press ENTER.

13-2) Return to the step 5).

14-2) Make sure that the indication on LCD3 shows the gain correction value set.

15-2) Press RETURN.

16-2) Return to the step 2).

17-2) Place the maintenance key switch in "OFF" position.

Setting of drift correction value

10-3) LCD1 Set content with ##, and press &
.

LCD4 Blinks

11-3) Press ## and set the drift correction value.

When stopping the setting, press RETURN before making the step 11-3). (Go to the step 5).)

The blinking on LCD4 display goes out.

<<Caution>>

Drift point correction value differs from the curve data to the curve data.

- "Crane" and "Auxiliary sheaves without jib" is same value.

- "Luffing" and "Auxiliary sheaves with jib" and "Midfall" is same value.

12-3) Press ENTER.

13-3) Return to the step 5).

14-3) Make sure that the indication on LCD4 shows the drift correction value set.

15-3) Press RETURN.

16-3) Return to the step 2).

17-3) Place the maintenance key switch in "OFF" position.

Initial value

Zero point correction value : 3167

Gain correction value : 1.250

Drift correction value : 0.00

Setable value

$2800 \leq$ Zero point correction value ≤ 3800

$0.500 \leq$ Gain correction value ≤ 3.000

$-9.99 \leq$ Drift correction value ≤ 9.99

Maintenance No.31 Setting of boom tension correction value (Manual)

Function

This enables to change the boom tension correction value (ZERO / GAIN / DRIFT).

Setting procedures ## : Δ▽ & : ↪

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=31 with ##.

4) Press ENTER.

5) LCD1 31: B. Te manual
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 ZERO GAIN DRIFT

8) Press ## and select the setting item.

9) Press ENTER.

When selecting setting of zero point correction value "ZERO"

→ To 10-1)

When selecting setting of gain correction value "GAIN"

→ To 10-2)

When selecting setting of drift correction value "DRIFT"

→ To 10-3)

Setting of zero point correction value

10-1) LCD1 Set content with ##, and press &.

LCD2 Blinks

11-1) Press ## and set the zero point correction value.

When stopping the setting, press RETURN before making the step 12-1). (Go to the step 5).)

The blinking on LCD2 display goes out.

12-1) Press ENTER.

13-1) Return to the step 5).

14-1) Make sure that the indication on LCD2 shows the zero point correction value set.

15-1) Press RETURN.

16-1) Return to the step 2).

17-1) Place the maintenance key switch in "OFF" position.

Maintenance No.31 Setting of boom tension correction value (Manual)

Setting of gain correction value

10-2) LCD1 Set content with ##, and press &.

LCD3 Blinks

11-2) Press ## and set the gain correction value.

When stopping the setting, press RETURN before making the step 11-2). (Go to the step 5.)

The blinking on LCD3 display goes out.

12-2) Press ENTER.

13-2) Return to the step 5).

14-2) Make sure that the indication on LCD3 shows the gain correction value set.

15-2) Press RETURN.

16-2) Return to the step 2).

17-2) Place the maintenance key switch in "OFF" position.

Setting of drift correction value

10-3) LCD1 Set content with ##, and press &.

LCD4 Blinks

11-3) Press ## and set the drift correction value.

When stopping the setting, press RETURN before making the step 11-3). (Go to the step 5.)

The blinking on LCD4 display goes out.

12-3) Press ENTER.

13-3) Return to the step 5).

14-3) Make sure that the indication on LCD4 shows the drift correction value set.

15-3) Press RETURN.

16-3) Return to the step 2).

17-3) Place the maintenance key switch in "OFF" position.

Initial value

Zero point correction value : 500

Gain correction value : 1.875

Drift correction value : 0.00

Setable value

$0 \leq$ Zero point correction value ≤ 1000

$0.500 \leq$ Gain correction value ≤ 3.000

- (Load cell capacity X 0.1) \leq Drift correction value \leq (Load cell capacity X 0.1)

Maintenance No.32 Setting of jib angle correction value (Manual)

Function

This enables to change the boom angle correction value (ZERO / GAIN / DRIFT).

Setting procedures ## : Δ▽ & : ↲

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=32 with ##.

4) Press ENTER.

5) LCD1 32: J. Ang manual
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 ZERO GAIN DRIFT

8) Press ## and select the setting item.

9) Press ENTER.

When selecting setting of zero point correction value "ZERO"

→ To 10-1)

When selecting setting of gain correction value "GAIN"

→ To 10-2)

When selecting setting of drift correction value "DRIFT"

→ To 10-3)

Setting of zero point correction value

10-1) LCD1 Set content with ##, and press &.

LCD2 Blinks

11-1) Press ## and set the zero point correction value.

When stopping the setting, press RETURN before making the step 11-1). (Go to the step 5).)

The blinking on LCD2 display goes out.

12-1) Press ENTER.

13-1) Return to the step 5).

14-1) Make sure that the indication on LCD2 shows the zero point correction value set.

15-1) Press RETURN.

16-1) Return to the step 2).

17-1) Place the maintenance key switch in "OFF" position.

Maintenance No.32 Setting of jib angle correction value (Manual)

Setting of gain correction value

10-2) LCD1 Set content with ##, and press &.
*.***

LCD3 Blinks

11-2) Press ## and set the gain correction value.

When stopping the setting, press RETURN before making the step 11-2). (Go to the step 5).)

The blinking on LCD3 display goes out.

12-2) Press ENTER.

13-2) Return to the step 5).

14-2) Make sure that the indication on LCD3 shows the gain correction value set.

15-2) Press RETURN.

16-2) Return to the step 2).

17-2) Place the maintenance key switch in "OFF" position.

Setting of drift correction value

10-3) LCD1 Set content with ##, and press &.
.

LCD4 Blinks

11-3) Press ## and set the drift correction value.

When stopping the setting, press RETURN before making the step 11-3). (Go to the step 5).)

The blinking on LCD4 display goes out.

12-3) Press ENTER.

13-3) Return to the step 5).

14-3) Make sure that the indication on LCD4 shows the drift correction value set.

15-3) Press RETURN.

16-3) Return to the step 2).

17-3) Place the maintenance key switch in "OFF" position.

Initial value

Zero point correction value : 3167

Gain correction value : 1.250

Drift correction value : 0.00

Setable value

$2800 \leq$ Zero point correction value ≤ 3800

$0.500 \leq$ Gain correction value ≤ 3.000

$-9.99 \leq$ Drift correction value ≤ 9.99

Maintenance No.33 Setting of jib tension correction value (Manual)

Function

This enables to change the jib tension correction value (ZERO / GAIN / DRIFT).

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=33 with ##.

4) Press ENTER.

5) LCD1 31: J. Te manual
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &. ZERO GAIN DRIFT

8) Press ## and select the setting item.

9) Press ENTER.

When selecting setting of zero point correction value "ZERO"

→ To 10-1)

When selecting setting of gain correction value "GAIN"

→ To 10-2)

When selecting setting of drift correction value "DRIFT"

→ To 10-3)

Setting of zero point correction value

10-1) LCD1 Set content with ##, and press &. ****

LCD2 Blanks

11-1) Press ## and set the zero point correction value.

When stopping the setting, press RETURN before making the step 11-1). (Go to the step 5).)

The blinking on LCD2 display goes out.

12-1) Press ENTER.

13-1) Return to the step 5).

14-1) Make sure that the indication on LCD2 shows the zero point correction value set.

15-1) Press RETURN.

16-1) Return to the step 2).

17-1) Place the maintenance key switch in "OFF" position.

Maintenance No.33 Setting of jib tension correction value (Manual)

Setting of gain correction value

- 10-2) LCD1 Set content with ##, and press &.

LCD3 Blinks

- 11-2) Press ## and set the gain correction value.

When stopping the setting, press RETURN before making the step 11-2). (Go to the step 5).)

The blinking on LCD3 display goes out.

- 12-2) Press ENTER.

- 13-2) Return to the step 5).

- 14-2) Make sure that the indication on LCD3 shows the gain correction value set.

- 15-2) Press RETURN.

- 16-2) Return to the step 2).

- 17-2) Place the maintenance key switch in "OFF" position.

Setting of drift correction value

- 10-3) LCD1 Set content with ##, and press &.

LCD4 Blinks

- 11-3) Press ## and set the drift correction value.

When stopping the setting, press RETURN before making the step 11-3). (Go to the step 5).)

The blinking on LCD4 display goes out.

- 12-3) Press ENTER.

- 13-3) Return to the step 5).

- 14-3) Make sure that the indication on LCD4 shows the drift correction value set.

- 15-3) Press RETURN.

- 16-3) Return to the step 2).

- 17-3) Place the maintenance key switch in "OFF" position.

Initial value

Zero point correction value : 500

Gain correction value : 1.875

Drift correction value : 0.00

Setable value

$0 \leq$ Zero point correction value ≤ 1000

$0.500 \leq$ Gain correction value ≤ 3.000

- (Load cell capacity X 0.1) \leq Drift correction value \leq (Load cell capacity X 0.1)

Maintenance No.34 Setting of grip / throttle volume / foot pedal adjustment value (Manual)

Function

- (1-1) This enables to change the grip adjustment value (MIN and MAX position).
- (1-2) This enables to change the throttle volume adjustment value (MIN(at idle) and MAX(at full) position).
- (2) This enables to change the foot pedal adjustment value (MIN(at idle) and MAX(at full) position).

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=34 with ##.

4) Press ENTER.

5) LCD1 34: grip MIN
& : next ## : other


LCD2 MIN position adjustment value

LCD3 MAX position adjustment value

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.



7) Press ENTER.

8) LCD1 Select content with ##, and press &.

LCD2 Blinks (When "34: grip" MIN" or "34: foot MIN" selected)
LCD3 Blinks (When "34: grip" MAX" or "34: foot MAX" selected)

9) Set the adjustment value with ##.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

The blinking on the corresponding LCD display goes out.

10) Press ENTER.

11) Return to the step 5).

12) Make sure that the indication on the corresponding LCD shows a value set.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Maintenance No.34 Setting of grip / throttle volume / foot pedal adjustment value (Manual)

				Initial value	Setable value	
grip	Tier2	LS-308HII	Min	1440 [3.600V]	650 ≤	≤ 2340 [1.625V] [5.850V]
		LS-308H5		2880 [7.200V]	1610 ≤	≤ 4340 [4.025V] [10.850V]
	Tier3	LS-348H5	Max	2880 [7.200V]	1610 ≤	≤ 4340 [4.025V] [10.850V]
		LS-348H5		3150 [7.875V]	1600 ≤	≤ 4400 [4.000V] [11.000V]
throttle volume	Tier3	LS-238H5	Min	1650 [4.125V]	400 ≤	≤ 3000 [1.000V] [7.500V]
		LS-248H5		3150 [7.875V]	1600 ≤	≤ 4400 [4.000V] [11.000V]
		LS-108H5	Max	3752 [9.380V]	2400 ≤	≤ 4400 [6.000V] [11.000V]
	Tier2	LS-348H5	Min	1600 [4.000V]	400 ≤	≤ 2400 [1.000V] [6.000V]
			Max	3200 [8.000V]	2000 ≤	≤ 4400 [5.000V] [11.000V]
			Min	1600 [4.000V]	400 ≤	≤ 2400 [1.000V] [6.000V]

Maintenance No.35 Setting of Luffing Test STEP

Function

This enables to change Luffing Test STEP.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=35 with ##.

4) Press ENTER.

5) LCD1 Luffing Test
Press &.

LCD2 The correction value

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &. *.

LCD2 Blanks

8) Set the correction value with ##.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 shows a value set.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

0 [Normal]

Setable value

0 [Normal], 1 [STEP 1], 2 [STEP 2], 3 [STEP 3]

**Maintenance No.36 Setting of radio load cell capacity
& coefficient (Indication of actual load) for radio load cell**

Function

This enables to change radio load capacity value and coefficient (Indication of actual load) for radio load cell.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=36 with ##.

4) Press ENTER.

5) LCD1 36: Radio-Main-F & : next ## : other ↔ 36: Radio-Aux-R/3 & : next ## : other

LCD2 Radio load cell - main[front] capacity [**.**kips]

LCD3 Radio load cell - aux[rear/3rd] capacity [**.**kips]

LS-348H5 : Rear Drum / LS-248H5 : 3rd Drum

LCD4 to LCD5 Blank

LCD1 36: LOAD DISP & : next ## : other

LCD2 Coefficient (Indication of actual load) for radio load cell

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

► 36: Radio-Main-F Radio load cell - main[front] capacity



36: Radio-Aux-R/3 Radio load cell - aux[rear/3rd] capacity



► 36: LOAD DISP Coefficient (Indication of actual load) for radio load cell

7) Press ENTER.

When selecting setting of radio load cell - main[front] & aux[rear/3rd] capacity

► To 8-1)

When selecting setting of Coefficient (Indication of actual load) for radio load cell

► To 8-2)

**Maintenance No.36 Setting of radio load cell capacity
& coefficient (Indication of actual load) for radio load cell**

Setting of radio load cell - main[front] & aux[rear/3rd] capacity

8-1) LCD1 Select content with ##, and press &.
**.*kips

LCD2 Blinks (When "36: Radio-Main-F" selected)
LCD3 Blinks (When "36: Radio-Aux-R/3" selected)

9-1) Set the capacity with ##.

When stopping the setting, press RETURN before making the step 10-1). (Go to the step 5).)
The blinking on the corresponding LCD display goes out.

10-1) Press ENTER.

11-1) Return to the step 5).

12-1) Make sure that the indication on the corresponding LCD shows a value set.

13-1) Press RETURN.

14-1) Return to the step 2).

15-1) Place the maintenance key switch in "OFF" position.

Setting of coefficient (Indication of actual load) for radio load cell

8-2) LCD1 Select content with ##, and press &.
*,***

LCD2 Blinks

9-2) Press ## and select coefficient.

When stopping the setting, press RETURN before making the step 10-2). (Go to the step 5).)
The blinking on LCD2 display goes out.

10-2) Press ENTER.

11-2) Return to the step 5).

12-2) Make sure that the indication on LCD2 shows coefficient selected.

13-2) Press RETURN.

14-2) Return to the step 2).

15-2) Place the maintenance key switch in "OFF" position.

Initial value

Capacity : 45.00 kips
Coefficient : 1.000

Setable value

Capacity : No limitation
0.000 ≤ Coefficient ≤ 9.999

Maintenance No.37 Setting of throttle motor adjustment value (Manual)

Function

This enables to change the throttle motor adjustment value (idle and full position).

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=37 with ##.

4) Press ENTER.

5) LCD1 37: IDLING
& : next ## : other

LCD2 Idle position adjustment value

LCD3 Full position adjustment value

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

37: IDLING Setting of throttle motor Idle position adjustment value



37: FULL Setting of throttle motor full position adjustment value

7) Press ENTER.

8) LCD1 Select content with ##, and press &.

LCD2 Blinks (When "37: IDLING" selected)

LCD3 Blinks (When "37: FULL" selected)

9) Set the adjustment value with ##.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

The blinking on the corresponding LCD display goes out.

10) Press ENTER.

11) Return to the step 5).

12) Make sure that the indication on the corresponding LCD is same as LCD5.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

Idle position adjustment value : 599 [1.499V]

Full position adjustment value : 4110 [10.275V]

Setable value

115 [0.288V] ≤ Idle position adjustment value ≤ 1083 [2.708V]

3626 [9.065V] ≤ Full position adjustment value ≤ 4594 [11.485V]

Maintenance No.38 Setting of boom tension hysteresis correction value

Function

This enables to change the boom tension hysteresis to correct the hysteresis which occurs to the load cell detection signal for the boom hoist rope tension detection with the boom hoisting / lowering.

Setting procedures # : $\Delta\nabla$ & : $\leftarrow\downarrow$

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=38 with ##.

4) Press ENTER.

5) LCD1 38: HYST Boom
Press &.

LCD2 The boom tension hysteresis correction value

LCD3 The jib tension hysteresis correction value

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 ..*

LCD2 Blanks

8) Set the correction value with ##.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 shows a value set.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

Curve data	Crane	Auxiliary sheaves without jib	Auxiliary sheaves with jib
LS-108H5	1.021	N / A	N / A
LS-138H5	1.021	N / A	N / A
LS-218H5	1.015	1.015	1.015
LS-238H5	1.018	1.018	1.018
LS-248H5	1.024	N / A	N / A
LS-308HII	1.015	N / A	N / A
LS-308H5			
LS-348H5	1.036 \times 1	1.036 \times 2	1.036 \times 2

\times 1: When the radio load cell is used with the crane attachment, this value is not used.

\times 2: This value is not used, because the radio load cell is used with the luffing attachment.

<<Caution>>

The followings are given according to the curve data when the maintenance No.9 is executed, and an individual set is required.

A. When selecting "Crane", "Auxiliary sheaves with jib" and "Auxiliary sheaves without jib"

The jib tension hysteresis correction value = 1.000

>>>The setting with Maintenance No.39 is required.

B. When selecting "Luffing" and "Midfall"

The boom tension hysteresis correction value = 1.000

>>>The setting with Maintenance No.38 is required.

Setable value

0.500 \leq Hysteresis correction value \leq 3.000

Maintenance No.39 Setting of jib tension hysteresis correction value

Function

This enables to change the jib tension hysteresis to correct the hysteresis which occurs to the load cell detection signal for the jib hoist rope tension detection with the jib hoisting / lowering.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 [Select content with ##, and press &.]
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=39 with ##.

4) Press ENTER.

5) LCD1 [39: HYST Jib
Press &.]

LCD2 The boom tension hysteresis correction value

LCD3 The jib tension hysteresis correction value

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 [Select content with ##, and press &.
*.***]

LCD3 Blinks

8) Set the correction value with ##.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD3 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD3 shows a value set.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

Curve data	Luffing	Midfall
LS-108H5	N / A	N / A
LS-138H5	N / A	N / A
LS-218H5	1.012	N / A
LS-238H5	1.012	N / A
LS-248H5	1.015 ×1	1.015 ×1
LS-308HII		
LS-308H5	N / A	N / A
LS-348H5	1.015 ×1	1.015 ×1

※1: This value is not used, because the radio load cell is used with the luffing attachment.

<<Caution>>

The followings are given according to the curve data when the maintenance No.9 is executed, and an individual set is required.

A. When selecting "Crane", "Auxiliary sheaves with jib" and "Auxiliary sheaves without jib"

The jib tension hysteresis correction value = 1.000

>>>The setting with Maintenance No.39 is required.

B. When selecting "Luffing" and "Midfall"

The boom tension hysteresis correction value = 1.000

>>>The setting with Maintenance No.38 is required.

Setable value

0.500 ≤ Hysteresis correction value ≤ 3.000

Maintenance No.40 Setting of pump / engine / winch motor control point

Function

This enables to change the pump / engine / winch motor control point.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=40 with ##.

4) Press ENTER.

5) LCD1 40: Pump MIN 1
& : next ## : other

LCD2 Pump MIN point (At throttle variable)

LCD3 Pump MAX point (At throttle variable)

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2.).

6) Press ## and select the setting item.

- | | |
|---|---|
| ► 40 : Pump MIN 1 | Setting of pump control Min. point (At throttle variable) |
|  | |
| 40 : Pump MAX 1 | Setting of pump control Max. point (At throttle variable) |
|  | |
| 40 : Pump MIN 2 | Setting of pump control Min. point (At throttle fixed) |
|  | |
| 40 : Pump MAX 2 | Setting of pump control Max. point (At throttle fixed) |
|  | |
| 40 : Engine MIN | Setting of engine control Min.[Idle] point (At throttle variable) |
|  | |
| 40 : Engine MAX | Setting of engine control Max.[Full] point (At throttle variable) |
|  | |
| 40 : Winch MAX 1 | Setting of winch motor control Max.[1st speed] point (At throttle variable) |
|  | |
| 40 : Winch MIN 1 | Setting of winch motor control Min.[2nd speed] point (At throttle variable) |
|  | |
| 40 : Winch MAX 2 | Setting of winch motor control Max.[1st speed] point (At throttle fixed) |
|  | |
| ► 40 : Winch MIN 2 | Setting of winch motor control Min.[2nd speed] point (At throttle fixed) |

7) Press ENTER.

8) LCD1 Select content with ##, and press &.

LCD2 Blinks (When "40 : Pump MIN 1" or "40 : Pump MIN 2" or "40 : Engine MIN" or "40 : Winch MAX 1" or "40 : Winch MAX 2" selected)

LCD3 Blinks (When "40 : Pump MAX 1" or "40 : Pump MAX 2" or "40 : Engine MAX" or "40 : Winch MIN 1" or "40 : Winch MIN 2" selected)

9) Set the control point with ##.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

The blinking on the corresponding LCD display goes out.

Maintenance No.40 Setting of pump / engine / winch motor control point

- 10) Press ENTER.
- 11) Return to the step 5).
- 12) Make sure that the indication on the corresponding LCD shows a value set.
- 13) Press RETURN.
- 14) Return to the step 2).
- 15) Place the maintenance key switch in "OFF" position.

Initial value

		At throttle variable	At throttle fixed
Pump	Min. point	0% Pmin-V	0% Pmin-F
	Max. point	35% Pmax-V	100% Pmax-F
Engine	Min.[Idle] point	10% Emin	----
	Max.[Full] point	100% Emax	----
Winch motor	Max.[1st speed] point	100%	100%
	Min.[2nd speed] point	100%	100%

These data are not used.


Setable value

Pump control point : $0\% \leq \text{Min. point} \leq \text{Max. point} \leq 100\%$

Engine control point : $0\% \leq \text{Min.}[Idle] \text{ point} \leq \text{Max.}[Full] \text{ point} \leq 100\%$

Winch motor control point : $0\% \leq \text{Max.}[1\text{st speed}] \text{ point} \leq \text{Min.}[2\text{nd speed}] \text{ point} \leq 100\%$

Explanation



Maintenance No.41 Setting of throttle motor control data

Function

This enables to change the throttle motor control data.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=41 with ##.

4) Press ENTER.

5) LCD1 41: Throttle 1
& : next ## : other

LCD2 Throttle motor deadband engine speed

LCD3 High idle cut engine speed

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

-
- 41: Throttle 1 Setting of throttle motor deadband engine speed
↑
↓
► 41: Throttle 2 Setting of high idle cut engine speed

7) Press ENTER.

8) LCD1 Select content with ##, and press &.
 ***[rpm]

LCD2 Blinks (When "41: Throttle 1" selected)

LCD3 Blinks (When "41: Throttle 2" selected)

LCD4 to LCD5 Blank

9) Set the engine speed with ##.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

10) Press ENTER.

11) Make sure that the indication on the corresponding LCD shows a value set.

12) Return to the step 5).

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

Throttle motor deadband engine speed : 50rpm

High idle cut engine speed : 1850rpm [LS-348H5 Tier2]

Setable value

5rpm ≤ Throttle motor deadband engine speed ≤ 175rpm

2000rpm ≤ High idle cut engine speed ≤ 3000rpm

Explanation

• Throttle motor deadband engine speed

This is data for the throttle motor control to prevent the engine hunting phenomenon.

When setting value of "Maintenance No.59 - Throttle motor control" is "1 (Present)", this data is used.

| Demand position - Actual position | ≤ Throttle motor deadband engine speed → STOP

Demand position - Actual position > Throttle motor deadband engine speed → UP

Demand position - Actual position < Throttle motor deadband engine speed → DOWN

• High idle cut engine speed

This is data for the high idle cut control to protect the pump.

When setting value of "Maintenance No.59 - High idle cut control" is "1 (Present)", this data is used.

Maintenance No.42 Setting of ECU / ECM control data

Function

This enables to change the engine throttle output voltage (Idle and Full) to ECU / ECM.

Setting procedures ## : Δ▽ & : ←→

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=42 with ##.

4) Press ENTER.

5) LCD1 42: IDLING
& : next ## : other

LCD2 Idle output voltage

LCD3 Full output voltage

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2.).

6) Press ## and select the setting item.

-
- ▶ 42: IDLING Setting of engine throttle idle output voltage
 - ↓
 - ▶ 42: FULL Setting of engine throttle full output voltage

7) Press ENTER.

8) LCD1 Select voltage with ##, and press &.
 *.**[v]

LCD2 Blinks (When "42: IDLING" selected)

LCD3 Blinks (When "42: FULL" selected)

LCD4 to LCD5 Blank

9) Set the output voltage with ##.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5.).

10) Press ENTER.

11) Make sure that the indication on the corresponding LCD shows a value set.

12) Return to the step 5).

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

	Tier2		Tier3	
	ECU		ECU	ECM
LS-308HII		LS-348H5	LS-238H5	
LS-308H5			LS-248H5	
			LS-108H5	
Idle output voltage	2.042V [52]		0.902V [23]	
Full output voltage	3.704V [94]		4.118V [105]	

Setable value

0.000V ≤ Engine throttle output voltage ≤ 9.999V

Maintenance No.43 Setting of radio load cell - main[front] correction value (Manual)

Function

This enables to change radio load cell - main[front] correction value (ZERO / GAIN / DRIFT).

Setting procedures ## : Δ▽ & : ←↓

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=43 with ##.

4) Press ENTER.

5) LCD1 43: Radio-Main-F
Press &.

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 ZERO GAIN DRIFT

8) Press ## and select the setting item.

9) Press ENTER.

When selecting setting of zero point correction value "ZERO"

→ To 10-1)

When selecting setting of gain correction value "GAIN"

→ To 10-2)

When selecting setting of drift correction value "DRIFT"

→ To 10-3)

Setting of zero point correction value

10-1) LCD1 Set content with ##, and press &.

LCD2 Blanks

11-1) Press ## and set the zero point correction value.

When stopping the setting, press RETURN before making the step 11-1). (Go to the step 5).)

The blinking on LCD2 display goes out.

12-1) Press ENTER.

13-1) Return to the step 5).

14-1) Make sure that the indication on LCD2 shows the zero point correction value set.

15-1) Press RETURN.

16-1) Return to the step 2).

17-1) Place the maintenance key switch in "OFF" position.

Maintenance No.43 Setting of radio load cell - main[front] correction value (Manual)

Setting of gain correction value

10-2) LCD1 Set content with ##, and press &.
*.***

LCD3 Blinks

11-2) Press ## and set the gain correction value.

When stopping the setting, press RETURN before making the step 11-2). (Go to the step 5).)

The blinking on LCD3 display goes out.

12-2) Press ENTER.

13-2) Return to the step 5).

14-2) Make sure that the indication on LCD3 shows the gain correction value set.

15-2) Press RETURN.

16-2) Return to the step 2).

17-2) Place the maintenance key switch in "OFF" position.

Setting of drift correction value

10-3) LCD1 Set content with ##, and press &.
.

LCD4 Blinks

11-3) Press ## and set the drift correction value.

When stopping the setting, press RETURN before making the step 11-3). (Go to the step 5).)

The blinking on LCD4 display goes out.

12-3) Press ENTER.

13-3) Return to the step 5).

14-3) Make sure that the indication on LCD4 shows the drift correction value set.

15-3) Press RETURN.

16-3) Return to the step 2).

17-3) Place the maintenance key switch in "OFF" position.

Initial value

Zero point correction value : 900

Gain correction value : 1.389

Drift correction value : 0.00

Setable value

50 ≤ Zero point correction value ≤ 1500

0.500 ≤ Gain correction value ≤ 3.000

- (Load cell capacity X 0.1) ≤ Drift correction value ≤ (Load cell capacity X 0.1)

Maintenance No.44 Setting of radio load cell - aux[rear/3rd] correction value (Manual)

Function

This enables to change radio load cell - aux[rear/3rd] correction value (ZERO / GAIN / DRIFT).
LS-348H5 : Rear Drum / LS-248H5 : 3rd Drum

Setting procedures ## : Δ▽ & : ↲

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=44 with ##.

4) Press ENTER.

5) LCD1 44: Radio-Aux-R/3
Press &

LCD2 Zero point correction value

LCD3 Gain correction value

LCD4 Drift correction value

LCD5 Blank

(When RETURN is pressed, go to the step 2.)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
ZERO GAIN DRIFT

8) Press ## and select the setting item.

9) Press ENTER.

When selecting setting of zero point correction value "ZERO"

→ To 10-1)

When selecting setting of gain correction value "GAIN"

→ To 10-2)

When selecting setting of drift correction value "DRIFT"

→ To 10-3)

Setting of zero point correction value

10-1) LCD1 Set content with ##, and press &.

LCD2 Blanks

11-1) Press ## and set the zero point correction value.

When stopping the setting, press RETURN before making the step 11-1). (Go to the step 5.)

The blinking on LCD2 display goes out.

12-1) Press ENTER.

13-1) Return to the step 5).

14-1) Make sure that the indication on LCD2 shows the zero point correction value set.

15-1) Press RETURN.

16-1) Return to the step 2).

17-1) Place the maintenance key switch in "OFF" position.

Maintenance No.44 Setting of radio load cell - aux[rear/3rd] correction value (Manual)

Setting of gain correction value

- 10-2) LCD1 Set content with ##, and press &.
..*

LCD3 Blinks

- 11-2) Press ## and set the gain correction value.

When stopping the setting, press RETURN before making the step 11-2). (Go to the step 5).)

The blinking on LCD3 display goes out.

- 12-2) Press ENTER.

- 13-2) Return to the step 5).

- 14-2) Make sure that the indication on LCD3 shows the gain correction value set.

- 15-2) Press RETURN.

- 16-2) Return to the step 2).

- 17-2) Place the maintenance key switch in "OFF" position.

Setting of drift correction value

- 10-3) LCD1 Set content with ##, and press &.
..*

LCD4 Blinks

- 11-3) Press ## and set the drift correction value.

When stopping the setting, press RETURN before making the step 11-3). (Go to the step 5).)

The blinking on LCD4 display goes out.

- 12-3) Press ENTER.

- 13-3) Return to the step 5).

- 14-3) Make sure that the indication on LCD4 shows the drift correction value set.

- 15-3) Press RETURN.

- 16-3) Return to the step 2).

- 17-3) Place the maintenance key switch in "OFF" position.

Initial value

Zero point correction value : 900

Gain correction value : 1.389

Drift correction value : 0.00

Setable value

$50 \leq$ Zero point correction value ≤ 1500

$0.500 \leq$ Gain correction value ≤ 3.000

- (Load cell capacity X 0.1) \leq Drift correction value \leq (Load cell capacity X 0.1)

Maintenance No.45 Setting of radio load cell hysteresis correction value (Manual)

Function

This enables to change radio load cell hysteresis correction value.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.

Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=45 with ##.

4) Press ENTER.

5) LCD1 45: Radio-Main-F
& : next ## : other

LCD2 Radio load cell - main[front] hysteresis correction value

LCD3 Radio load cell - aux[rear/3rd] hysteresis correction value

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

45: Radio-Main-F Radio load cell - main[front] hysteresis correction value



45: Radio-Aux-R/3 Radio load cell - aux[rear/3rd] hysteresis correction value
LS-348H5 : Rear Drum / LS-248H5 : 3rd Drum

7) Press ENTER.

8) LCD1 Select content with ##, and press &.
..*

LCD2 Blanks (When "45: Radio-Main-F" selected)

LCD3 Blanks (When "45: Radio-Aux-R/3" selected)

9) Set the correction value with ##.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

The blinking on the corresponding LCD display goes out.

10) Press ENTER.

11) Return to the step 5).

12) Make sure that the indication on the corresponding LCD shows a value set.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

1.000

Setable value

0.500 ≤ Hysteresis correction value ≤ 3.000

Maintenance No.46 Setting of luffing protection device (Luffing set mode) data

Function

This enables to change the luffing protection device (Luffing set mode) data, and this displays the jib tension judgement value.

<<Caution>>

The luffing protection device does not function in LBCE Model.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=46 with ##.

4) Press ENTER.

5) LCD1 LF protect 1
& : next ## : other

LCD2 Working status

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2.)

6) Press ## and select the setting item.

LCD1	LCD2	LCD3	LCD4	LCD5	Item	Initial value
LF protect 1 & : next ## : other	*	Blank	Blank	Blank	Setting of working status	0
LF protect 2 & : next ## : other	**.** °	Blank	Blank	Blank	Setting of jib angle when the jib catch limit switch functions	27.00°
LF protect 3	**.** ton Override	**.** ton Stop	Blank	Blank	Display of jib tension judgement value when raising the luffing boom	0.00ton 0.00ton
LF protect 4	**.** ton Override	**.** ton Stop	**.** ton Slow down	Blank	Display of jib tension judgement value when lowering the luffing boom	0.00ton 0.00ton 0.00ton
LF protect 5	**.** ton Override	**.** ton Stop	Blank	Blank	Display of jib tension judgement value when raising the luffing jib	0.00ton 0.00ton

When selecting setting of working status "LF protect 1"

→ To 7-1)

When selecting setting of jib angle when the jib catch limit switch functions "LF protect 2"

→ To 7-2)

When selecting display of jib tension judgement value "LF protect 3 / LF protect 4 / LF protect 5"

→ To 7-3)

Maintenance No.46 Setting of luffing protection device (Luffing set mode) data

Setting of working status

7-1) Press ENTER.

8-1) LCD1 Select content with ##, and press &.
* *

LCD2 Working status
LCD3 to LCD5 Blank

9-1) Set the working status with ##.

When stopping the setting, press RETURN before making the step 10-1). (Go to the step 5.)

10-1) Press ENTER.

11-1) Make sure that the indication on LCD2 shows the working status set.

12-1) Return to the step 5).

13-1) Press RETURN.

14-1) Return to the step 2).

15-1) Place the maintenance key switch in "OFF" position.

Initial value

0 (Rigging mode, Crane set mode, Work mode)

Setable value

$0 \leq$ Working status ≤ 8

Setting of jib angle when the jib catch limit switch functions

7-2) Press ENTER.

8-2) LCD1 Select content with ##, and press &.
.°

LCD2 Jib angle
LCD3 to LCD5 Blank

9-2) Set the jib angle with ##.

When stopping the setting, press RETURN before making the step 10-2). (Go to the step 5.)

10-2) Press ENTER.

11-2) Make sure that the indication on LCD2 shows the jib angle set.

12-2) Return to the step 5).

13-2) Press RETURN.

14-2) Return to the step 2).

15-2) Place the maintenance key switch in "OFF" position.

Display of jib tension judgement value

7-3) The following are displayed.

LCD1	LCD2	LCD3	LCD4	LCD5	Item
LF protect 3	**.** ton Override	**.** ton Stop	Blank	Blank	Display of jib tension judgement value when raising the luffing boom
LF protect 4	**.** ton Override	**.** ton Stop	**.** ton Slow down	Blank	Display of jib tension judgement value when lowering the luffing boom
LF protect 5	**.** ton Override	**.** ton Stop	Blank	Blank	Display of jib tension judgement value when raising the luffing jib

8-3) Press RETURN.

9-3) Return to the step 2).

10-3) Place the maintenance key switch in "OFF" position.

Maintenance No.47 Setting of anti-two block limit data

Function

This enables to change the anti-two block limit data.

<<Caution>>

The anti-two block limit does not function in LBCE Model.

Setting procedures ## : $\Delta\nabla$ & : \leftarrow

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=47 with ##.

4) Press ENTER.

5) LCD1 47: start
& : next ## : other

LCD2 Deceleration start distance

LCD3 Deceleration end distance

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

- ▶ 47: start Setting of deceleration start distance
- ↑
↓
- ▶ 47: end Setting of deceleration end distance

7) Press ENTER.

8) LCD1 Select content with ##, and press &.
**.*[m]

LCD2 Blinks (When "47: start" selected)

LCD3 Blinks (When "47: end" selected)

LCD4 to LCD5 Blank

9) Set the distance with ##.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

10) Press ENTER.

11) Make sure that the indication on the corresponding LCD shows a value set.

12) Return to the step 5).

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

Deceleration start distance : 1.0m

Deceleration end distance : 0.5m

Setable value

$0.0m \leq$ Deceleration end distance < Deceleration start distance $\leq 10.0m$

Maintenance No.48 Setting of pump control data

Function

This enables to change the pump control data.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=48 with ##.

4) Press ENTER.

5) LCD1 1: Delay
& : next ## : other

LCD2 Primary delay coefficient

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

- | | |
|--------------|--|
| ► 1: Delay | Setting of primary delay coefficient |
| ↑ | |
| 2: Mode | Setting of ultra low speed mode control type |
| ↓ | |
| ► 3: Neutral | Setting of control lever neutral check |

7) Press ENTER.

8) LCD1 Select content with ##, and press &.

LCD2 The memorized value

LCD3 to LCD5 Blank

9) Press ## and select value.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

10) Press ENTER.

11) Make sure that the indication on LCD2 shows value selected.

12) Return to the step 5).

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

Primary delay coefficient : 8%
Ultra low speed mode control type : 2 (Type 2)
Control lever neutral check : 1 (w/ interlock)

Setable value

0% ≤ Primary delay coefficient ≤ 100%
Ultra low speed mode control type : 2 (Type 2), 3(Type 3)
Control lever neutral check : 1 (w/ interlock), 0 (w/o interlock)

Maintenance No.49 Setting of rigging mode data

Function

This enables to change the rigging mode data.

Setting procedures ## : Δ▽ & : ↪

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=49 with ##.

4) Press ENTER.

5) LCD1 Rigging mode 1
& : next ## : other

LCD2 Rigging mode judgement value

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

- ▶ Rigging mode 1 Rigging mode judgement value
- ↑
- Rigging mode 6 Angle sensor signal wire breakage judgement value
- ↓
- ▶ Rigging mode 8 Boom angle judgement value 1

7) Press ENTER.

8) LCD1 Select content with ##, and press &.

LCD2 The memorized value

LCD3 to LCD5 Blank

9) Press ## and select value.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

10) Press ENTER.

11) Make sure that the indication on LCD2 shows value selected.

12) Return to the step 5).

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

Rigging mode judgement value : 0 (Other modes)

Angle sensor signal wire breakage judgement value : 2.00deg

Boom angle judgement value 1 : 75.00deg [Other model] / 65.00deg [LS-348H5] / 80.00deg [LS-248H5]

Setable value

Rigging mode judgement value : 0 (Other modes) / 1 (Rigging mode) / 2 (Crane set mode) / 3 (Luffing set mode)

0.00deg ≤ Angle sensor signal wire breakage judgement value ≤ 10.00deg

0.00deg ≤ Boom angle judgement value 1 ≤ 90.00deg

Maintenance No.50 Setting of slowdown device reset time

Function

This enables to change the slowdown device reset time.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=50 with ##.

4) Press ENTER.

5) LCD1 50: Reset time
Press &.

LCD2 Slowdown device reset time

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 .[sec]

LCD2 Blanks

8) Press ## and select the slowdown device reset time.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 shows the slowdown device reset time selected.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

5.00seconds [100]

Setable value

0.00second [0] ≤ Slowdown device reset time ≤ 10.00seconds [200]

The setting is every 0.05 seconds.

Maintenance No.51 Setting of boom protection device judgement coefficient

Function

This enables to change the boom protection device judgement coefficient.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=51 with ##.

4) Press ENTER.

5) LCD1 51: Coefficient
Press &.

LCD2 Boom protection device judgement coefficient [%]

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 ***[%]

LCD2 Blanks

8) Press ## and select the coefficient.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 shows the coefficient selected.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

50% [500]

Setable value

0% [0] < Coefficient ≤ 100% [1000]

Maintenance No.52 Setting of Pz-DA curve

Function

This enables to change Pz-DA curve that shows relation between Pz [Power shift pressure] and DA [Power shift output voltage].
Also this enables to make initializing.

Preparation

Connect the pressure gauge on the power shift pressure port when executing "Adjustment of power shift output voltage (Actual machine)" and "Pz [Power shift pressure] - Point ?".

Setting procedures ## : Δ▽ & : ←

- 1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)
- 2) LCD1 Select content with ##, and press &.
Mainte No.= 0

LCD2 to LCD5 Blank

- 3) Set the Mainte No.=52 with ##.
- 4) Press ENTER.

- 5) LCD1 52: Adjustment
& : next ## : other

LCD2 Pz [Power shift pressure] - Point ? [***.*kgf/cm²]

LCD3 DA [Power shift output voltage] - Point ? [**.**V]


LCD4 Pzmax [Max. power shift pressure] [0.0kgf/cm²]

LCD5 Power shift output voltage [**.**V]

(When RETURN is pressed, go to the step 2).)

	Power shift output voltage (displayed on LCD5)
All machine	0.00V

- 6) Press ## and select the setting item.



- 7) Press ENTER.

- | | |
|---|-----------|
| When selecting adjustment of power shift output voltage (Actual machine) "52: Adjustment" | → To 8-1) |
| When selecting Pz [Power shift pressure] - Point ? "52: Point ? PZ" | → To 8-2) |
| When selecting DA [Power shift output voltage] - Point ? "52: Point ? DA" | → To 8-3) |
| When selecting offset amount of power shift output voltage "52: Offset" | → To 8-4) |
| When selecting Pz-DA curve initial "52: PZ-DA initial" | → To 8-5) |

Maintenance No.52 Setting of Pz-DA curve

Adjustment of power shift output voltage (Actual machine)

- Find out the power shift output voltage when the power shift pressure that read with watching the pressure gauge is same as Pz [Power shift pressure] (displayed on LCD2) and correct the individual difference.
- The gap between the actual machine adjustment value and the initial value is reflected in DA of other points.

		Adjustment	Reflection
Tier2	LS-308HII / LS-308H5	Point 5	Point 1, 2, 3, 4, 6
	LS-348H5	Point 5	Point 1, 2, 3, 4, 6
	LS-138H5 from LS138-4264	Point 2	Point 1, 3, 4, 5
Tier3	LS-238H5	Point 3	Point 1, 2, 4, 5
	LS-248H5	Point 3	Point 1, 2, 4, 5
	LS-348H5	Point 3	Point 1, 2, 4, 5

8-1) LCD1 52: Adjustment
& : start

LCD2 Pz [Power shift pressure] - Point ? [***.*kgf/cm²]

LCD3 DA [Power shift output voltage] - Point ? [**.*V]

LCD4 Pzmax [Max. power shift pressure] [0.0kgf/cm²]

LCD5 Power shift output voltage [**.*V]

(When RETURN is pressed, go to the step 2).)

		Power shift output voltage (displayed on LCD5)
Tier2	LS-308HII / LS-308H5	DA Point 5 - 3.00V
	LS-348H5	DA Point 5 - 3.00V
	LS-138H5 from LS138-4264	10.00V
Tier3	LS-238H5	DA Point 3 - 3.00V
	LS-248H5	DA Point 3 - 3.00V
	LS-348H5	10.00V → DA Point 3 + 3.00V

9-1) Press #.

10-1) LCD1 52: Adjustment
& : Set voltage

LCD3 DA [Power shift output voltage] - Point ? [**.*V] Blanks

11-1) The power shift output voltage (displayed on LCD5) changes by 0.1V, and the power shift pressure (the pressure gauge) changes.

		Power shift output voltage (displayed on LCD5)	Power shift pressure (the pressure gauge)
Tier2	LS-308HII / LS-308H5	0.10V increase	Fall
	LS-348H5	0.10V increase	Fall
	LS-138H5 from LS138-4264	0.10V decrease	Fall
Tier3	LS-238H5	0.10V increase	Rise
	LS-248H5	0.10V increase	Rise
	LS-348H5	0.10V decrease	Rise

When stopping the setting, press RETURN before making the step 12-1). (Go to the step 5).)

12-1) Press ENTER when the power shift pressure (the pressure gauge) is same as Pz [Power shift pressure] (displayed on LCD2).

13-1) Return to the step 5).

14-1) Make sure that the indication on LCD3 shows the power shift output voltage (displayed on LCD5) with ENTER pressed.

15-1) Press RETURN.

16-1) Return to the step 2).

17-1) Place the maintenance key switch in "OFF" position.

Maintenance No.52 Setting of Pz-DA curve

Pz [Power shift pressure] - Point ?

8-2) LCD1 Select content with ##, and press &.
Pz ? ***.*

LCD2	Pz [Power shift pressure] - Point ?	[***.*kgf/cm ²]	Blinks
LCD3	DA [Power shift output voltage] - Point ?	[**.**V]	
LCD4	Pzmax [Max. power shift pressure]	[0.0kgf/cm ²]	
LCD5	Blank		

The power shift output voltage displayed on LCD3 is output.

(When RETURN is pressed, go to the step 5).)

- 9-2) Read the power shift pressure with watching the pressure gauge connected on the power shift pressure port.
10-2) Press ## and select the power shift pressure that read with watching the pressure gauge.

When stopping the setting, press RETURN before making the step 11-2). (Go to the step 5).)

- 11-2) Press ENTER.
12-2) Return to the step 5).
13-2) Make sure that the indication on LCD2 shows the power shift pressure selected.
14-2) Press RETURN.
15-2) Return to the step 2).
16-2) Place the maintenance key switch in "OFF" position.

DA [Power shift output voltage] - Point ?

8-3) LCD1 Select content with ##, and press &.
DA ? **.**

LCD2	Pz [Power shift pressure] - Point ?	[***.*kgf/cm ²]	
LCD3	DA [Power shift output voltage] - Point ?	[**.**V]	Blinks
LCD4	Pzmax [Max. power shift pressure]	[0.0kgf/cm ²]	
LCD5	Blank		

The power shift output voltage displayed on LCD3 is output.

(When RETURN is pressed, go to the step 5).)

- 9-3) Press ## and select the power shift output voltage.
When stopping the setting, press RETURN before making the step 10-3). (Go to the step 5).)
10-3) Press ENTER.
11-3) Return to the step 5).
12-3) Make sure that the indication on LCD3 shows the power shift output voltage selected.
13-3) Press RETURN.
14-3) Return to the step 2).
15-3) Place the maintenance key switch in "OFF" position.

Maintenance No.52 Setting of Pz-DA curve

[Offset amount of power shift output voltage]

8-4) LCD1 Select content with ##, and press &.
.

LCD2 Offset amount of power shift output voltage [**.**V] Blinks
LCD3 to LCD5 Blank

9-4) Press ## and select the offset amount of power shift output voltage.

(When stopping the setting, press RETURN before making the step 10-4). (Go to the step 5).)

10-4) Press ENTER.

11-4) Return to the step 5).

12-4) Make sure that the indication on LCD2 shows the offset amount of power shift output voltage selected.

13-4) Press RETURN.

14-4) Return to the step 2).

15-4) Place the maintenance key switch in "OFF" position.

[Pz-DA curve initial]

8-5) LCD1 Select content with ##, and press &.

LCD2 to LCD3 ----
LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 5).)

9-5) Press ## and select 5252.

10-5) Press ENTER.

LCD2 to LCD3 ---- → HHHH → ----

11-5) Press RETURN.

12-5) Return to the step 5).

13-5) Press RETURN.

14-5) Return to the step 2).

15-5) Place the maintenance key switch in "OFF" position.

Initial value

Pz-DA curve : Refer to the table.

Offset amount of power shift output voltage : 0.00V

Setable value

$0.0\text{kgf/cm}^2 \leq \text{Pz}$ [Power shift pressure] $\leq 50.0\text{kgf/cm}^2$

$0.00\text{V} \leq \text{DA}$ [Power shift output voltage] $\leq 10.00\text{V}$

$0.00\text{V} \leq \text{Offset amount of power shift output voltage} \leq 10.00\text{V}$

Maintenance No.52

Setting of Pz-DA curve - Table

		Initial value															
		LS-108H5			LS-138H5			LS-218H5		LS-238H5		LS-248H5		LS-348H5		LS-308H5	
		Tier2	Tier3	Tier2	Tier2	Tier3	Tier2	Tier3	Tier2	Tier3	Tier2	Tier3	Tier2	Tier3	Tier2	Tier3	
Pz (kgf/cm ²) [Power shift pressure]	Point 1	40.0	40.0	40.0	21.8	40.0	40.0	40.0	40.0	40.0	40.0	40.0	40.0	35.1	31.3	34.6	
	Point 2	40.0	40.0	40.0	17.5	40.0	40.0	21.0	40.0	21.0	26.0	24.5	26.0	24.5	32.6	32.6	
	Point 3	40.0	40.0	40.0	9.0	40.0	40.0	11.0	40.0	11.0	16.9	19.0	11.0	16.9	16.7	16.7	
	Point 4	40.0	40.0	40.0	5.5	40.0	40.0	7.3	40.0	7.3	11.3	11.0	7.3	11.3	10.0	10.0	
	Point 5	40.0	40.0	40.0	1.0	40.0	40.0	3.5	40.0	3.5	5.7	3.0	3.5	5.7	3.0	3.3	
	Point 6	40.0	40.0	40.0	0.0	40.0	40.0	0.0	40.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
DA (V) [Power shift output voltage]	Point 1	0.00	0.00	10.00	0.00	0.00	8.88	0.00	8.88	0.00	0.58	0.58	0.58	[0.580]	[0.580]	0.36	
	Point 2	0.00	0.00	8.55	0.00	0.00	5.65	0.00	5.65	0.00	2.82	2.75	2.75	[2.826]	[2.754]	[0.362]	
	Point 3	0.00	0.00	5.65	0.00	0.00	3.47	0.00	3.47	0.00	3.47	5.07	4.20	[4.203]	[4.203]	1.23	
	Point 4	0.00	0.00	4.20	0.00	0.00	2.75	0.00	2.75	0.00	2.75	6.05	5.65	[5.652]	[5.652]	[1.232]	
	Point 5	0.00	0.00	2.75	0.00	0.00	2.02	0.00	2.02	0.00	2.02	7.04	7.10	[7.043]	[7.101]	7.24	
	Point 6	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	8.04	10.00	[8.047]	[10.000]	7.81	

<Reference>

Pressure-reducing valve	None	None	None	Direct proportion	None	None	Direct proportion	None	Direct proportion	None	Inverse proportion	None	Inverse proportion	None	Inverse proportion
Current-pressure profile															

Maintenance No.53 Setting of N-Pz curve

Function

This enables to change Pz [Power shift pressure] of Pz-DA curve that shows relation between N [Engine speed] and Pz [Power shift pressure].

Also this enables to make initializing.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=53 with ##.

4) Press ENTER.

5) LCD1 N Point1 PZ1
& : next ## : other

LCD2 N [Engine speed] - Point 1 [****rpm]


LCD3 Pz [Power shift pressure] No.1 - Point 1 [***.*kgf/cm²]

LCD4 Pz [Power shift pressure] No.2 - Point 1 [***.*kgf/cm²]

LCD5 Blank

(When RETURN is pressed, go to the step 2.)

6) Press ## and select the setting item.



7) Press ENTER.

When selecting Pz [Power shift pressure] No.1- Point ? "N Point ? PZ1"

→ To 8-1)

When selecting Pz [Power shift pressure] No.2- Point ? "N Point ? PZ2"

→ To 8-2)

When selecting N-Pz curve initial "N-PZ initial"

→ To 8-3)

Pz [Power shift pressure] No.1- Point ?

8-1) LCD1 Select content with ##, and press &. Pz ? ***.*

LCD2 N [Engine speed] - Point ? [****rpm]

LCD3 Pz [Power shift pressure] No.1 - Point ? [***.*kgf/cm²] Blinks

LCD4 Pz [Power shift pressure] No.2 - Point ? [***.*kgf/cm²]

LCD5 Blank

(When RETURN is pressed, go to the step 5.)

9-1) Press ## and select the power shift pressure that read with watching the pressure gauge.

When stopping the setting, press RETURN before making the step 10-1). (Go to the step 5.)

10-1) Press ENTER.

11-1) Return to the step 5).

12-1) Make sure that the indication on LCD3 shows the power shift pressure selected.

13-1) Press RETURN.

14-1) Return to the step 2).

15-1) Place the maintenance key switch in "OFF" position.

Maintenance No.53 Setting of N-Pz curve

Pz [Power shift pressure] No.2- Point ?
 8-2) LCD1 Select content with ##, and press &.
 Pz ? ***.*

LCD2 N [Engine speed] - Point ? [****rpm]
 LCD3 Pz [Power shift pressure] No.1 - Point ? [***.*kgf/cm²]
 LCD4 Pz [Power shift pressure] No.2 - Point ? [***.*kgf/cm²] Blinks
 LCD5 Blank

(When RETURN is pressed, go to the step 5).)

9-2) Press ## and select the power shift pressure that read with watching the pressure gauge.
 When stopping the setting, press RETURN before making the step 10-2). (Go to the step 5).)

- 10-2) Press ENTER.
- 11-2) Return to the step 5).
- 12-2) Make sure that the indication on LCD4 shows the power shift pressure selected.
- 13-2) Press RETURN.
- 14-2) Return to the step 2).
- 15-2) Place the maintenance key switch in "OFF" position.

N-Pz curve initial
 8-3) LCD1 Select content with ##, and press &.

LCD2 to LCD3 -----
 LCD4 to LCD5 Blank
 (When RETURN is pressed, go to the step 5).)

- 9-3) Press ## and select 5353.
- 10-3) Press ENTER.
 LCD2 to LCD3 ----- → HHHH → -----
- 11-3) Press RETURN.
- 12-3) Return to the step 5).
- 13-3) Press RETURN.
- 14-3) Return to the step 2).
- 15-3) Place the maintenance key switch in "OFF" position.

Initial value

Refer to the table.

Setable value

0.0kgf/cm² ≤ Pz [Power shift pressure] ≤ 50.0kgf/cm²

Maintenance No.53 Setting of N-Pz curve - Table

LS-108H5		LS-138H5		LS-218H5		LS-238H5		LS-248H5		LS-348H5	
Tier2	Tier3	Tier2	Tier3	Tier2	Tier3	Tier2	Tier3	Tier2	Tier3	Tier2	Tier3
N (rpm) [Engine speed]		From LS138-4264									
Point 1	600	600	600	600	600	700	600	700	600	600	600
Point 2	800	800	800	800	800	900	800	900	800	800	800
Point 3	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
Point 4	1200	1200	1100	1200	1200	1100	1200	1100	1100	1100	1200
Point 5	1400	1400	1400	1400	1400	1200	1400	1200	1400	1200	1400
Point 6	1600	1600	1600	1600	1600	1300	1600	1300	1500	1300	1600
Point 7	1800	1800	1800	1800	1800	1400	1800	1400	1600	1400	1800
Point 8	2000	2000	2000	1500	2000	2000	1500	2000	1500	1700	1600
Point 9	2200	2200	2200	1600	2200	1600	2200	1600	1800	1800	2200
Point 10	2400	2400	2400	2400	2400	2400	2400	2400	2000	2000	2400
Point 11	40.0	40.0	40.0	[40.00]	[40.00]	40.0	40.0	32.9	40.0	29.8	7.1
Point 12	[40.00]	[40.00]	[40.00]	[26.29]	[40.00]	[40.00]	[40.00]	[32.90]	[40.00]	[21.28]	[7.10]
Point 13	40.0	40.0	40.0	[40.00]	[24.81]	[40.00]	[40.00]	[23.33]	[40.00]	[21.28]	[12.71]
Point 14	40.0	40.0	40.0	[40.00]	[15.28]	[40.00]	[40.00]	[18.6]	[40.0]	[17.0]	[3.1]
Point 15	40.0	40.0	40.0	[40.00]	[11.08]	[40.00]	[40.00]	[14.9]	[40.0]	[13.7]	[0.0]
Point 16	40.0	40.0	40.0	[40.00]	[7.62]	[40.00]	[40.00]	[14.95]	[40.00]	[13.70]	[0.0]
Point 17	40.0	40.0	40.0	[40.00]	[3.97]	[40.00]	[40.00]	[7.31]	[40.00]	[3.35]	[0.0]
Point 18	40.0	40.0	40.0	[40.00]	[0.68]	[40.00]	[40.00]	[3.6]	[40.0]	[0.0]	[0.0]
Point 19	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 20	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 21	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 22	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 23	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 24	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 25	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 26	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 27	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 28	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 29	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
Point 30	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.0]	[0.0]	[0.0]
No.2											
For w/ Rack sensor <Abnormal>											
For w/o Rack sensor											
Point 1	40.0	40.0	40.0	[40.00]	[26.29]	[40.00]	[40.00]	[32.9]	[40.0]	[29.8]	[35.1]
Point 2	40.0	40.0	40.0	[40.00]	[24.81]	[40.00]	[40.00]	[23.3]	[40.00]	[21.28]	[24.40]
Point 3	[40.00]	[40.00]	[40.00]	[15.28]	[40.00]	[40.00]	[40.00]	[18.6]	[40.0]	[17.0]	[14.5]
Point 4	40.0	40.0	40.0	[40.00]	[11.08]	[40.00]	[40.00]	[14.9]	[40.0]	[13.7]	[5.5]
Point 5	40.0	40.0	40.0	[40.00]	[7.62]	[40.00]	[40.00]	[11.0]	[40.0]	[10.0]	[3.5]
Point 6	40.0	40.0	40.0	[40.00]	[3.97]	[40.00]	[40.00]	[7.3]	[40.0]	[6.6]	[3.0]
Point 7	40.0	40.0	40.0	[40.00]	[0.68]	[40.00]	[40.00]	[3.97]	[40.00]	[6.67]	[3.0]
Point 8	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.00]	[0.0]	[0.0]
Point 9	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.00]	[0.0]	[0.0]
Point 10	40.0	40.0	40.0	[40.00]	[0.0]	[40.00]	[40.00]	[0.0]	[40.00]	[0.0]	[0.0]

Maintenance No.54 Setting of management time

Function

This enables to change the hour meter and the LMI power ON time.

Setting procedures ## : Δ▽ & : ←→

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.

Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=54 with ##.

4) Press ENTER.

5) LCD1 54: Hour meter

& : next ## : other

LCD2 Hour meter (Place of 10000)

LCD3 Hour meter (Place of 1 to 1000)

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

► 54: Hour meter Setting of hour meter



► 54: Power ON Setting of LMI power ON time

7) Press ENTER.

When selecting setting of hour meter "54: Hour meter" → To 8-1)

When selecting setting of LMI power ON time "54: Power ON" → To 8-2)

Setting of hour meter

8-1) LCD1 Select content with ##, and press &.

LCD2 Hour meter (Place of 10000)

LCD3 Hour meter (Place of 1 to 1000)

LCD4 to LCD5 Blank

9-1) Press ## and set the hour meter.

When stopping the setting, press RETURN before making the step 10-1). (Go to the step 5).)

10-1) Press ENTER.

11-1) Return to the step 5).

12-1) Press RETURN.

13-1) Return to the step 2).

14-1) Place the maintenance key switch in "OFF" position.

Maintenance No.54 Setting of management time

Setting of LMI power ON time

8-2) LCD1 Select content with ##, and press &.

LCD2 LMI power ON time (Place of 10000)
LCD3 LMI power ON time (Place of 1 to 1000)
LCD4 to LCD5 Blank

9-2) Press ## and set the LMI power ON time.

When stopping the setting, press RETURN before making the step 10-2). (Go to the step 5).)

10-2) Press ENTER.

11-2) Return to the step 5).

12-2) Press RETURN.

13-2) Return to the step 2).

14-2) Place the maintenance key switch in "OFF" position.

Initial value

0 hour

<<Caution>>

These times are not initialized by Maintenance No.9 (Setting of initial value) - "1.All initial".

Hour meter is initialized by Maintenance No.9 (Setting of initial value) - "23.Hour meter initial".

LMI Power ON time is initialized by Maintenance No.9 (Setting of initial value) - "24.LMI Power ON time initial".

Setable value

0hour ≤ Hour meter ≤ 49999hours

0hour ≤ LMI Power ON time ≤ 49999hours

Maintenance No.55 Setting of boom protection device auto stop judgement time

Function

This enables to change the boom protection device auto stop judgement time.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.

Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=55 with ##.

4) Press ENTER.

5) LCD1 55: Judge time
Press &.

LCD2 Boom protection device auto stop judgement time [seconds]

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
**.*[sec]

LCD2 Blanks

8) Press ## and select the judgement time.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 shows the judgement time selected.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

0.25seconds [5]

Setable value

0.00second [0] ≤ Boom protection device auto stop judgement time ≤ 10.00seconds [200]

The setting is every 0.05 seconds.

Maintenance No.58 Setting of rigging mode selection

Function

This enables to change the rigging mode selection.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.

Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=58 with ##.

4) Press ENTER.

5) LCD1 Rigging mode 1


& : next ## : other

LCD2 Rigging mode

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.



7) Press ENTER.

8) LCD1 Select content with ##, and press &.

*

9) Press ## and select the value.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

10) Press ENTER.

11) Return to the step 5).

12) Make sure that the indication on LCD2 shows a value selected.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

Rigging mode 1 : Present

Crane set mode 1 : Present

Luffing set mode 2 : Present

Setable value

Rigging mode 0 : None 1 : Present

Crane set mode 0 : None 1 : Present

Luffing set mode 0 : None 2 : Present

Maintenance No.59 Setting of control selection

Function

This enables to change "Present" or "None" for corresponding to various controls & functions.
Also this enables to make initializing.

Setting procedures ## : Δ▽ & : ←→

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=59 with ##.

4) Press ENTER.

5) LCD1 Control select 1
& : next ## : other

LCD2 Setting Value

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item. (Refer to the table.)

7) Press ENTER.

When selecting "Control select??".

→ To 8-1)

When selecting "Pressure - 3.Fixed power shift pressure".

→ To 8-2)

When selecting "Initialize - 19.Initialize".

→ To 8-3)

Control select??

8-1) LCD1 Select content with ##, and press &.
@

LCD2 Setting Value Blinks

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

9-1) Press ## and select setting value.

10-1) Press ENTER.

11-1) Make sure that the indication on LCD2 shows value selected.

12-1) Return to the step 5).

13-1) Press RETURN.

14-1) Return to the step 2).

15-1) Place the maintenance key switch in "OFF" position.

Pressure - 3.Fixed power shift pressure

8-2) LCD1 Select content with ##, and press &.
@@@,@

LCD2 Setting Value - Fixed power shift pressure

(kgf/cm²) Blinks

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

9-2) Press ## and select setting value.

10-2) Press ENTER.

11-2) Make sure that the indication on LCD2 shows value selected.

12-2) Return to the step 5).

13-2) Press RETURN.

14-2) Return to the step 2).

15-2) Place the maintenance key switch in "OFF" position.

Maintenance No.59 Setting of control selection

Initialize - 19.Initial
8-3) LCD1 Select content with ##, and press &
@@@@

LCD2 to LCD5 Blank
(When RETURN is pressed, go to the step 2).)

- 9-3) Press ## and set 5959.
- 10-3) Press ENTER.
LCD2 to LCD3 Blank → HHHH → Blank
- 11-3) Return to the step 5).
- 12-3) Press RETURN.
- 13-3) Return to the step 2).
- 14-3) Place the maintenance key switch in "OFF" position.

Initial value

Refer to the table.

Setable value

Refer to the table.

Maintenance No.59 Setting of control selection - Table

LCD1	Setting item	Setable value	Initial value					
			LS-108H5 Tier2	LS-138H5 Tier3	LS-218H5 Tier2	LS-238H5 Tier3	LS-248H5 Tier2	LS-248H5 Tier3
Control select 1	1.Power shift control	0 : None 1 : Present - Tier2 I-Pz Inverse proportion	0	/	0	0	0	0
		2 : Present - Tier2 I-Pz Direct proportion	0	0	2 From LS138-4264	4	0	4
		3 : Present - Tier3 I-Pz Inverse proportion						
		4 : Present - Tier3 I-Pz Direct proportion						
Control select 2	2.Fixed power shift control	0 : None 1 : Present	0	0	0	0	0	0
		0.0kgf/cm ² ≤ 40.0kgf/cm ²	40.0	40.0	40.0	40.0	40.0	40.0
Pressure	3.Fixed power shift pressure	0 : None 1 : Present	0	0	0	0	0	0
Control select 3	4.Pump control	0 : None 1 : Present	0	0	0	0	0	0
Control select 5	6.Winch motor control	0 : None 1 : Present	0	0	0	0	0	0
Control select 6	7.Throttle motor control	0 : None 1 : Present	0	0	0	0	0	0
Control select 7	8.Foot pedal throttle control	0 : None 1 : Present	0	1	0	0	1	1
Control select10	11.Boom protection device	0 : None 1 : Present	1	1	1	1	1	1
Control select11	12.Slowdown device	0 : None 1 : Present	0	0	0	0	0	1
Control select12	13.Rigging mode	0 : None 1 : Present - Other models 3 : Present - LS-348H5 4 : Present - LS-248H5	1	1	1	1	4	3
Control select13	14.Anti-two block limit	0 : None 1 : Present	0	0	0	0	0	0
Control select14	15.Anti-two block limit (slowdown)	0 : None 1 : Present	0	0	0	0	0	0
Control select15	16.Hook height indicator	0 : None 1 : Present	0	0	0	0	0	0
Control select17	18.High idle cut control	0 : None 1 : Present	0	0	0	0	0	1
Initialize	19.Initial	0 : None 1 : Present	---	---	---	---	---	---
Control select18	20.Engine speed display	0 : None 1 : Present	0	1	1	1	1	1
Control select19	21.Winch motor control (Switch control mode)	0 : None 1 : Present	0	0	0	0	0	1
Control select20	22.SiC control mode	0 : None 1 : Present	0	0	0	0	0	0
Control select21	23. ECU / ECM control	0 : None 1 : Present - Grip 2 : Present - Throttle volume	0	2	0	0	2	0
Control select22	24.Winch motor control (3rd speed)	0 : None 1 : Present	0	0	0	0	0	0

Maintenance No.60 A/D check

Function

This displays A/D signals.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=60 with ##.

4) Press ENTER.

5) LCD1 60: AD 0-3
: Select ch

LCD2 to LCD5 A/D conversion value (Refer to the followings)

6) Press ## and select the channel.

		Signal name <For LBCE Model>	Analogue circuit input signal	A/D conversion value
LCD1	60 : AD 0-3			
LCD2	ch 0	BOOM HOISTING ROPE TENSION	0 - 18mV	500 - 4500
LCD3	ch 1	JIB HOISTING ROPE TENSION	0 - 18mV	500 - 4500
LCD4	ch 2	BOOM ANGLE	-3.6 - 1.8V	500 - 4500
LCD5	ch 3	JIB ANGLE	-3.6 - 1.8V	500 - 4500
LCD1	60 : AD 4-7			
LCD2	ch 4	GRIP THROTTLE ROTATING ANG. THROTTLE VOLUME ROTATING ANG.	0 - 12V	0 - 4800
LCD3	ch 5	-----	0 - 12V	0 - 4800
LCD4	ch 6	THROTTLE MOTOR FEEDBACK	0 - 12V	0 - 4800
LCD5	ch 7	RACK SENSOR	0 - 5V	0 - 2500
LCD1	60 : AD 8-11			
LCD2	ch 8	FRONT DRUM ROPE TENSION [RADIO LOAD CELL]	0 - 5V	0 - 2500
LCD3	ch 9	REAR/3RD DRUM ROPE TENSION [RADIO LOAD CELL]	0 - 5V	0 - 2500
LCD4	ch 10	JIB ANGLE FOR RIGGING MODE [RELATIVE ANGLE]	0 - 12V	0 - 4800
LCD5	ch 11	FOOT THROTTLE	0 - 12V	0 - 4800
LCD1	60 : AD 12-15			
LCD2	ch 12	-----	0 - 12V	0 - 4800
LCD3	ch 13	-----	0 - 12V	0 - 4800
LCD4	ch 14	MAINTENANCE MODE SW	0 - 12V	0 - 4800
LCD5	ch 15	SENSOR POWER SUPPLY E-25 Sensor power supply error "A/D conversion value<3510" or "A/D conversion value≥3814"	-----	3662

7) Press RETURN.

8) Return to the step 2).

9) Place the maintenance key switch in "OFF" position.

Maintenance No.61 D/I check

Function

This displays the condition of D/I signals.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank



3) Set the Mainte No.=61 with ##.

4) Press ENTER.

5) LCD1 61: DI 0- 7
: Select ch

LCD2 to LCD5 Condition of D/I signals (Refer to the followings)

6) Press ## and select the channel.



Signal name <For LBCE Model>

LCD1 61 : DI 0- 7

ch 0 WINCH OPERATION MODE SW
ch 1 FRONT MOTOR HI SPEED SW
ch 2 -----
ch 3 -----
ch 4 -----
ch 5 THROTTLE FIXING SW
ch 6 REAR MOTOR HI SPEED SW
ch 7 RIGGING MODE SW

LCD1 61 : DI 8-15

ch 8 DIAG LAMP-1 RED
ch 9 BY-PASS CONNECTOR
ch 10 LMI OVERRIDE MODE SW
ch 11 LUFFER MODE DETECTION
ch 12 3rd/4th DRUM HOISTING DETECT
ch 13 INSPECTION MODE SW
ch 14 LUFFER BOOM ANGLE FIXING
ch 15 TRAVEL DETECTION PSW

LCD1 61 : DI 16-23

ch 16 FRONT DRUM HOISTING DETECT
ch 17 FRONT DRUM LOWERING DETECT
ch 18 VOICE ALARM ON-OFF
ch 19 3rd/4th DRUM LOWERING DETECT
ch 20 BOOM HOISTING DETECT
ch 21 BOOM LOWERING DETECT
ch 22 REAR DRUM HOISTING DETECT
ch 23 REAR DRUM LOWERING DETECT

LCD1 61 : DI 24-31

ch 24 BOOM HOIST LIMIT
ch 25 JIB HOIST LIMIT
ch 26 ANTI-TWO BLOCK
ch 27 FREEFALL ALARM
ch 28 PUMP CONTROL SW HIGH SPEED
ch 29 PILOT PRESS. DETECT
ch 30 FREE MODE ALARM
ch 31 -----

Maintenance No.61 D/I check

			Signal name <For LBCE Model>
LCD1	61 : DI	32-39	
LCD2	ch 33	ch 32	ch 32 VOICE ALARM ON-OFF
LCD3	ch 35	ch 34	ch 33 WORKING MODE SELECT
LCD4	ch 37	ch 36	ch 34 -----
LCD5	ch 39	ch 38	ch 35 OVERRIDE MASTER CONTROL KEY ch 36 PUMP CONTROL SW ULTRA-LOW SPEED ch 37 ----- ch 38 ----- ch 39 DRUM REVOLUTION DETECT. STOP
LCD1	61 : DIPSW 0-7		
LCD2	SW1	SW0	These switches are not used though equipped in SML-10.
LCD3	SW3	SW2	
LCD4	SW5	SW4	
LCD5	SW7	SW6	
LCD1	61 : DIPSW 8-15		
LCD2	SW9	SW8	These switches are not equipped in SML-10.
LCD3	SW11	SW10	
LCD4	SW13	SW12	
LCD5	SW15	SW14	

- 7) Press RETURN.
- 8) Return to the step 2).
- 9) Place the maintenance key switch in "OFF" position.

Maintenance No.62 Touch switch check

Function

This displays the condition of touch switch signals.

Setting procedures # : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank


3) Set the Mainte No.=62 with ##.

4) Press ENTER.

5) LCD1 62: Touch SW ??

LCD2 to LCD5 Blank

6) While the touch switch is pressed, the number is displayed on LCD1 and the LEDs are lit.



	Number	LED
27. LCD2 Select Switch (LCD3 Select Switch)	01	A
28. LCD4 Select Switch (LCD5 Select Switch)	04	A)
29. Hook Height Reset Switch	05	A
30. Setting Mode Start/End Switch	06	A)
31. Enter Switch	02	B
32. △Switch	08	B
33. ▽Switch	10	B
34. Return Switch	07	B
35. Hook Select Switch	09	B
36. Tip Height Limit Set/Delete Switch	11	A
37. Anti-two Block Limit Set/Delete Switch	13	A
38. Radius Limit Set/Delete Switch	14	A
39. Load Test Switch	15	A
40. Help Switch	16	A
		Return to the step 2).
		Help message is displayed on LCD1.

- 7) Press RETURN.
- 8) Return to the step 2).
- 9) Place the maintenance key switch in "OFF" position.

Maintenance No.63 Counter check

Function

This displays counter signals.

Setting procedures ## : Δ▽ & : ←↓

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.

Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=63 with ##.

4) Press ENTER.

5) LCD1

63: CNT

: Select

LCD2 to LCD4 Number of pulses (Refer to the followings)

LCD5 Blank

6) Press ## and select counter.

Single phase counter

Signal name <For LBCE Model>

LCD1	63 : CNT	
LCD2	ch 0	ENGINE REV.
LCD3	ch 1	-----
LCD4	ch 2	-----
LCD5	Blank	

Two phase counter

Signal name <For LBCE Model>

LCD1	63 : U/D CNT	
LCD2	ch 0	FRONT DRUM REVOLUTION <Not used>
LCD3	ch 1	REAR DRUM REVOLUTION <Not used>
LCD4	ch 2	-----
LCD5	Blank	

<Reference>

When pushing "Hook Height Reset Switch", the two phase counter are reset to "0 pulse".

7) Press RETURN.

8) Return to the step 2).

9) Place the maintenance key switch in "OFF" position.

Maintenance No.64 LCD & LED check

Function

This checks LCDs and LEDs.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)



2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=64 with ##.

4) Press ENTER.

5) LCD1 LCD2 to LCD5 LEDs



Blinks

- 6) Press RETURN.
- 7) Return to the step 2).
- 8) Place the maintenance key switch in "OFF" position.

Maintenance No.65 D/O check

Function

This enables to output D/O signals.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 [Select content with ##, and press &. Mainte No.= 0]

LCD2 to LCD5 Blank

3) Set the Mainte No.=65 with ##.

4) Press ENTER.

5) LCD1 [65: D/O & : Output
: Select ch ??]

LCD2 Condition of D/O signal oFF ↔ on

LCD3 to LCD5 Blank

6) Press ## and select the channel.

Signal name <For LBCE Model>

ch 00	OVERLOAD LIMIT
ch 01	BOOM HOISTING LIMIT
ch 02	BOOM LOWERING LIMIT
ch 03	JIB HOISTING LIMIT
ch 04	JIB LOWERING LIMIT
ch 05	ANTI-TWO BLOCK LIMIT
ch 06	BOOM PROTECTION
ch 07	LMI OVERRIDE MODE

ch 08	-----
ch 09	-----

ch 10	RED ROTATING LAMP
ch 11	YELLOW ROTATING LAMP
ch 12	LIMIT STOP RELEASE
ch 13	THROTTLE UP
ch 14	THROTTLE DOWN
ch 15	OVERLOAD LIMIT

ch 16	OFFSET ANGLE LIMIT
ch 17	JIB ANGLE LIMIT
ch 18	OFFSET ANGLE LIMIT
ch 19	BRINK SIGNAL
ch 20	LMI OVERRIDE MODE
ch 21	TIMER SIGNAL
ch 22	LUFFER TOP LIFTING
ch 23	-----

ch 24	BUZZER in SML-10
-------	------------------

7) While ENTER is pressed, D/O signal of the selected channel is output, and "on" is displayed on LCD2.

8) Press RETURN.

9) Return to the step 2).

10) Place the maintenance key switch in "OFF" position.

Maintenance No.66 Voice alarm check

Function

This enables to output the voice alarm.

Setting procedures ## : Δ▽ & : ↲

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=66 with ##.

4) Press ENTER.

5) LCD1 66: V/O & : Output
: Select ch ??

LCD2 Condition of the voice alarm off ↔ on

LCD3 to LCD5 Blank

6) Press ## and select the channel.

Voice alarm ROM [IC52] <CXR0659 Ver0.0>

ch 00 Overload Limit
ch 01 Approaching Limit
ch 02 Boomhoist Limit
ch 03 Jibhoist Limit
ch 04 Boom Lower Limit
ch 05 Jib Lower Limit
ch 06 Two-block Limit
ch 07 Free mode activated

ch 08 Freefall
ch 09 Height Limit Set
ch 10 Radius Limit Set
ch 11 Luffing attachment protection activated
ch 12 Boom protection activated
ch 13 Hydraulic control pressure reduced
ch 14 Override
ch 15 Rigging Mode

7) While ENTER is pressed, the voice alarm of the selected channel is output, and "on" is displayed on LCD2.

8) Press RETURN.

9) Return to the step 2).

10) Place the maintenance key switch in "OFF" position.

Maintenance No.67 D/A check

Function

This enables to output D/A signals.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.

Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=67 with #.

4) Press ENTER.

5) LCD1 67: D/A ## : Select ch → Press &
?ch **.*v

ch : Blinks

LCD2 D/A channel

LCD3 Output voltage

[**.*V]

LCD4 Condition of D/A signal

oFF

LCD5 Blank

6) Press ## and select the channel.

Signal name <For LBCE Model>	
ch 0	POWER SHIFT CONTROL
ch 1	MAIN PUMP CONTROL
ch 2	----
ch 3	FRONT MOTOR CONTROL
ch 4	REAR MOTOR CONTROL
ch 5	----
ch 6	----
ch 7	ENGINE THROTTLE

7) Press ENTER.

8) LCD1 67: D/A ## : Set voltage → Press &
?ch \$\$. \$\$v

v : Blinks

LCD2 D/A channel selected at the step 6)

LCD3 Output voltage

[**.*V]

LCD4 Condition of D/A signal

oFF

LCD5 Blank

9) Press ## and set the output voltage.

10) Press ENTER.

11) LCD1 67: D/A & : Output
?ch \$\$. \$\$v

LCD2 D/A channel selected at the step 6)

LCD3 Output voltage set at the step 9)

[**.*V]

LCD4 Condition of D/A signal

oFF ↶ on

LCD5 Blank

12) While ENTER is pressed, the set output voltage of the selected channel is output, and "on" is displayed on LCD4.

13) When changing the output voltage → Press RETURN once. (To the step 8).
When changing the channel → Press RETURN twice. (To the step 5.).

14) Press RETURN three times.

15) Return to the step 2).

16) Place the maintenance key switch in "OFF" position.

<Reference>

D/A 8bits 0V - 10V

0 - 255

Resolution 39mV/bit

Maintenance No.68 Communication check (RS232C)

Function

This is to check communication RS232C.

Preparation

It prepares so that the transferring data can be received.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=68 with ##.

4) Press ENTER.

5) LCD1 68: RS232C check
Press &.

LCD2 to LCD5 Blank

6) Press ENTER.

7) LCD1 RS232C READY
&.: start

LCD2 to LCD5 Blank

8) Press ENTER.

9) LCD1 RS232C checking
RETURN : stop

LCD2 Transferring data counts (Transferring data : 55H)

LCD3 Receiving data counts (Recieving data : 55H)

LCD4 Transferring data counts (Transferring data : AAH)

LCD5 Receiving data counts (Recieving data : AAH)

<Reference>

The transferring and the receiving of 55H and AAH are executed 5000 times respectively.

When the transferring and the receiving are finished, the count of the data correctly received are displayed.

10) When data are correctly received

→ LCD1 RS232C check end
Press &.

LCD2 5000
LCD3 5000
LCD4 5000
LCD5 5000

When data are not correctly received

→ LCD1 RS232C error
Press &.

LCD2 5000
LCD3 ???
LCD4 5000
LCD5 ???

11) Press ENTER.

12) Return to the step 5).

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Maintenance No.69 Communication check (RS485)

Function

This is to check communication RS485.

Preparation

It prepares so that the transferring data can be received.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=69 with ##.

4) Press ENTER.

5) LCD1 69: RS485 check
Press &.

LCD2 to LCD5 Blank

6) Press ENTER.

7) LCD1 RS485 READY
&.: start

LCD2 to LCD5 Blank

8) Press ENTER.

9) LCD1 RS485 checking
RETURN : stop

LCD2 Transferring data counts (Transferring data : 55H)

LCD3 Receiving data counts (Receiving data : 55H)

LCD4 Transferring data counts (Transferring data : AAH)

LCD5 Receiving data counts (Receiving data : AAH)

<Reference>

The transferring and the receiving of 55H and AAH are executed 5000 times respectively.

When the transferring and the receiving are finished, the count of the data correctly received are displayed.

10) When data are correctly received

→ LCD1 RS485 check end
Press &.

LCD2 5000
LCD3 5000
LCD4 5000
LCD5 5000

When data are not correctly received

→ LCD1 RS485 error
Press &.

LCD2 5000
LCD3 ???
LCD4 5000
LCD5 ???

11) Press ENTER.

12) Return to the step 5).

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Maintenance No.70 Display of load history

Function

This displays load history.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=70 with ##.

4) Press ENTER.

5) LCD1 70: Load history
Press &.

LCD2 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &
? !!!!!!!

LCD2 to LCD5 Blank

(When RETURN is pressed, go to the step 5).)

? !!!!!!!

1 Overload count

2 Maximum ratio

3 Maximum load

4 Load frequency

5 Every one hour

8) Press ## and select content.

9) Press ENTER and decide content.

10) LCD1 Select content with ##, and press &
?% @@@@@@@@

LCD2 to LCD5 Blank

(When RETURN is pressed, go to the step 7).)

? % @@ @@@@ @@@@

C Crane (Crane [Normal mode])

B Override (Crane [LMI override mode])

L Luffing (Luffing)

A ASw/ j (Auxiliary sheaves with jib)

a ASw/o j (Auxiliary sheaves without jib)

M Midfall (Midfall)

11) Press ## and select content.

12) Press ENTER and decide content.

13) LCD1 Select indication with ##.
?% \$\$\$\$

\$\$\$\$: Displayed values differ from the display content
to the display content.

LCD2 to LCD5 Refer to the following pages

(When RETURN is pressed, go to the step 10).)

14) Press ## and select No.(\$\$\$\$).

15) Record the value displayed on LCD2 to LCD5.

16) Press RETURN.

17) Return to the step 10).

18) Press RETURN.

19) Return to the step 7).

20) Press RETURN.

21) Return to the step 5).

22) Press RETURN.

23) Return to the step 2).

24) Place the maintenance key switch in "OFF" position.

Maintenance No.70 Display of load history

1. Overload count

LCD1 lower column display ?%
 1C : Crane [Normal mode]
 1B : Crane [LMI override mode]
 1L : Luffing
 1A : Auxiliary sheaves with jib
 1a : Auxiliary sheaves without jib
 1M : Midfall

\$\$\$\$	Mode	Performance	Display data
0000	Work mode	Present	Overload count
0001			Occurred date / time
0002		Extrapolation	Overload count
0003			Occurred date / time
0004		None	Overload count
0005			Occurred date / time
0006	Setting mode	Present	Overload count
0007			Occurred date / time
0008		Extrapolation	Overload count
0009			Occurred date / time
0010		None	Overload count
0011			Occurred date / time
0012	Inspection mode	Present	Overload count
0013			Occurred date / time
0014		Extrapolation	Overload count
0015			Occurred date / time
0016		None	Overload count
0017			Occurred date / time
0018	Rigging mode	Present	Overload count
0019			Occurred date / time
0020		Extrapolation	Overload count
0021			Occurred date / time
0022		None	Overload count
0023			Occurred date / time

Select indication with ##.
 1% \$\$\$\$

1
 2345
 6789 Overload count
 ex) 123456789 times
 (Maximum = 4294967294 times)

Select indication with ##.
 1% \$\$\$\$

2003 Year
 5. 8 Month and date
 THU A day of the week
 19:05 Time
 ex) 19:05 May 8, 2003 (Tursday)

<Reference>
 When data are not recorded.

2000
0.0
SUN
00:00

Maintenance No.70 Display of load history

2.Maximum ratio

LCD1 lower column display ?%

- 2C : Crane [Normal mode]
- 2B : Crane [LMI override mode]
- 2L : Luffing
- 2A : Auxiliary sheaves with jib
- 2a : Auxiliary sheaves without jib
- 2M : Midfall

\$\$\$\$	Mode	Perfomance	Display data
0000	Work mode	Present	Boom length, Boom hook reeving, Jib length With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight Curve number, Load ratio, Actual load, Rated load Boom angle, Jib angle Radius, Hook selected condition, Drum selected condition Tip height limit setting condition & setting height Radius limit setting condition & setting radius Occurred date / time
0001			
0002			
0003			
0004			
0005			
0006			
0007			
0008			
0010			
0011	Extrapolation	Extrapolation	Boom length, Boom hook reeving, Jib length With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight Curve number, Load ratio, Actual load, Rated load Boom angle, Jib angle Radius, Hook selected condition, Drum selected condition Tip height limit setting condition & setting height Radius limit setting condition & setting radius Occurred date / time
0012			
0013			
0014			
0015			
0016			
0017			
0018			
0020	Setting mode	Present	Boom length, Boom hook reeving, Jib length With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight Curve number, Load ratio, Actual load, Rated load Boom angle, Jib angle Radius, Hook selected condition, Drum selected condition Tip height limit setting condition & setting height Radius limit setting condition & setting radius Occurred date / time
0021			
0022			
0023			
0024			
0025			
0026			
0027			
0028			
0030	Extrapolation	Extrapolation	Boom length, Boom hook reeving, Jib length With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight Curve number, Load ratio, Actual load, Rated load Boom angle, Jib angle Radius, Hook selected condition, Drum selected condition Tip height limit setting condition & setting height Radius limit setting condition & setting radius Occurred date / time
0031			
0032			
0033			
0034			
0035			
0036			
0037			
0038			

Maintenance No.70 Display of load history management data

\$\$\$\$	Mode	Performance	Display data
0040	Inspection mode	Present	Boom length, Boom hook reeving, Jib length
0041			With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib
0042			Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight
0043			Curve number, Load ratio, Actual load, Rated load
0044			Boom angle, Jib angle
0045			Radius, Hook selected condition, Drum selected condition
0046			Tip height limit setting condition & setting height
0047			Radius limit setting condition & setting radius
0048			Occurred date / time
0050			Boom length, Boom hook reeving, Jib length
0051	Extrapolation		With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib
0052			Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight
0053			Curve number, Load ratio, Actual load, Rated load
0054			Boom angle, Jib angle
0055			Radius, Hook selected condition, Drum selected condition
0056			Tip height limit setting condition & setting height
0057			Radius limit setting condition & setting radius
0058			Occurred date / time
0060	Rigging mode	Present	Boom length, Boom hook reeving, Jib length
0061			With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib
0062			Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight
0063			Curve number, Load ratio, Actual load, Rated load
0064			Boom angle, Jib angle
0065			Radius, Hook selected condition, Drum selected condition
0066			Tip height limit setting condition & setting height
0067			Radius limit setting condition & setting radius
0068			Occurred date / time
0070	Extrapolation		Boom length, Boom hook reeving, Jib length
0071			With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib
0072			Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight
0073			Curve number, Load ratio, Actual load, Rated load
0074			Boom angle, Jib angle
0075			Radius, Hook selected condition, Drum selected condition
0076			Tip height limit setting condition & setting height
0077			Radius limit setting condition & setting radius
0078			Occurred date / time

Maintenance No.70 Display of load history management data

Select indication with ##.
2% \$\$\$0

18.0	Boom length
14	Boom hook reeving
0.0	Jib length

ex) Boom length 18.0(m)
Boom hook reeving 14(reevings)
Jib length 0.0(m)

Select indication with ##.
2% \$\$\$1

0	With or without midfall extension
0.0	Jib offset
1	Jib hook reeving
0	With or without fixed jib

ex) With or without midfall extensor 0 "without" (1 "with")
Jib offset 0.0(deg)
Jib hook reeving 1(reeving)
With or without fixed jib 0 "without" (1 "with")

Select indication with ##.
2% \$\$S2

0.00	Midfall hook weight
6.12	Boom hook weight
0.52	Jib hook weight
0.00	Fixed jib hook weight

ex) Midfall hook weight 0.00(t)
Boom hook weight 6.12(t)
Jib hook weight 0.52(t)
Fixed jib hook weight 0.00(t)

Select indication with ##.
2% \$\$S3

2	Curve number
110.0	Load ratio
123.0	Actual load
112.0	Rated load

ex) Curve number 2
Load ratio 110.0(%)
Actual load 123.0(t)
Rated load 112.0(t)

Select indication with ##.
2% \$\$S4

75.0	Boom angle
0.0	Jib angle

ex) Boom angle 75.0(deg)
Jib angle 0.0(deg)
<Reference>
"Crane" and "Auxiliary sheaves without jib"
→ Jib angle = 0.0(deg)

Select indication with ##.
2% \$\$S5

12.3	Radius
0	Hook selected condition
[F]	Drum selected condition

ex) Radius 12.3(m)
Hook selected condition
0 "Boom hook" (1 "Jib hook" / 2 "Fixed jib hook")
(3 "Midfall hook")
Drum selected condition
[F] "Front drum" ([R] "Rear drum" / [3] "3rd drum")
<Reference>
Drum selected condition is blank
when data are not recorded.

Select indication with ##.
2% \$\$S6

1	Tip height limit setting condition
13.0	Tip height limit setting height

ex) Tip height limit setting condition
1 "Performed" (0 "Not performed")
Tip height limit setting height
13.0(m) "Performed" (- - - (m) "Not performed")

Select indication with ##.
2% \$\$S7

1	Radius limit setting condition
14.0	Radius limit setting height

ex) Radius limit setting condition
1 "Performed" (0 "Not performed")
Radius limit setting height
14.0(m) "Performed" (- - - (m) "Not performed")

Select indication with ##.
2% \$\$S8

2003	Year
5.8	Month and date
THU	A day of the week
19:05	Time

<Reference>
When data are not recorded.

ex) 19:05 May 8, 2003 (Tursday)

Maintenance No.70 Display of load history

3. Maximum load

LCD1 lower column display ?%
 3C : Crane [Normal mode]
 3B : Crane [LMI override mode]
 3L : Luffing
 3A : Auxiliary sheaves with jib
 3a : Auxiliary sheaves without jib
 3M : Midfall

\$\$\$\$	Mode	Performance	Display data
0000	Work mode	Present	Boom length, Boom hook reeving, Jib length
0001			With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib
0002			Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight
0003			Curve number, Load ratio, Actual load, Rated load
0004			Boom angle, Jib angle
0005			Radius, Hook selected condition, Drum selected condition
0006			Tip height limit setting condition & setting height
0007			Radius limit setting condition & setting radius
0008			Occurred date / time
0010		Extrapolation	Boom length, Boom hook reeving, Jib length
0011			With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib
0012			Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight
0013			Curve number, Load ratio, Actual load, Rated load
0014			Boom angle, Jib angle
0015			Radius, Hook selected condition, Drum selected condition
0016			Tip height limit setting condition & setting height
0017			Radius limit setting condition & setting radius
0018			Occurred date / time
0020	Setting mode	Present	Boom length, Boom hook reeving, Jib length
0021			With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib
0022			Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight
0023			Curve number, Load ratio, Actual load, Rated load
0024			Boom angle, Jib angle
0025			Radius, Hook selected condition, Drum selected condition
0026			Tip height limit setting condition & setting height
0027			Radius limit setting condition & setting radius
0028			Occurred date / time
0030		Extrapolation	Boom length, Boom hook reeving, Jib length
0031			With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib
0032			Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight
0033			Curve number, Load ratio, Actual load, Rated load
0034			Boom angle, Jib angle
0035			Radius, Hook selected condition, Drum selected condition
0036			Tip height limit setting condition & setting height
0037			Radius limit setting condition & setting radius
0038			Occurred date / time

Maintenance No.70 Display of load history management data

\$\$\$\$	Mode	Perfomance	Display data
0040	Inspection mode	Present	Boom length, Boom hook reeving, Jib length With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight Curve number, Load ratio, Actual load, Rated load Boom angle, Jib angle Radius, Hook selected condition, Drum selected condition Tip height limit setting condition & setting height Radius limit setting condition & setting radius Occurred date / time
0041			
0042			
0043			
0044			
0045			
0046			
0047			
0048			
0050	Extrapolation		Boom length, Boom hook reeving, Jib length With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight Curve number, Load ratio, Actual load, Rated load Boom angle, Jib angle Radius, Hook selected condition, Drum selected condition Tip height limit setting condition & setting height Radius limit setting condition & setting radius Occurred date / time
0051			
0052			
0053			
0054			
0055			
0056			
0057			
0058			
0060	Rigging mode	Present	Boom length, Boom hook reeving, Jib length With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight Curve number, Load ratio, Actual load, Rated load Boom angle, Jib angle Radius, Hook selected condition, Drum selected condition Tip height limit setting condition & setting height Radius limit setting condition & setting radius Occurred date / time
0061			
0062			
0063			
0064			
0065			
0066			
0067			
0068			
0070	Extrapolation		Boom length, Boom hook reeving, Jib length With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight Curve number, Load ratio, Actual load, Rated load Boom angle, Jib angle Radius, Hook selected condition, Drum selected condition Tip height limit setting condition & setting height Radius limit setting condition & setting radius Occurred date / time
0071			
0072			
0073			
0074			
0075			
0076			
0077			
0078			

Maintenance No.70 Display of load history management data

Select indication with ##.
3% \$\$\$0

18.0	Boom length
14	Boom hook reeving
0.0	Jib length

ex) Boom length 18.0(m)
Boom hook reeving 14(reevings)
Jib length 0.0(m)

Select indication with ##.
3% \$\$\$1

0	With or without midfall extension
0.0	Jib offset
1	Jib hook reeving
0	With or without fixed jib

ex) With or without midfall extensor 0 "without" (1 "with")
Jib offset 0.0(deg)
Jib hook reeving 1(reeving)
With or without fixed jib 0 "without" (1 "with")

Select indication with ##.
3% \$\$\$2

0.00	Midfall hook weight
6.12	Boom hook weight
0.52	Jib hook weight
0.00	Fixed jib hook weight

ex) Midfall hook weight 0.00(t)
Boom hook weight 6.12(t)
Jib hook weight 0.52(t)
Fixed jib hook weight 0.00(t)

Select indication with ##.
3% \$\$\$3

2	Curve number
110.0	Load ratio
123.0	Actual load
112.0	Rated load

ex) Curve number 2
Load ratio 110.0(%)
Actual load 123.0(t)
Rated load 112.0(t)

Select indication with ##.
3% \$\$\$4

75.0	Boom angle
0.0	Jib angle

ex) Boom angle 75.0(deg)
Jib angle 0.0(deg)
<Reference>
"Crane" and "Auxiliary sheaves without jib"
→ Jib angle = 0.0(deg)

Select indication with ##.
3% \$\$\$5

12.3	Radius
0	Hook selected condition
[F]	Drum selected condition

ex) Radius 12.3(m)
Hook selected condition
0 "Boom hook" (1 "Jib hook" / 2 "Fixed jib hook")
(3 "Midfall hook")
Drum selected condition
[F] "Front drum" ([R] "Rear drum" / [3] "3rd drum")
<Reference>
Drum selected condition is blank
when data are not recorded.

Select indication with ##.
3% \$\$\$6

1	Tip height limit setting condition
13.0	Tip height limit setting height

ex) Tip height limit setting condition
1 "Performed" (0 "Not performed")
Tip height limit setting height
13.0(m) "Performed" (---(m) "Not performed")

Select indication with ##.
3% \$\$\$7

1	Radius limit setting condition
14.0	Radius limit setting height

ex) Radius limit setting condition
1 "Performed" (0 "Not performed")
Radius limit setting height
14.0(m) "Performed" (---(m) "Not performed")

Select indication with ##.
3% \$\$\$8

2003	Year
5.8	Month and date
THU	A day of the week
19:05	Time

<Reference>
When data are not recorded.

2000
0.0
SUN
00:00

ex) 19:05 May 8, 2003 (Tursday)

Maintenance No.70 Display of load history

4.Load frequency

LCD1 lower column display ?%
 4C : Crane [Normal mode]
 4B : Crane [LMI override mode]
 4L : Luffing
 4A : Auxiliary sheaves with jib
 4a : Auxiliary sheaves without jib
 4M : Midfall

\$\$\$\$	Mode	Perfomance	Display data
0000	Work mode	Present & Extrapolation	0% ≤ < 30% Frequency
0001			30% ≤ < 50% Frequency
0002			50% ≤ < 70% Frequency
0003			70% ≤ < 90% Frequency
0004			90% ≤ < 110% Frequency
0005			110% ≤ < 130% Frequency
0006			130% ≤ < 150% Frequency
0007			150% ≤ < 200% Frequency
0008			200% ≤ < 300% Frequency
0009			300% ≤ < 400% Frequency
0010			400% ≤ < 500% Frequency
0011			500% ≤ Frequency
0020	Setting mode	Present & Extrapolation	0% ≤ < 30% Frequency
0021			30% ≤ < 50% Frequency
0022			50% ≤ < 70% Frequency
0023			70% ≤ < 90% Frequency
0024			90% ≤ < 110% Frequency
0025			110% ≤ < 130% Frequency
0026			130% ≤ < 150% Frequency
0027			150% ≤ < 200% Frequency
0028			200% ≤ < 300% Frequency
0029			300% ≤ < 400% Frequency
0030			400% ≤ < 500% Frequency
0031			500% ≤ Frequency
0040	Inspection mode	Present & Extrapolation	0% ≤ < 30% Frequency
0041			30% ≤ < 50% Frequency
0042			50% ≤ < 70% Frequency
0043			70% ≤ < 90% Frequency
0044			90% ≤ < 110% Frequency
0045			110% ≤ < 130% Frequency
0046			130% ≤ < 150% Frequency
0047			150% ≤ < 200% Frequency
0048			200% ≤ < 300% Frequency
0049			300% ≤ < 400% Frequency
0050			400% ≤ < 500% Frequency
0051			500% ≤ Frequency

Maintenance No.70 Display of load history management data

\$\$\$\$	Mode	Perfomance	Display data		
0060	Rigging mode & Extrapolation	Present	0% \leq	< 30%	Frequency
0061			30% \leq	< 50%	Frequency
0062			50% \leq	< 70%	Frequency
0063			70% \leq	< 90%	Frequency
0064			90% \leq	< 110%	Frequency
0065			110% \leq	< 130%	Frequency
0066			130% \leq	< 150%	Frequency
0067			150% \leq	< 200%	Frequency
0068			200% \leq	< 300%	Frequency
0069			300% \leq	< 400%	Frequency
0070			400% \leq	< 500%	Frequency
0071			500% \leq	Frequency	

Select indication with ##.
4% \$\$\$\$

1
2345
6789

Frequency of the selected load ratio range condition
ex) 123456789 times
(Maximum = 4294967294 times)

Maintenance No.70 Display of load history

5. Maximum load ratio condition for every one hour

LCD1 lower column display ?%

- 5 : Crane [Normal mode]
- Crane [LMI override mode]
- Luffing
- Auxiliary sheaves with jib
- Auxiliary sheaves without jib
- Midfall

\$\$\$\$	Mode	Display data
0000	The newest data	Boom length, Boom hook reeving, Jib length
0001		With or without midfall extension, Jib offset, Jib hook reeving, With or without fixed jib
0002		Midfall hook weight, Boom hook weight, Jib hook weight, Fixed jib hook weight
0003		Curve number, Load ratio, Actual load, Rated load
0004		Boom angle, Jib angle
0005		Radius, Hook selected condition, Drum selected condition
0006		Tip height limit setting condition & setting height
0007		Radius limit setting condition & setting radius
0008		Mode, Performance
0009		Occurred date / time
001\$		
002\$		
003\$		
004\$		
005\$		
006\$		
007\$		
008\$		
009\$		
010\$		
011\$		
012\$		
013\$		
014\$		
015\$		
016\$		
017\$		
018\$		
019\$		
020\$		
021\$		
022\$		
023\$	The oldest data	

Maintenance No.70 Display of load history management data

Select indication with ##.
5 \$\$\$0

18.0	Boom length
14	Boom hook reeving
0.0	Jib length

ex) Boom length 18.0(m)
Boom hook reeving 14(reevings)
Jib length 0.0(m)

Select indication with ##.
5 \$\$\$1

0	With or without midfall extension
0.0	Jib offset
1	Jib hook reeving
0	With or without fixed jib

ex) With or without midfall extensor 0 "without" (1 "with")
Jib offset 0.0(deg)
Jib hook reeving 1(reeving)
With or without fixed jib 0 "without" (1 "with")

Select indication with ##.
5 \$\$\$2

0.00	Midfall hook weight
6.12	Boom hook weight
0.52	Jib hook weight
0.00	Fixed jib hook weight

ex) Midfall hook weight 0.00(t)
Boom hook weight 6.12(t)
Jib hook weight 0.52(t)
Fixed jib hook weight 0.00(t)

Select indication with ##.
5 \$\$\$3

2	Curve number
110.0	Load ratio
123.0	Actual load
112.0	Rated load

ex) Curve number 2
Load ratio 110.0(%)
Actual load 123.0(t)
Rated load 112.0(t)

Select indication with ##.
5 \$\$\$4

75.0	Boom angle
0.0	Jib angle

ex) Boom angle 75.0(deg)
Jib angle 0.0(deg)
<Reference>
"Crane" and "Auxiliary sheaves without jib"
→ Jib angle = 0.0(deg)

Select indication with ##.
5 \$\$\$5

12.3	Radius
0	Hook selected condition
[F]	Drum selected condition

ex) Radius 12.3(m)
Hook selected condition
0 "Boom hook" (1 "Jib hook" / 2 "Fixed jib hook"
(3 "Midfall hook")
Drum selected condition
[F] "Front drum" ([R] "Rear drum" / [3] "3rd drum")
<Reference>
Drum selected condition is blank
when data are not recorded.

Select indication with ##.
5 \$\$\$6

1	Tip height limit setting condition
13.0	Tip height limit setting height

ex) Tip height limit setting condition
1 "Performed" (0 "Not performed")
Tip height limit setting height
13.0(m) "Performed" (---(m) "Not performed")

Select indication with ##.
5 \$\$\$7

1	Radius limit setting condition
14.0	Radius limit setting height

ex) Radius limit setting condition
1 "Performed" (0 "Not performed")
Radius limit setting height
14.0(m) "Performed" (---(m) "Not performed")

Select indication with ##.
5 \$\$\$8

0	Mode
0	Performance

ex) Mode
0 "Work mode" (1 "Setting mode")
(2 "Inspection mode") (3 "Rigging mode")
Performance
0 "Present" (1 "Extrapolation" / 2 "None")

Select indication with ##.
5 \$\$\$9

2003	Year
5. 8	Month and date
THU	A day of the week
19:05	Time

<Reference>
When data are not recorded.

2000
0.0
SUN
00:00

ex) 19:05 May 8, 2003 (Tursday)

Maintenance No.71 Display of error history

Function

This displays error history.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=71 with ##.

4) Press ENTER.

5) LCD1 71: Error history
Press &.

LCD2 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &. @-@@ ??????????

@-@@ :	Error code	C-@@@ , E-@@@ , H-@@@ , S-@@@ , F-@@@
????????? :	Content	Cycles : Error occurred cycles
		Date/Time : Error occurred date and time
		Data : Abnormal value

LCD2 to LCD5 Blank

(When RETURN is pressed, go to the step 5).)

8) Press ## and select error code.

<Reference>

The error code to which the history data is memorized can be selected.

9) Press ENTER.

10) Press ## and select content.

(When RETURN is pressed, go to the step 7).)

Select indication with ##.
@-@@ Cycles

1
2345
6789

Error cycles
ex) 123456789 times
(Maximum = 4294967294 times)

Select indication with ##.
@-@@ Date/Time

2003	Year
5. 8	Month and date
THU	A day of the week
19:05	Time

ex) 19:05 May 8, 2003 (Tursday)

Select indication with ##.
E-10 Data

5000	A/D conversion value

ex) E-10 Boom tension signal error

<Reference>

The value displayed on LCD2 to LCD5 when "Data" is selected are different according to the error code.
Refer to the table for details.

11) Record the values displayed on LCD2 to LCD5.

12) Press RETURN.

13) Return to the step 7).

14) Go to the step 15) after all are recorded.

15) Press RETURN.

16) Return to the step 5).

17) Press RETURN.

18) Return to the step 2).

19) Place the maintenance key switch in "OFF" position.

Maintenance No.71 Display of error history - Table

Code	Name	Error occurred cycles [times]				Error occurred date and time				Abnormal value			
		LCD2	LCD3	LCD4	LCD5	LCD2 Year	LCD3 Month Date	LCD4 A day of the week	LCD5 Time	LCD2	LCD3	LCD4	LCD5
C-2	Layer number error									Drum [F]:Front / [R]:Rear / [3d]:3rd	Layer		
C-4	Total pulse count error									Drum [F]:Front / [R]:Rear / [3d]:3rd	Total pulse count	Total pulse count	Total pulse count
E-10	Boom tension signal error									A/D conversion value (A/Dch0)			
E-11	Jib tension signal error									A/D conversion value (A/Dch1)			
E-12	Boom angle signal error									A/D conversion value (A/Dch2)			
E-13	Jib angle signal error									A/D conversion value (A/Dch3)			
H-14	Grip signal error									A/D conversion value (A/Dch4)			
H-16	Throttle motor signal error									A/D conversion value (A/Dch6)			
H-17	Rack sensor signal error									A/D conversion value (A/Dch7)			
E-20	Jib angle signal for rigging mode error									A/D conversion value (A/Dch10)			
H-21	Foot throttle signal error									A/D conversion value (A/Dch11)			
E-22	Radio Load Cell - MAIN [Front] signal error									A/D conversion value (A/Dch8)			
E-23	Radio Load Cell - AUX [Rear/3rd] signal error									A/D conversion value (A/Dch9)			
E-25	Sensor power supply error									A/D conversion value (A/Dch15)			
E-26	Boom angle signal disconnection									A/D conversion value (A/Dch2)			
E-27	Jib angle signal disconnection									A/D conversion value (A/Dch3)			
E-28	Angle detector connection error									Boom angle [degrees]	Jib angle [degrees]		
S-32	Attachment mode signal error									LMI override mode SW (D/Ich10) 1:ON / 0:OFF	Luffer mode detection (D/Ich11) 1:ON / 0:OFF	Curve number	Attachment mode data
S-33	Mode combination error									LMI override mode SW (D/Ich10) 1:ON / 0:OFF	Luffer mode detection (D/Ich11) 1:ON / 0:OFF	Curve number	Attachment mode data
S-34	Boom hoisting/lowering signal error									Boom hoisting detect (D/Ich20) 1:ON / 0:OFF	Boom lowering detect (D/Ich21) 1:ON / 0:OFF		
S-35	Rear drum hoisting/lowering signal error									Rear drum hoisting detect (D/Ich22) 1:ON / 0:OFF	Rear drum lowering detect (D/Ich23) 1:ON / 0:OFF		
S-36	Front drum hoisting/lowering signal error									Front drum hoisting detect (D/Ich16) 1:ON / 0:OFF	Front drum lowering detect (D/Ich17) 1:ON / 0:OFF		
S-37	3rd drum hoisting/lowering signal error									Rear drum hoisting detect (D/Ich12) 1:ON / 0:OFF	Rear drum lowering detect (D/Ich19) 1:ON / 0:OFF		
S-38	LMI override mode selection error									LMI override mode SW (D/Ich10) 1:ON / 0:OFF	Luffer mode detection (D/Ich11) 1:ON / 0:OFF	Curve number	Attachment mode data
H-40	Throttle motor position error									Throttle motor position [rpm]			
H-41	Throttle motor following error									Required throttle motor position [rpm]	Throttle motor position [rpm]		
H-42	Engine speed error									Engine speed [rpm]	Max. engine speed [rpm] (ROM data)		
H-43	Engine speed signal disconnection									Engine speed [rpm]	Rack sensor signal [V]	Rack sensor zero point correction value [V]	
E-50	Table data none									Table number	Index (0)	Index (1)	Index (2)
A-60	Zero point correction value error												
A-61	Gain correction value error												
A-62	Drift correction value error												
A-65	Adjustment range over												
A-70	Adjustment value error												
F-80	SRAM error									SRAM check data 1 [HEX]	SRAM check data 2 [HEX]	SRAM check data 3 [HEX]	
F-81	Display error												
E-95	Overflow error												

Maintenance No.72 Display of error code

Function

This displays the error codes that occur currently.

This displays the error codes not displayed on the work mode.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=72 with ##.

4) Press ENTER.

5) LCD1 72: Error 0 – 3

##: Select

LCD2 to LCD5 Blank / Error code

(When RETURN is pressed, go to the step 2).)

6) Press ## and select error code block.

Error code block

0- 3

4- 7

8-11

12-15

<Reference>

:

The maximum number of displayed error codes is 40.

24-27

28-31

32-35

36-39

7) Record the error codes displayed on LCD2 to LCD5.

8) Press RETURN.

9) Return to the step 2).

10) Place the maintenance key switch in "OFF" position.

Maintenance No.73 Display of ROM data for load calculating

Function

This displays ROM data for load calculating.

Setting procedures ## : $\Delta\nabla$ & : $\leftarrow\rightarrow$

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=73 with ##.

4) Press ENTER.

5) LCD1 Select content with ##.
 BL/JL/OFFSET/SJ

LCD2 Boom length

LCD3 Jib length

LCD4 Jib offset

LCD5 With or without fixed jib

(When RETURN is pressed, go to the step 2).)

6) Press ## and select content.

BL/JL/OFFSET/FJ : Boom length / Jib length / Jib offset / With or without fixed jib

BA/JA : Boom angle / Jib angle

MO/BS/JS : Tension of the self-weight / Boom suspension arm length / Jib suspension arm length

HB/HJ/HFJ : Boom hook hoisting suspension arm length / Jib hook hoisting suspension arm length / Fixed jib hook hoisting suspension arm length

$\Delta B/\Delta J$: Boom bending angle / Jib bending angle

Refer to the next page for details.






7) Record the error codes displayed on LCD2 to LCD5.

8) Press RETURN.

9) Return to the step 2).

10) Place the maintenance key switch in "OFF" position.

Maintenance No.73 Display of ROM data for load calculating



Maintenance No.74 Display of data number**Function**

This displays the data number of the selected curve number.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.

Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=74 with ##.

4) Press ENTER.

5) LCD1 74: Data No.

LCD2 Data number

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Confirm the number displayed on LCD2.

7) Press RETURN.

8) Return to the step 2).

9) Place the maintenance key switch in "OFF" position.

Maintenance No.75 Display and rewrite of AJST data

Function

This displays and rewrites the various memorized values in RAM.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=75 with ##.

4) Press ENTER.

5) LCD1 75: AJST data
Press &.

LCD2 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 Data No.= ????

LCD2 to LCD5 Blank

(When RETURN is pressed, go to the step 5).)

8) Press ## and select data number.

9) Press ENTER.

10) LCD1 Select content with ##, and press &.
 Setting Yes No

LCD2 Data number

LCD3 Memorized value 0~FFFF(hex)

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 5).)

11) Press ## and select "Yes/No".

If setting the data, select "Yes" and press ENTER. → To 12)

If not setting the data, select "No" and press ENTER. → To 5)

12) LCD1 Select content with ##, and press &.
 &&&

LCD2 Data number

LCD3 Memorized value 0~FFFF(hex) Blinks

LCD4 to LCD5 Blank

When stopping the setting, press RETURN before making the step 13). (Go to the step 5).)

The blinking on LCD3 display goes out.

13) Press ## and select the value.

14) Press ENTER.

15) Return to the step 10).

16) Make sure that the indication on LCD3 shows a value set.

17) Press RETURN.

18) Return to the step 5).

19) Press RETURN.

20) Return to the step 2).

21) Place the maintenance key switch in "OFF" position.

Maintenance No.77 Setting of calendar

Function

This displays and set the calendar informations.

Setting procedures ## : Δ▽ & : ←→

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=77 with ##.


4) Press ENTER.

5) LCD1 77: Indication
& : next ## : other

LCD2 to LCD5 Blank

(When RETURN is pressed, go to the step 2.)

6) Press ## and select the item.



7) Press ENTER.

When selecting display of calendar "77: Indication"

→ To 8-1)

When selecting setting of calendar (Year/Month/Date/A day of the week) "77: Setting date"

→ To 8-2)

When selecting setting of calendar (Time) "77: Setting time"

→ To 8-3)

Display of calendar

8-1) LCD1 Indication finished.
Press &.

LCD2 Year
LCD3 Month/Date
LCD4 A day of the week
LCD5 Time

(When RETURN is pressed, go to the step 5.)

SUN : Sunday	THU : Thursday
MON : Monday	FRI : Friday
TUE : Tuesday	SAT : Saturday
WED : Wednesday	

9-1) Confirm the display.

10-1) Press ENTER.

11-1) Return to the step 5).

12-1) Press RETURN.

13-1) Return to the step 2).

14-1) Place the maintenance key switch in "OFF" position.

Maintenance No.77 Setting of calendar

Setting of calendar (Year/Month/Date/A day of the week)

8-2) LCD1 Select content with ##, and press &.
##/\$\$/%% XXX

: Year 20##
\$\$: Month 01 to 12
% % : Date 01 to 31
XXX : A day of the week

LCD2 Year Blinks
LCD3 Month/Date Blinks
LCD4 A day of the week Blinks
LCD5 Time

SUN : Sunday	THU : Thursday
MON : Monday	FRI : Friday
TUE : Tuesday	SAT : Saturday
WED : Wednesday	

(When RETURN is pressed, go to the step 5.)

9-2) Press ## and select Year/Month/Date/A day of the week.

10-2) Press ENTER.

11-2) LCD1 Setting finished.
Press &.

12-2) Make sure that the indication on LCD2 to LCD4 show Year/Month/Date/A day of the week selected.

13-2) Press ENTER.

14-2) Return to the step 5).

15-2) Press RETURN.

16-2) Return to the step 2).

17-2) Place the maintenance key switch in "OFF" position.

Setting of calendar (Time)

8-3) LCD1 Select content with ##, and press &.
@@:&&

@@ : Hour 00 to 23
&& : Minute 00 to 59

LCD2 Year
LCD3 Month/Date
LCD4 A day of the week
LCD5 Time Blinks

SUN : Sunday	THU : Thursday
MON : Monday	FRI : Friday
TUE : Tuesday	SAT : Saturday
WED : Wednesday	

(When RETURN is pressed, go to the step 5.)

9-3) Press ## and select Hour/Minute.

10-3) Press ENTER.

11-3) LCD1 Setting finished.
Press &.

12-3) Make sure that the indication on LCD5 shows Hour/Minute selected.

13-3) Press ENTER.

14-3) Return to the step 5).

15-3) Press RETURN.

16-3) Return to the step 2).

17-3) Place the maintenance key switch in "OFF" position.

Maintenance No.78 Setting of communication (RS232C)

Function

This selects RS232C communication object and re-initializes the hardware to match with the object.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=78 with ##.

4) Press ENTER.

5) LCD1 78: RS232C Set
Press &.

LCD2 Number

LCD3 Communication object

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 ? ###

? ### 0 DEF : Not connected

1 RMT : Remote control communication

LCD2 Number Blinks

LCD3 Communication object Blinks

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 5).)

8) Press ## and select Number/Communication object.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD3 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 to LCD3 show Number/Communication object selected.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

0 DEF : Not connected

Setable value

0 DEF : Not connected

1 RMT : Remote control communication

Maintenance No.79 Setting of communication (RS485)

Function

This selects RS485 communication object and re-initializes the hardware to match with the object.

Setting procedures ## : Δ▽ & : ↲

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=79 with ##.

4) Press ENTER.

5) LCD1 79: RS485 Set
Press &.

LCD2 Number

LCD3 Communication object

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 ? ###

? ### 0 DEF : Not connected

LCD2 Number Blinks

LCD3 Communication object Blinks

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 5).)

8) Press ## and select Number/Communication object.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD3 display goes out.

9) Press ENTER.

10) Return to the step 5).

11) Make sure that the indication on LCD2 to LCD3 show Number/Communication object selected.

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

0 DEF : Not connected

Setable value

0 DEF : Not connected

Maintenance No.80 Setting of slowdown ratio voltage (Manual)

Function

This enables to change the slowdown ratio voltage (0% and 100% point voltage) for S/C control mode.

<<Caution>>

S/C control mode does not function in LBCE Model.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=80 with ##.

4) Press ENTER.

5) LCD1 80: 0% point
& : next ## : other

LCD2 0% point voltage

LCD3 100% point voltage

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

80 : 0% Setting of 0% point voltage



80 : 100% Setting of 100% point voltage

7) Press ENTER.

8) LCD1 Select content with ##, and press &.

LCD2 Blanks (When "80 : 0%" selected)

LCD3 Blanks (When "80 : 100%" selected)

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 5).)

9) Press ## and select the value.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

The blinking on the corresponding LCD display goes out.

10) Press ENTER.

11) Return to the step 5).

12) Make sure that the indication on the corresponding LCD shows a value selected.

13) Press RETURN.

14) Return to the step 2).

15) Place the maintenance key switch in "OFF" position.

Initial value

0% point voltage : 400 [1.000V]

100% point voltage : 3600 [9.000V]

Setable value

0 [0.000V] ≤ 0% point voltage ≤ 5000 [12.500V]

0 [0.000V] ≤ 100% point voltage ≤ 5000 [12.500V]

Maintenance No.82 Setting of pump control adjustment value (Manual)

Function

This enables to change the pump control adjustment value (Voltage/Displacement).

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=82 with ##.


4) Press ENTER.

5) LCD1 82: P1/P3 Point 1v
& : next ## : other

LCD2 Voltage [*.***V]
LCD3 Displacement [***.*cc/rev]
LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.



7) Press ENTER.

When selecting setting of P?/P? - ##### point - Voltage "82: P?/P? Point %v" → To 8-1)
When selecting setting of P?/P? - ##### point - Displacement "82: P?/P? Point %q" → To 8-2)

Maintenance No.82 Setting of pump control adjustment value (Manual)

Setting of P?/P? - ##### point - Voltage

8-1) LCD1 Select voltage with ##, and press &.
*.***[V]

LCD2	Voltage	[*.***V]	Blinks
LCD3	Displacement	[***.*cc/rev]	
LCD4 to LCD5	Blank		

(When RETURN is pressed, go to the step 5.)

9-1) Set the voltage with ##.

When stopping the setting, press RETURN before making the step 10-1). (Go to the step 5).)

The blinking on LCD2 display goes out.

10-1) Press ENTER.

11-1) Return to the step 5).

12-1) Make sure that the indication on LCD2 shows the voltage set.

13-1) Press RETURN.

14-1) Return to the step 2).

15-1) Place the maintenance key switch in "OFF" position.

Setting of P?/P? - ##### point - Displacement

8-2) LCD1 Select displacement with ##, and press &.
***.*[cc/rev]

LCD2	Voltage	[*.***V]	
LCD3	Displacement	[***.*cc/rev]	Blinks
LCD4 to LCD5	Blank		

(When RETURN is pressed, go to the step 5.)

9-2) Set the displacement with ##.

When stopping the setting, press RETURN before making the step 10-1). (Go to the step 5).)

The blinking on LCD3 display goes out.

10-2) Press ENTER.

11-2) Return to the step 5).

12-2) Make sure that the indication on LCD3 shows the displacement set.

13-2) Press RETURN.

14-2) Return to the step 2).

15-2) Place the maintenance key switch in "OFF" position.

Initial value

Refer to the table.

Setable value

0.000V ≤ Voltage ≤ 9.999V

0.0cc/rev ≤ Displacement ≤ 999.9cc/rev

Maintenance No.83 Setting of pump control adjustment value (Actual machine)

Function

This enables the adjustment of the pump control adjustment value (Voltage) by detecting the drum revolution.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank


3) Set the Mainte No.=83 with ##.

4) Press ENTER.

5) LCD1 83: Minimum Point
& : next ## : other

LCD2 Engine speed	[****rpm]
LCD3 Front/Rear Drum speed	[***.*rpm]
LCD4 Target drum speed	[***.*rpm]
LCD5 Voltage	[*.***V]

(When RETURN is pressed, go to the step 2).)



6) Press ## and select the setting item.

- ▶ 83: Minimum Point Setting of Minimum point - Voltage
- ↑ ↓
- 83: Normal Point Setting of Middle point - Voltage
- ↑ ↓
- ▶ 83: Maximum Point Setting of Maximum point - Voltage

7) Press ENTER.

8) LCD1 Set voltage with ##, and press &.
 *.***V Memory No

LCD2 Engine speed	[****rpm]
LCD3 Front/Rear Drum speed	[***.*rpm]
LCD4 Target drum speed	[***.*rpm]
LCD5 Voltage	[*.***V]

Blinks

(When RETURN is pressed, go to the step 5).)

9) Press ## and set the voltage.

10) Press ENTER.

11) LCD1 Select processing with ##, and press &.
 *.***V Memory No

Memory : Blinks

LCD2 Engine speed	[****rpm]
LCD3 Front/Rear Drum speed	[***.*rpm]
LCD4 Target drum speed	[***.*rpm]
LCD5 Voltage	[*.***V]

Blinks

(When RETURN is pressed, go to the step 8).)

Maintenance No.83 Setting of pump control adjustment value (Actual machine)

- 12) Set the engine speed to 1000 rpm, and operate the front/rear control lever to the 2nd speed position of the hoisting side.

<<Caution>>

The front and rear drum speed become 1st speed, because the front and rear motor displacement become the maximum by FRONT MOTOR CONTROL [D/Ach03] and REAR MOTOR CONTROL [D/Ach04].

- 13) Confirm whether the front/rear drum speed (LCD3) becomes the target drum speed (LCD4).

Return the control lever to the neutral position after confirming.

<<Caution>>

Confirm the drum speed after 5 seconds or more have passed after ENTER is pressed on the step 10).

When the front/rear drum speed dose not become the target drum speed

→ To 14)

When the front/rear drum speed becomes the target drum speed

→ To 16)

When the front/rear drum speed dose not become the target drum speed

- 14) Select "No" with ##, and press ENTER.

- 15) Return to the step 8), and set the voltage again.

When the front/rear drum speed becomes the target drum speed

- 16) Select "Memory" with ##, and press ENTER.

- 17) Make sure that the indication on LCD5 shows the voltage set.

- 18) Return to the step 5).

- 19) Press RETURN.

- 20) Return to the step 2).

- 21) Place the maintenance key switch in "OFF" position.

Initial value

Refer to the table.

Setable value

0.000V ≤ Voltage ≤ 9.999V

Maintenance No.82
Maintenance No.83

Setting of pump control adjustment value (Manual) - Table
Setting of pump control adjustment value (Actual machine) - Table

		Initial value							
		LS-108H5		LS-138H5		LS-218H5		LS-248H5	
		Tier2	Tier3	Tier2	From LS138-4264	Tier2	Tier3	Tier2	Tier3
Minimum point	Voltage (V)	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
	Displacement (cc/rev)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Middle point	Voltage (V)	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
	Displacement (cc/rev)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
Maximum point	Voltage (V)	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
	Displacement (cc/rev)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
		Not used	Not used	Not used	Not used	Not used	Not used	Not used	Not used

Maintenance No.84 Setting of winch motor control adjustment value (Manual)**Function**

This enables to change the winch motor control adjustment value (Voltage/Displacement).

Setting procedures ## : $\Delta\nabla$ & : \leftarrow

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.

Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=84 with ##.

4) Press ENTER.

5) LCD1 84: Front Point 1q
& : next ## : other

LCD2 Displacement [****cc/rev]


LCD3 Voltage [.***V]

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

Maintenance No.84 Setting of winch motor control adjustment value (Manual)

6) Press ## and select the setting item.

→ 84: Front Point 1q	Setting of Front motor - Minimum point - Displacement [308HII, 308H5 : 3rd speed point] [348H5 : 2nd speed point]		D/A ch 3 FRONT MOTOR CONTROL 308HII, 308H5, 348H5
84: Front Point 1v	Setting of Front motor - Minimum point - Voltage [308HII, 308H5 : 3rd speed point] [348H5 : 2nd speed point]		
84: Front Point 2q	Setting of Front motor - Middle point - Displacement [308HII, 308H5 : 2nd speed point] [348H5 : Not used]		
84: Front Point 2v	Setting of Front motor - Middle point - Voltage [308HII, 308H5 : 2nd speed point] [348H5 : Not used]		
84: Front Point 3q	Setting of Front motor - Maximum point - Displacement [308HII, 308H5 : 1st speed point] [348H5 : 1st speed point]		
84: Front Point 3v	Setting of Front motor - Maximum point - Voltage [308HII, 308H5 : 1st speed point] [348H5 : 1st speed point]		
84: Rear Point 1q	Setting of Rear motor - Minimum point - Displacement [308HII, 308H5 : 3rd speed point] [348H5 : 2nd speed point]		
84: Rear Point 1v	Setting of Rear motor - Minimum point - Voltage [308HII, 308H5 : 3rd speed point] [348H5 : 2nd speed point]		
84: Rear Point 2q	Setting of Rear motor - Middle point - Displacement [308HII, 308H5 : 2nd speed point] [348H5 : Not used]		
84: Rear Point 2v	Setting of Rear motor - Middle point - Voltage [308HII, 308H5 : 2nd speed point] [348H5 : Not used]		
84: Rear Point 3q	Setting of Rear motor - Maximum point - Displacement [308HII, 308H5 : 1st speed point] [348H5 : 1st speed point]		
84: Rear Point 3v	Setting of Rear motor - Maximum point - Voltage [308HII, 308H5 : 1st speed point] [348H5 : 1st speed point]		
84: 3rd Point 1q	Setting of 3rd motor - Minimum point - Displacement [308HII, 308H5 : Not used] [348H5 : Not used]		
84: 3rd Point 1v	Setting of 3rd motor - Minimum point - Voltage [308HII, 308H5 : Not used] [348H5 : Not used]		
84: 3rd Point 2q	Setting of 3rd motor - Maximum point - Displacement [308HII, 308H5 : Not used] [348H5 : Not used]		
84: 3rd Point 2v	Setting of 3rd motor - Maximum point - Voltage [308HII, 308H5 : Not used] [348H5 : Not used]		
→ 84: 3rd Point 2v			
			D/A ch 4 REAR MOTOR CONTROL 308HII, 308H5, 348H5
			D/Ach6 Not used

7) Press ENTER.

When selecting setting of ?????? motor - ##### point - Displacement "84: ?????? Point %q" → To 8-1)
When selecting setting of ?????? motor - ##### point - Voltage "84: ?????? Point %v" → To 8-2)

Maintenance No.84 Setting of winch motor control adjustment value (Manual)

Setting of ???? motor - ##### point - Displacement

8-1) LCD1 Select displacement with ##, and press &
****[cc/rev]

LCD2 Displacement [****cc/rev] Blinks
LCD3 Voltage [*.***V]
LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 5.)

9-1) Set the displacement with ##.

When stopping the setting, press RETURN before making the step 10-1). (Go to the step 5).)

The blinking on LCD2 display goes out.

10-1) Press ENTER.

11-1) Return to the step 5).

12-1) Make sure that the indication on LCD2 shows the displacement set.

13-1) Press RETURN.

14-1) Return to the step 2).

15-1) Place the maintenance key switch in "OFF" position.

Setting of ???? motor - ##### point - Voltage

8-2) LCD1 Select voltage with ##, and press &
*.***[V]

LCD2 Displacement [****cc/rev]
LCD3 Voltage [*.***V] Blinks
LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 5.)

9-2) Set the voltage with ##.

When stopping the setting, press RETURN before making the step 10-2). (Go to the step 5).)

The blinking on LCD3 display goes out.

10-2) Press ENTER.

11-2) Return to the step 5).

12-2) Make sure that the indication on LCD3 shows the voltage set.

13-3) Press RETURN.

14-3) Return to the step 2).

15-2) Place the maintenance key switch in "OFF" position.

Initial value

Refer to the table.

Setable value

0cc/rev ≤ Displacement ≤ 9999cc/rev
0.000V ≤ Voltage ≤ 9.999V

Maintenance No.85 Setting of winch motor control adjustment value (Actual machine)

Function

This enables the adjustment of the winch motor control adjustment value (Voltage) by detecting the drum revolution.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank


3) Set the Mainte No.=85 with ##.

4) Press ENTER.

5) LCD1 85: F 1st point
& : next ## : other

LCD2 Engine speed [****rpm]
LCD3 Front/Rear/3rd Drum speed [***.*rpm]
LCD4 Target drum speed [***.*rpm]
LCD5 Voltage [*.***V]

(When RETURN is pressed, go to the step 2.)



6) Press ## and select the setting item.

→ 85: F 1st point



85: F 3rd point



85: R 1st point



85: R 3rd point



85: 3 1st point



→ 85: 3 2nd point

Setting of Front motor - Maximum point - Voltage

[308HII, 308H5 : 1st speed point]
[348H5 : 1st speed point]

Setting of Front motor - Minimum point - Voltage

[308HII, 308H5 : 3rd speed point]
[348H5 : 2nd speed point]

Setting of Rear motor - Maximum point - Voltage

[308HII, 308H5 : 1st speed point]
[348H5 : 1st speed point]

Setting of Rear motor - Minimum point - Voltage

[308HII, 308H5 : 3rd speed point]
[348H5 : 2nd speed point]

Setting of 3rd motor - Maximum point - Voltage

[308HII, 308H5 : Not used]
[348H5 : Not used]

Setting of 3rd motor - Minimum point - Voltage

[308HII, 308H5 : Not used]
[348H5 : Not used]

D/A ch 3
FRONT MOTOR
CONTROL
308HII, 308H5, 348H5

D/A ch 4
REAR MOTOR
CONTROL
308HII, 308H5, 348H5

D/A ch 6
Not used

7) Press ENTER.

8) LCD1 Set voltage with ##, and press &. *.***V Memory No

LCD2 Engine speed [****rpm]
LCD3 Front/Rear/3rd Drum speed [***.*rpm]
LCD4 Target drum speed [***.*rpm]
LCD5 Voltage [*.***V]

(When RETURN is pressed, go to the step 5.)

Blinks

9) Press ## and set the voltage.

10) Press ENTER.

Maintenance No.85 Setting of winch motor control adjustment value (Actual machine)

- 11) LCD1 Select processing with ##, and press &. *.*V Memory No Memory : Blinks
- | | | |
|------|---------------------------|------------|
| LCD2 | Engine speed | [****rpm] |
| LCD3 | Front/Rear/3rd Drum speed | [***.*rpm] |
| LCD4 | Target drum speed | [***.*rpm] |
| LCD5 | Voltage | [*.***V] |
- Blinks
(When RETURN is pressed, go to the step 8).)
- 12) Set the engine speed to 1000 rpm, and operate the front/rear/3rd control lever to the 2nd speed position of the hoisting side.
<<Caution>>
 It takes time to becoming the set voltage after the control lever is operated.
- 13) Confirm whether the front/rear/3rd drum speed (LCD3) becomes the target drum speed (LCD4).
 Return the control lever to the neutral position after confirming.
<<Caution>>
 A. 85: F 1st point / 85: R 1st point / 85: 3 1st point
 Confirm the drum speed after 14 seconds or more have passed after the control lever is operated on the step 12).
 B. 85: F 3rd point / 85: R 3rd point / 85: 3 2nd point
 Confirm the drum speed after 7 seconds or more have passed after the control lever is operated on the step 12).

When the front/rear/3rd drum speed dose not become the target drum speed → To 14)
 When the front/rear/3rd drum speed becomes the target drum speed → To 16)

- When the front/rear/3rd drum speed dose not become the target drum speed
 14) Select "No" with ##, and press ENTER.
<<Caution>>

It becomes effective when ENTER is pressed after 3 seconds pass after the control lever is returned to the neutral position.
 When ENTER is pressed before the time of the step 13), it becomes invalid.

- 15) Return to the step 8), and set the voltage again.

- When the front/rear/3rd drum speed becomes the target drum speed
 16) Select "Memory" with ##, and press ENTER.
<<Caution>>

It becomes effective when ENTER is pressed after 3 seconds pass after the control lever is returned to the neutral position.
 When ENTER is pressed before the time of the step 13), it becomes invalid.

- 17) Make sure that the indication on LCD5 shows the voltage set.

- 18) Return to the step 5).
 19) Press RETURN.
 20) Return to the step 2).
 21) Place the maintenance key switch in "OFF" position.

Initial value

Refer to the table.

Setable value

0.000V ≤ Voltage ≤ 9.999V

Maintenance No.84
Maintenance No.85

Setting of winch motor control adjustment value (Manual) - Table
Setting of winch motor control adjustment value (Actual machine) - Table

		Initial value																
		LS-108H5			LS-138H5			LS-218H5			LS-238H5			LS-248H5			LS-348H5	
		Tier2	Tier3	Tier2	Tier2	From LS138-4264	Tier2	Tier3	Only LS308-4000	From LS308-4001								
Front & Rear motor	Minimum point	Displacement (cc/rev)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	533	533
	Voltage (V)	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	4.891	4.891	
Middle point	Displacement (cc/rev)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	300	300
	Voltage (V)	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	3.377	3.232
Maximum point	Displacement (cc/rev)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	192	192
	Voltage (V)	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	1.935	1.804
		Not used	Not used	Not used	Not used	Not used	Not used	Not used	Not used	Not used	Not used	Not used	Not used	Not used	Not used	Not used		
3rd motor	Minimum point	Displacement (cc/rev)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	Voltage (V)	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
Maximum point	Displacement (cc/rev)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	Voltage (V)	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

Maintenance No.87 Display of drum speed

Function

This displays the drum speed.

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=87 with ##.

4) Press ENTER.

5) LCD1 87: Drum speed

LCD2 Front drum speed [***.*rpm]

LCD3 Rear drum speed [***.*rpm]

LCD4 3rd drum speed [***.*rpm]

LCD5 Blank

6) Press RETURN.

7) Return to the step 2).

8) Place the maintenance key switch in "OFF" position.

Maintenance No.88 Debug mode

Function

This displays various control values.

Setting procedures # : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=88 with ##.

4) Press ENTER.

5) Press ## and select content. (Refer to the followings)

6) Press RETURN.

7) Return to the step 2).

8) Place the maintenance key switch in "OFF" position.

0 : S Smo P1v P2v	Throttle control
## : other	Pump control
**** rpm	Required throttle
**** rpm	Throttle motor position
**** V	Output voltage : MAIN PUMP CONTROL
**** V	Output voltage : Not used
	(D/A ch 1) (D/A ch 2)
1 : Sg St Ego Egc	Throttle control
## : other	Engine speed display
**** rpm	Required throttle : Grip / Throttle volume
**** rpm	Required throttle : Foot pedal
**** rpm	Engine speed : For control
**** rpm	Engine speed : For display
	(A/D ch 4) (A/D ch 11) (CNT ch 0) (CNT ch 0)
2 : P1c P2c P1v P2v	Pump control
## : other	
**** cc/rev	Required displacement : MAIN PUMP CONTROL
**** cc/rev	Required displacement : Not used
**** V	Output voltage : MAIN PUMP CONTROL
**** V	Output voltage : Not used
	(D/A ch 1) (D/A ch 2)
3 : Fdc Rdc Fdv Rdv	Winch motor control
## : other	
**** cc/rev	Required displacement : FRONT MOTOR CONTROL
**** cc/rev	Required displacement : REAR MOTOR CONTROL
**** V	Output voltage : FRONT MOTOR CONTROL
**** V	Output voltage : REAR MOTOR CONTROL
	(D/A ch 3) (D/A ch 4)
4 : Fds Rds Fdc Rdc	Drum revolution detection
## : other	Winch motor control
**** rpm	Drum revolution : Front <Not used>
**** rpm	Drum revolution : Rear <Not used>
**** cc/rev	Required displacement : FRONT MOTOR CONTROL
**** cc/rev	Required displacement : REAR MOTOR CONTROL
	(U/D CNT ch 0) (U/D CNT ch 1)

Maintenance No.88 Debug mode

13 : Egc Pzt Pzr Pz ## : other	Power shift control	
**** rpm	Engine speed : For control	(CNT ch 0)
**** kgf/cm ²	Power shift pressure : N-Pz curve control	
**** kgf/cm ²	Power shift pressure : Rack sensor control	
**** kgf/cm ²	Power shift pressure : Final value	
14 : Egc Pz Pzmax DA ## : other	Power shift control	
**** rpm	Engine speed : For control	(CNT ch 0)
**** kgf/cm ²	Power shift pressure : Final value	
**** kgf/cm ²	Maximum power shift pressure	
**** V	Output voltage : POWER SHIFT CONTROL	(D/A ch 0)
15 : Egc Ra Rh Rlim ## : other	Power shift control	
**** rpm	Engine speed : For control	(CNT ch 0)
**** V	Rack sensor voltage	(A/D ch 7)
**** V	Rack sensor target voltage	
**** V	Rack sensor engine stall prevention judgement voltage	
16 : pump 1 ## : other	Pump control - MAIN PUMP CONTROL	
**** cc/rev	Required displacement - This time	
**** cc/rev	Required displacement - Last time	
**** cc/rev	Required displacement - First delay processing - Last time	
**** cc/rev	Required displacement - First delay processing - This time	
17 : pump 2 ## : other	Pump control - MAIN PUMP CONTROL	
**** cc/rev	Required displacement - First delay processing - Last time	
**** cc/rev	Required displacement - First delay processing - This time	
**** cc/rev	Required displacement - First delay processing	
**** cc/rev	Required displacement - Final	
18 : ECU ## : other	ECU/ECM control	
****	A/D conversion value : Grip	(A/D ch 4)
****	D/A conversion value - Calculation 1st : ENGINE THROTTLE	(D/A ch 7)
****	D/A conversion value - Calculation 2nd : ENGINE THROTTLE	(D/A ch 7)
****	D/A conversion value - Output : ENGINE THROTTLE	(D/A ch 7)
19 : DA 0-3 ## : other		
****	D/A conversion value - Output : POWER SHIFT CONTROL	(D/A ch 0)
****	D/A conversion value - Output : MAIN PUMP CONTROL	(D/A ch 1)
****	D/A conversion value - Output : Not used	(D/A ch 2)
****	D/A conversion value - Output : FRONT MOTOR CONTROL	(D/A ch 3)
20 : DA 4-7 ## : other		
****	D/A conversion value - Output : REAR MOTOR CONTROL	(D/A ch 4)
****	D/A conversion value - Output : Not used	(D/A ch 5)
****	D/A conversion value - Output : Not used	(D/A ch 6)
****	D/A conversion value - Output : ENGINE THROTTLE	(D/A ch 7)

Maintenance No.89 Boom protection device non-function mode

Function

This is the mode that functions the same to the work mode except the boom protection device. It doesn't shift from this mode to "Setting Mode/Rigging Mode/Inspection Mode".

Setting procedures ## : Δ▽ & : ←

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)


2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=89 with ##.

4) Press ENTER.

5) The contents of the display of from LCD1 to LCD5 are the same as the contents of the display of the work mode.



- 6) Press RETURN.
- 7) Return to the step 2).
- 8) Place the maintenance key switch in "OFF" position.

Maintenance No.91 Display of tension

Function

This enables to display the boom/jib load cell detection tension.

Setting procedures ## : Δ▽ & : ←→

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.

Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=91 with ##.

4) Press ENTER.

5) LCD1 91: Tension

LCD2 Boom load cell detection tension [**.*t]

LCD3 Jib load cell detection tension [**.*t]

LCD4 Blank

LCD5 Actual load [***.*t]

Reference

The tension displayed on the this maintenance is T1.

The tension to be used with the actual load calculation is T3.

$$T1 [t] = ((\text{A/D conversion value} - \text{Zero point correction value}) \times \text{Gain correction value}) \\ \times \text{Load cell capacity} / 5000$$

$$T2 [t] = T1 - \text{Drift correction value}$$

$$\begin{array}{ll} \text{<Hoisting>} & T3 [t] = T2 \times \text{hysteresis correction value} \\ \text{<Lowering>} & T3 [t] = T2 / \text{hysteresis correction value} \end{array}$$

6) Press RETURN.

7) Return to the step 2).

8) Place the maintenance key switch in "OFF" position.

Maintenance No.92 Display of angle

Function

This enables to display the boom/jib angle.

Setting procedures ## : Δ▽ & : ↲

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=92 with ##.

4) Press ENTER.

5) LCD1 92: Angle

LCD2 Boom angle [***.*deg]

LCD3 Jib angle [***.*deg]

LCD4 to LCD5 Blank

Reference

The angle displayed on the this maintenance is θ 1.

The angle to be used with the working radius calculation and displayed on the work mode is θ 3.

$$\theta 1 [\text{deg}] = ((\text{A/D conversion value} - \text{Zero point correction value}) \times \text{Gain correction value} + 3333) \\ \times 90 / 5000$$

$$\theta 2 [\text{deg}] = \theta 1 - \text{Drift correction value}$$

$$\theta 3 [\text{deg}] = \theta 2 + \text{Bending angle}$$

6) Press RETURN.

7) Return to the step 2).

8) Place the maintenance key switch in "OFF" position.

Maintenance No.95 Setting of self-weight correction value (Manual)

Function

This enables to change the self-weight correction value.

Setting procedures ## : Δ▽ & : ↶

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=95 with ##.

4) Press ENTER.

5) LCD1 95: Adjust point 1
& : next ## : other

LCD2 Self-weight correction value [*.***]

LCD3 Angle of correction point [**.*deg]

LCD4 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

6) Press ## and select the setting item.

► 95: Adjust point 1 Setting of self-weight correction value - Correction point No.1



95: Adjust point 2 Setting of self-weight correction value - Correction point No.2



95: Adjust point 3 Setting of self-weight correction value - Correction point No.3



95: Adjust point 4 Setting of self-weight correction value - Correction point No.4



95: Adjust point 5 Setting of self-weight correction value - Correction point No.5



95: Adjust point 6 Setting of self-weight correction value - Correction point No.6



95: Adjust point 7 Setting of self-weight correction value - Correction point No.7 <<Only Luffing>>



95: Adjust point 8 Setting of self-weight correction value - Correction point No.8 <<Only Luffing>>



95: Adjust point 9 Setting of self-weight correction value - Correction point No.9 <<Only Luffing>>



► 95: Adjust point 0 Setting of self-weight correction value - Correction point No.10 <<Only Luffing>>

7) Press ENTER.

8) LCD1 Select content with ##, and press &.
 *.***

LCD2 Self-weight correction value [*.***] Blinks

LCD3 Angle of adjust point [**.*deg]

LCD4 to LCD5 Blank

9) Set the self-weight correction value with ##.

When stopping the setting, press RETURN before making the step 10). (Go to the step 5).)

Maintenance No.95 Setting of self-weight correction value (Manual)

- 10) Press ENTER.
- 11) Make sure that the indication on LCD2 shows the self-weight correction value set.
- 12) Return to the step 5).

- 13) Press RETURN.
- 14) Return to the step 2).
- 15) Place the maintenance key switch in "OFF" position.

Initial value

Self-weight correction value : 1.000
Angle of correction point : Refer to the table.

Setable value

$0.000 < \text{Self-weight correction value} \leq 9.999$

Maintenance No.95 Setting of self-weight correction value (Manual) - Table**Crane**

No.	Correction point						
	Boom angle [deg]						
	LS-108H5	LS-138H5	LS-218H5	LS-238H5	LS-308HII / LS-308H5	LS-248H5	LS-348H5
6	80.10	80.10	80.10	78.10	80.00	80.10	HD : 81.10 LR : 80.10
5	77.10	75.30	75.30	72.70	75.00	75.00	74.00
4	65.00	65.00	65.00	65.00	65.00	65.00	65.00
3	55.00	55.00	55.00	55.00	55.00	55.00	55.00
2	40.00	40.00	40.00	40.00	40.00	40.00	40.00
1	20.00	20.00	20.00	20.00	20.00	20.00	20.00

Luffing

No.	Correction point						
	Luffing jib angle [deg]						
	LS-108H5	LS-138H5	LS-218H5	LS-238H5	LS-308HII / LS-308H5	LS-248H5	LS-348H5
10	N/A	N/A	73.10	73.10	N/A	No correction	No correction
9	N/A	N/A	65.00	65.00	N/A	No correction	No correction
8	N/A	N/A	60.00	60.00	N/A	No correction	No correction
7	N/A	N/A	55.00	55.00	N/A	No correction	No correction
6	N/A	N/A	50.00	50.00	N/A	No correction	No correction
5	N/A	N/A	45.00	45.00	N/A	No correction	No correction
4	N/A	N/A	40.00	40.00	N/A	No correction	No correction
3	N/A	N/A	35.00	35.00	N/A	No correction	No correction
2	N/A	N/A	20.00	20.00	N/A	No correction	No correction
1	N/A	N/A	5.00	5.00	N/A	No correction	No correction

LS-248H5 & LS-348H5

No self-weight correction, because these models use radio load cell.

Maintenance No.95 Setting of self-weight correction value (Manual) - Table
Aux. Sheaves w/ Jib

No.	Correction point						
	Luffing boom angle [deg]						
	LS-108H5	LS-138H5	LS-218H5	LS-238H5	LS-308HII / LS-308H5	LS-248H5	LS-348H5
6	N/A	N/A	78.10	78.10	N/A	N/A	No correction
5	N/A	N/A	75.10	72.70	N/A	N/A	No correction
4	N/A	N/A	70.00	70.00	N/A	N/A	No correction
3	N/A	N/A	65.00	65.00	N/A	N/A	No correction
2	N/A	N/A	60.00	60.00	N/A	N/A	No correction
1	N/A	N/A	55.00	55.00	N/A	N/A	No correction

LS-348H5

No self-weight correction, because this model use radio load cell.

Aux. Sheaves w/o Jib

No.	Correction point						
	Luffing boom angle [deg]						
	LS-108H5	LS-138H5	LS-218H5	LS-238H5	LS-308HII / LS-308H5	LS-248H5	LS-348H5
6	N/A	N/A	78.10	78.10	N/A	N/A	No correction
5	N/A	N/A	75.10	72.70	N/A	N/A	No correction
4	N/A	N/A	65.00	65.00	N/A	N/A	No correction
3	N/A	N/A	55.00	55.00	N/A	N/A	No correction
2	N/A	N/A	40.00	40.00	N/A	N/A	No correction
1	N/A	N/A	20.00	20.00	N/A	N/A	No correction

LS-348H5

No self-weight correction, because this model use radio load cell.

Maintenance No.96 Setting of tension drift correction value (Actual machine)

Function

This enables to adjust the drift correction value of the load cell for boom/jib hoist rope tension detection.

Setting procedures ## : Δ∇ & : ←↓

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.

Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=96 with ##.

4) Press ENTER.

5) LCD1 96: Tension drift
Press &.

LCD2 Drift correction value - Boom load cell

LCD3 Drift correction value - Jib load cell

LCD4 to LCD5 Content same as Work mode

(When RETURN is pressed, go to the step 2).)

6) Press ENTER.

Setting of curve number

Crane, Aux. Sheaves w/ Jib, Aux. Sheaves w/o Jib	→ To 7-1)
Luffing	→ To 7-2)

Drift correction value of boom load cell

7-1) LCD1 Hoist up boom/jib hook to overhoist position and press &.

Hoist up the boom/jib hook to the anti-two block limit switch position.

When stopping the setting, press RETURN before making the step 8-1). (Go to the step 5).)

8-1) Press ENTER.

9-1) LCD1 Set hook selection sw at target hook and press &.

Select the boom hook with the hook selection switch.

When the boom hook is not attached, select the jib hook.

When stopping the setting, press RETURN before making the step 10-1). (Go to the step 7-1).)

10-1) Press ENTER.

11-1) Return to the step 5).

12-1) Make sure that the indication on LCD2 changes.

13-1) Press RETURN.

14-1) Return to the step 2).

15-1) Place the maintenance key switch in "OFF" position.

Maintenance No.96 Setting of tension drift correction value (Actual machine)

Drift correction value of jib load cell

7-2) LCD1 Hoist up jib/short jib hook to overhoist position and press &.

Hoist up the luffing jib/fixed jib hook to the anti-two block limit switch position.

When stopping the setting, press RETURN before making the step 8-2). (Go to the step 5).)

8-2) Press ENTER.

9-2) LCD1 Set hook selection sw at target hook and press &.

Select the luffing jib hook with the hook selection switch.

When the luffing jib hook is not attached, select the fixed jib hook.

When stopping the setting, press RETURN before making the step 10-2). (Go to the step 7-2).)

10-2) Press ENTER.

11-2) Return to the step 5).

12-2) Make sure that the indication on LCD3 changes.

13-2) Press RETURN.

14-2) Return to the step 2).

15-2) Place the maintenance key switch in "OFF" position.

Initial value

Drift correction value : 0.00

Setable value

- (Load cell capacity X 0.1) ≤ Drift correction value ≤ (Load cell capacity X 0.1)

Maintenance No.97 Setting of offset angle drift correction value (Manual)

Function

This enables to change the drift correction value of crane jib offset angle.

Setting procedures ## : ΔV & : \leftarrow

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with ##, and press &.
 Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=97 with ##.

4) Press ENTER.

5) LCD1 97: Offset drift
Press &.

LCD2 Drift correction value

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 2).)

<<Caution>>

CASE1 : The setting of the configuration is not "Crane w/Jib".

LCD1 Cannot be set, in this style.

→ Press RETURN, and return to the step 2).

CASE2 : "Setting of offset angle drift correction value (Actual machine) [Maintenance No.98]" is not executed.

LCD1 Not adjusted, in this style.

→ Press RETURN, and return to the step 2).

6) Press ENTER.

7) LCD1 Select content with ##, and press &.
 .

LCD2 Drift correction value [**.**deg] Blinks

LCD3 to LCD5 Blank

(When RETURN is pressed, go to the step 5).)

8) Set the offset angle drift correction value with ##.

When stopping the setting, press RETURN before making the step 9). (Go to the step 5).)

The blinking on LCD2 display goes out.

9) Press ENTER.

10) Make sure that the indication on LCD2 shows the drift correction value set.

11) Return to the step 5).

12) Press RETURN.

13) Return to the step 2).

14) Place the maintenance key switch in "OFF" position.

Initial value

Drift correction value : 0.00

Setable value

-9.99 ≤ Drift correction value ≤ 9.99

Maintenance No.98 Setting of offset angle drift correction value (Actual machine)

Function

This enables to adjust the drift correction value of crane jib offset angle.

Setting procedures $\# \Delta \nabla \& \leftarrow$

1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)

2) LCD1 Select content with $\#$, and press &
Mainte No.= 0

LCD2 to LCD5 Blank

3) Set the Mainte No.=98 with $\#$.

4) Press ENTER.

5) LCD1 Select adjustment with $\#$, and press &
Adjust Clear

LCD2 Drift correction value

LCD3 Execution condition of adjustment " - - - " Blinks : Unexecution / Blank : Done

LCD4 to LCD5 Content same as Work mode

(When RETURN is pressed, go to the step 2).)

When adjusting the offset angle drift correction value → To 6-1)

When clearing the offset angle drift correction value → To 6-2)

Adjusting the offset angle drift correction value

6-1) Select "Adjust" with $\#$, and press ENTER.

7-1) LCD1 Set boom angle at 60° , and press &

When stopping the setting, press RETURN before making the step 8-1). (Go to the step 2).)

8-1) Adjust the boom angle to $60 \pm 1^\circ$ on LCD5 with the boom raising or lowering.

9-1) Press ENTER.

10-1) LCD1 Set hook selection at jib hook, and press &

11-1) Select the jib hook with the hook selection switch.

12-1) Press ENTER.

13-1) LCD1 Set measured jib hook radius with $\#$, and press &
**.*m

14-1) Measure the working radius of the jib hook.

15-1) Set the measured working radius with $\#$.

When stopping the setting, press RETURN before making the step 16-1). (Go to the step 2).)

16-1) Press ENTER.

17-1) LCD1 Calculating now.

18-1) LCD1 Adjustment completed. Press &.

The drift correction value displayed on LCD2 changes.

The execution condition of adjustment displayed on LCD3 changes to blank.

19-1) Press ENTER.

20-1) Return to the step 5).

21-1) Press RETURN.

22-1) Return to the step 2).

23-1) Place the maintenance key switch in "OFF" position.

Maintenance No.98 Setting of offset angle drift correction value (Actual machine)

Clearing the offset angle drift correction value

6-2) Select "Adjust" with ##, and press ENTER.

7-2) LCD1 **Select adjustment with ##, and press &.**
Only All

When stopping the setting, press RETURN before making the step 8-1). (Go to the step 2).)

8-2) Select the clearing content with ##, and press ENTER.

9-2) CASE1 : When selecting "Only"

LCD1 **Clear current corrected values only. Press &.**

CASE2 : When selecting "All"

LCD1 **Clear all corrected values. Press &.**

10-2) Press ENTER.

11-2) LCD1 **Calculating now.**

12-2) LCD1 **Clearing completed. Press &.**

The drift correction value displayed on LCD2 changes to 0.00° .

The execution condition of adjustment displayed on LCD3 changes to "----" blinks.

13-2) Press ENTER.

14-2) Return to the step 5).

15-2) Press RETURN.

16-2) Return to the step 2).

17-2) Place the maintenance key switch in "OFF" position.

Initial value

Drift correction value : 0.00

Setable value

-9.99 ≤ Drift correction value ≤ 9.99

Maintenance No.99 Display of ROM informations

Function

This displays the ROM informations.

Setting procedures ## : Δ▽ & : ←

- 1) Place the maintenance key switch in "ON" position. (Input 2.5V or more at A/D ch14.)
- 2) LCD1 Select content with ##, and press &. Mainte No.= 0

LCD2 to LCD5 Blank

- 3) Set the Mainte No.=99 with ##.
- 4) Press ENTER.

- 5) Press ## and select content. (Refer to the followings)

- 6) Press RETURN.

- 7) Return to the step 2).

- 8) Place the maintenance key switch in "OFF" position.

